boAt Rockerz 260

boAt Rockerz 260 Bluetooth In-Ear Earphones User Manual

Model: Rockerz 260 | Brand: boAt

1. Overview

The boAt Rockerz 260 is a wireless neckband designed for an enhanced audio experience. It incorporates features such as low-latency Beast™ Mode for gaming, ENx™ Technology for clear voice calls, and ASAP™ Charge for quick power-ups. The neckband offers up to 25 hours of playback and is built with IPX5 water resistance, making it suitable for various environments.

2. What's in the Box

- 1 X Neckband (boAt Rockerz 260)
- 1 X Charging Cable (Type-C)
- 1 X User Manual
- 2 X Additional Earbuds (pairs)

3. Getting Started

3.1 Charging the Earphones

Before first use, fully charge the earphones. Connect the provided Type-C charging cable to the charging port on the neckband and to a compatible USB power source. The LED indicator will show charging status.
The ASAP™ Charge technology allows for up to 10 hours of playtime with just 10 minutes of charging. A full charge provides up to 25 hours of playback.



Image: Earphones highlighting ASAP Charge and 25 hours playback.

3.2 Powering On/Off

- **To Power On:** Press and hold the Multi-function Button until the LED indicator flashes.
- **To Power Off:** Press and hold the Multi-function Button until the LED indicator turns off.

3.3 Bluetooth Pairing

1. Ensure the earphones are powered off.
2. Press and hold the Multi-function Button until the LED indicator flashes blue and red alternately, indicating pairing mode.
3. On your device (smartphone, tablet, laptop), enable Bluetooth and search for available devices.
4. Select "boAt Rockerz 260" from the list of devices.
5. Once connected, the LED indicator will flash blue periodically.

The Rockerz 260 supports Bluetooth v5.2 and Dual Pairing, allowing connection to two devices simultaneously.



Image: Earphones demonstrating IPX5 water resistance and Bluetooth V5.2 dual pairing capability.

4. Controls and Functions

The boAt Rockerz 260 features easy-access controls for managing audio playback, calls, and voice assistant activation.

- **Multi-function Button:** Power On/Off, Play/Pause, Answer/End Calls.
- **Volume Up (+):** Increase volume, Next track (long press).
- **Volume Down (-):** Decrease volume, Previous track (long press).
- **Voice Assistant:** Activate your device's default voice assistant (specific button or long press on Multi-function Button, refer to product diagram if available).

5. Features Explained

5.1 Beast™ Mode (Low Latency)

Beast™ Mode provides ultra-low latency (as low as 65ms), optimizing the audio-visual synchronization for gaming and video streaming. This reduces delay between audio and video, offering a more immersive experience.



Image: Earphones showcasing the Beast Mode feature for low latency.

5.2 ENx™ Technology (Environmental Noise Cancellation)

ENx™ Technology is designed to cancel environmental noise during voice calls. This ensures your voice is transmitted clearly to the other party, even in noisy surroundings, improving call quality.



Image: Earphones demonstrating ENx Technology for clear voice calls.

5.3 10mm Audio Drivers

The earphones are equipped with 10mm audio drivers, engineered to deliver boAt's signature immersive sound. These drivers provide a balanced audio output with clear highs and deep bass.



Image: Detailed view of the 10mm audio drivers within the earbud.

5.4 IPX5 Water and Sweat Resistance

With an IPX5 rating, the Rockerz 260 earphones are resistant to splashes of water and sweat. This makes them suitable for workouts and outdoor activities, protecting them from moisture damage.

6. Care and Maintenance

- Clean the earphones regularly with a soft, dry cloth.
- Avoid exposing the earphones to extreme temperatures or direct sunlight.
- Do not use abrasive cleaners or immerse the earphones in water.
- Store the earphones in a cool, dry place when not in use.
- Ensure the charging port is dry before connecting the charging cable.

7. Troubleshooting

7.1 No Power

- Ensure the earphones are fully charged.
- Check the charging cable and power source for proper connection.

7.2 Pairing Issues

- Make sure Bluetooth is enabled on your device.
- Ensure the earphones are in pairing mode (LED flashing blue and red).
- Move the earphones closer to your device.
- Forget the device from your phone's Bluetooth settings and try pairing again.

7.3 Low Sound Quality

- Adjust the volume on both the earphones and your connected device.
- Ensure the earbuds are properly seated in your ears for optimal sound.
- Clean any debris from the earbud mesh.

8. Specifications

Brand	boAt
Model Name	Rockerz 260
Colour	Electric Purple
Ear Placement	In Ear
Form Factor	In Ear (Neckband)
Noise Control	Environmental Noise Cancellation (ENx™)
Connectivity Technology	Bluetooth v5.2
Playback Time	Up to 25 hours
Charging Technology	ASAP™ Charge (10 min charge = 10 hrs playtime)
Drivers	10mm Audio Drivers
Latency	65ms (Beast™ Mode)
Water Resistance	IPX5
Control Type	Voice Control
Item Weight	32 Grams

9. Warranty and Support

The boAt Rockerz 260 comes with a **1-year warranty** from the date of purchase. For warranty claims or technical support, please refer to the contact information provided in the product packaging or visit the official boAt website.

10. Product Overview Video

Your browser does not support the video tag.

Video: An overview of the boAt Rockerz 260 earphones, detailing key features and benefits.

© 2023 boAt. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question