

[Manuals.plus](#) /

> [tectake](#) /

> tectake Bradford Nightstand Model 404698 Instruction Manual

## tectake 404698

# tectake Bradford Nightstand

Model: 404698

## 1. IMPORTANT SAFETY INFORMATION

---

Please read these instructions carefully before assembly and use. Retain this manual for future reference.

- **Keep fingers away from moving parts** during assembly and operation to prevent injury.
- **Ensure correct installation for stability.** Improper assembly can lead to instability and potential hazards.
- Do not exceed the maximum load capacities specified for each component.
- Place the nightstand on a flat, stable surface.
- Keep small parts and packaging materials away from children.

## 2. PACKAGE CONTENTS

---

Before starting assembly, verify that all components listed below are present and undamaged.

- Bradford Nightstand components
- Mounting Hardware (screws, connectors, etc.)
- Assembly Guide

## 3. PRODUCT OVERVIEW

---

The tectake Bradford Nightstand features a robust industrial design with clear structures and a timeless look. It combines particle board with a melamine coating in a dark industrial brown finish and a powder-coated steel frame.



Image 1: Assembled tectake Bradford Nightstand, showing the top shelf, drawer, and lower shelf.

### Key Features:

- Angular nightstand in a sturdy industrial style.
- Robust particle board with protective wood-look melamine coating.
- Sturdy powder-coated steel frame.
- One removable drawer and two open shelves for storage.
- Height-adjustable plastic feet for stability on uneven floors.
- Easy to clean surfaces.

## 4. SETUP AND ASSEMBLY

---

The tectake Bradford Nightstand is designed for quick and easy assembly. Please follow the included **Assembly Guide** step-by-step. All necessary mounting hardware is provided.

1. Unpack all components and verify against the package contents list.
2. Identify all parts and hardware.

3. Follow the detailed instructions in the separate Assembly Guide for step-by-step construction.
4. Ensure all screws and fasteners are securely tightened for stability.
5. Adjust the plastic feet as needed to level the nightstand on your floor.

**Recommended Tool:** Screwdriver (not included).

## 5. OPERATING AND USAGE

The Bradford Nightstand provides versatile storage options:

- **Top Surface:** Ideal for lamps, alarm clocks, books, or decorative items. Maximum load capacity: 40 kg.
- **Drawer:** Use the spacious drawer for personal items, remote controls, or other small essentials. Maximum load capacity: 10 kg.
- **Lower Shelf:** Perfect for additional books, magazines, or storage baskets. Maximum load capacity: 20 kg.

Always distribute weight evenly and avoid placing excessively heavy items on any single point.

## 6. MAINTENANCE AND CARE

To ensure the longevity and appearance of your nightstand, follow these care instructions:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Spills:** Clean up spills immediately to prevent staining or damage to the melamine coating.
- **Inspection:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Environment:** Avoid prolonged exposure to direct sunlight or extreme humidity, which can affect the material.

## 7. TROUBLESHOOTING

Most issues can be resolved by ensuring correct assembly and proper use.

- **Wobbling/Instability:** Check that all connections are tight. Adjust the height-adjustable plastic feet to level the nightstand on uneven floors.
- **Drawer not sliding smoothly:** Ensure the drawer runners are correctly installed and free of obstructions.
- **Missing parts:** Refer to the package contents list. If parts are missing, contact tectake customer support.

## 8. SPECIFICATIONS

Detailed dimensions and technical data for the tectake Bradford Nightstand.



Image 2: Technical drawing with detailed dimensions and load capacities.

|                                                 |                           |
|-------------------------------------------------|---------------------------|
| <b>Overall Dimensions (W x D x H)</b>           | Approx. 40 x 40 x 55.5 cm |
| <b>Top Shelf Dimensions (W x D)</b>             | Approx. 40 x 40 cm        |
| <b>Drawer Interior Dimensions (W x D x H)</b>   | Approx. 33 x 27.5 x 10 cm |
| <b>Distance between Drawer and Bottom Shelf</b> | Approx. 28.5 cm           |
| <b>Distance between Bottom Shelf and Floor</b>  | Approx. 9.5 cm            |
| <b>Particle Board Thickness</b>                 | Approx. 1.5 cm            |
| <b>Steel Frame Dimensions (W x D)</b>           | Approx. 2 x 2 cm          |

|                                   |                                                   |
|-----------------------------------|---------------------------------------------------|
| <b>Plastic Feet Adjustment</b>    | Approx. 1.5 cm                                    |
| <b>Top Shelf Load Capacity</b>    | 40 kg                                             |
| <b>Bottom Shelf Load Capacity</b> | 20 kg                                             |
| <b>Drawer Load Capacity</b>       | 10 kg                                             |
| <b>Weight</b>                     | Approx. 8.9 kg                                    |
| <b>Materials</b>                  | Particle board, powder-coated steel, polyethylene |
| <b>Color</b>                      | Dark Industrial Brown                             |
| <b>Model Number</b>               | 404698                                            |

## 9. WARRANTY AND SUPPORT

---

For warranty information or customer support, please refer to the official tectake website or contact your retailer. Keep your proof of purchase for any warranty claims.

Official tectake website: [www.tectake.eu](http://www.tectake.eu)