

TOZO T12

TOZO T12 Wireless Earbuds User Manual

Model: T12
Brand: TOZO

INTRODUCTION

Welcome to the user manual for your TOZO T12 Wireless Earbuds. These earbuds are designed to provide a premium audio experience with advanced features such as Bluetooth 5.3 technology, high-fidelity sound, a convenient wireless charging case with a digital LED display, and IPX8 waterproofing for durability. This manual will guide you through the setup, operation, maintenance, and troubleshooting of your new earbuds.

WHAT'S IN THE BOX

- TOZO T12 Wireless Earbuds
- Wireless Charging Case
- Eartips (various sizes)
- USB A to USB C Charging Cable
- User Manual

SETUP AND FIRST USE

Pairing Instructions

The TOZO T12 earbuds feature an advanced Bluetooth 5.3 technology, supporting HSP, HFP, A2DP, and AVRCP profiles. For initial pairing, simply pick up both headsets from the charging case. They will automatically pair with each other. After this, navigate to your mobile phone's Bluetooth settings and select 'TOZO-T12' to complete the pairing process. This provides in-call stereo sound and ensures fast, stable transmission without tangling.

One Step Pairing

Pick up 2 Earbuds from Charging Box
Connect Bluetooth <TOZO-T12>




Image: Illustration of the one-step pairing process for the TOZO T12 earbuds with a mobile phone.

OPERATING INSTRUCTIONS

Touch Controls

The TOZO T12 headphones are equipped with intuitive touch control sensors, designed to minimize pressure on your ears while performing various functions. The smart LED digital screen on the charging case allows you to monitor battery consumption at any time.

Compatible with Wireless Charging

Immerse yourself in the music world all day long and the charging case extends playtime up to 48 hours.



11 hrs
On a single
Charge



48 hrs
With Charging
Case



1.5 hrs
Fast Charging



TOZO W1 Ultrathin Wireless Charger

Image: Visual guide to the touch control functions on the TOZO T12 earbuds.

Control Functions:

Action	Function
Tap x1	Play/Pause, Answer/Hang up Call
Tap x2	Previous Song (Left Earbud), Next Song (Right Earbud)
Tap x3	Activate Siri (Voice Recognition)
Hold	Volume Down (Left Earbud), Volume Up (Right Earbud)

BATTERY AND CHARGING

The TOZO T12 earbuds offer impressive battery life, providing over 11 hours of playtime per charge and extending

up to 48 hours with the included charging case. The rechargeable case supports quick charging, reaching full capacity in under two hours using a wireless charger or approximately 1.5 hours with a fast USB A to USB C cable, ensuring convenient charging on the go.

High-Quality Stereo Sound

Eliminate Noise & Bass Boost, Aseparate Earpiece for Each EarEnjoy Crystal - Clear HiFi Stereo Sound

Bluetooth 5.0

10 mm

Large Size Speaker Driver
is **2.77** times than the
normal drive area

Image: The TOZO T12 charging case on a wireless charging pad, illustrating battery life and charging speed.

Portable Battery Case

Carrying Battery Case / Charging Box, Support 4 times fully charging for headsets



Image: Detailed view of the TOZO T12 earbuds and charging case, highlighting their respective battery capacities.

MAINTENANCE AND CARE

Waterproofing

Both the charging case and the earbuds are rated IPX8 waterproof, meaning they can withstand submersion in water up to 1 meter deep for 30 minutes, thanks to an internal nano-coating. This makes them ideal for use during sports or workouts, protecting them from sweat and rain. The earbuds and base can also be cleaned with water.

IP-X8 Waterproof rating

Resistant to sweat, water and rain



Image: The TOZO T12 earbuds and case being submerged in water, showcasing their IPX8 waterproof capability.

TROUBLESHOOTING

If you encounter any issues with your TOZO T12 Wireless Earbuds, please refer to the following common solutions:

- **No Sound/Connection Issues:** Ensure both earbuds are fully charged and within the Bluetooth range of your device (up to 10 meters). Try unpairing and re-pairing the earbuds with your device.
- **Charging Problems:** Verify that the charging cable is securely connected to both the case and a power source. Ensure the charging contacts on both the earbuds and inside the case are clean and free of debris.
- **Poor Sound Quality:** Check for any debris or earwax in the earbud nozzles that might be obstructing sound. Ensure the earbuds are properly seated in your ears for an optimal seal.
- **Earbuds Not Pairing Together:** Place both earbuds back into the charging case, close the lid for a few seconds, then open it again. This often resets their connection and allows them to pair with each other before connecting to your device.

PRODUCT SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Name	T12
Connectivity Technology	Wireless (Bluetooth 5.3)
Bluetooth Range	10 Meters
Ear Placement	In Ear
Noise Control	Sound Isolation
Water Resistance Level	IPX8 Waterproof
Battery Life (Earbuds)	12 Hours (per charge)
Battery Life (with Charging Case)	Up to 48 Hours
Charging Time	1.5 Hours (USB-C), <2 Hours (Wireless)
Control Type	Touch Control
Audio Driver Type	Dynamic Driver (10mm)
Frequency Range	14Hz - 20kHz
Impedance	32 Ohm
Material	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	5.9 ounces
Manufacturer	TOZO

WARRANTY AND SUPPORT

TOZO products come with a standard manufacturer's warranty. For detailed warranty information, including terms and conditions, please refer to the warranty card included in your product packaging or visit the official TOZO website.

Should you require technical assistance, troubleshooting guidance beyond this manual, or have any questions regarding your TOZO T12 Wireless Earbuds, please contact TOZO customer service. Support contact details can typically be found on the official TOZO website or within your product documentation.

For the latest FAQs, software updates, and additional support resources, please visit www.tozostore.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question