

Hot Wheels HTP55

Hot Wheels Epic Crash Dash Track Set

MODEL: HTP55

1. Product Overview

The Hot Wheels Action Epic Crash Dash Track Set is designed for thrilling racing and crashing action. It features five exciting crash zones, two loops, and a motorized booster that keeps cars in continuous motion. This set encourages creative play and provides hours of entertainment for Hot Wheels enthusiasts.

What's Included:

- 1 Hot Wheels Action Epic Crash Dash set
- 1 Hot Wheels car in 1:64 scale



An overview of the Hot Wheels Epic Crash Dash Track Set, showcasing its multiple loops, crash zones, and motorized booster.

2. Important Safety Information

Please read all safety information before assembly and use. Keep these instructions for future reference.

- This toy is not suitable for ages under 5 years.
- Adult supervision is recommended during play.
- Keep fingers and loose clothing away from moving parts, especially the motorized booster.
- Do not use damaged or modified cars on the track.

3. Setup

Assembly Instructions:

The Hot Wheels Epic Crash Dash track components are designed for easy assembly. Follow the visual guides provided in the packaging or refer to the online user manual for detailed step-by-step instructions. Ensure all track pieces click securely into place to prevent disconnections during play.

Battery Installation:

The motorized booster requires 4 'D' batteries (not included). To install batteries:

1. Locate the battery compartment on the base of the motorized booster.
2. Using a Phillips head screwdriver, unscrew the battery compartment cover.
3. Insert 4 'D' batteries, ensuring correct polarity (+/-) as indicated inside the compartment.
4. Replace the cover and secure it with the screw.

Always use new batteries for optimal performance. Do not mix old and new batteries, or different types of batteries.



A child interacting with the track set, demonstrating the scale and play experience.

4. Operating Instructions

Getting Started:

1. Ensure the track set is fully assembled and batteries are installed in the motorized booster.
2. Place a Hot Wheels car (1:64 scale) onto the starting gate or entry point of the track.
3. Activate the motorized booster using the power switch. The booster will begin to spin, ready to propel cars.
4. Release the car onto the track. The motorized booster will launch the car into the loops and crash zones, keeping it in continuous motion.


Crash Zones:

The Epic Crash Dash features five designated crash zones. The objective is to see how many cars can race simultaneously before an exciting collision occurs. Experiment with different Hot Wheels cars to observe varied crash dynamics.



MOTORIZED BOOSTER KEEPS CARS MOVING!

Detail of the motorized booster, which propels cars continuously around the track.



5 CRASH ZONES!

An illustration highlighting the five distinct crash zones designed for exciting collisions.

5. Maintenance

Care and Cleaning:

To keep your Hot Wheels track set in optimal condition:

- Wipe the track and components with a dry or slightly damp cloth. Do not immerse in water.
- Avoid exposing the set to extreme temperatures or direct sunlight for prolonged periods.
- Regularly check for any loose or damaged parts and discontinue use if found.

Battery Replacement:

When the motorized booster's performance diminishes (cars slow down or fail to complete loops), it's time to replace the batteries. Follow the battery installation steps in Section 3, ensuring to use fresh 'D' batteries.

6. Troubleshooting

Common Issues:

- **Cars not completing loops or slowing down:**
 - Check battery power. Replace all 'D' batteries with new ones.
 - Ensure the track is fully assembled and all connections are secure.
 - Verify that the Hot Wheels car used is a standard 1:64 scale and has appropriate weight for track performance. Some cars may perform better than others.
- **Motorized booster not working:**
 - Check battery installation for correct polarity.
 - Ensure batteries are new and fully charged.
 - Confirm the power switch is in the 'ON' position.
- **Track pieces disconnecting:**
 - Ensure all pieces are firmly clicked into place during assembly.
 - Avoid excessive force or bending of track pieces during play.

7. Storage

The Hot Wheels Epic Crash Dash Track Set is designed to collapse for easy and convenient storage. To collapse the set, gently fold the designated sections as indicated in the assembly instructions or product packaging. This compact design allows for simple transport and storage when not in use.



***COLLAPSES FOR EASY TRANSPORT
& STORAGE!***

The track set in its collapsed state, demonstrating its compact design for easy transport and storage.

8. Product Specifications

Feature	Detail
Product Dimensions	4 x 24 x 13 inches
Item Weight	4.24 pounds
Model Number	HTP55
Manufacturer Recommended Age	5 years and up
Batteries Required	4 D batteries (not included)
Manufacturer	Mattel
Release Date	June 24, 2023

9. Warranty and Support

Warranty Information:

This Hot Wheels product is covered by a manufacturer's warranty against defects in materials and workmanship. Please refer to the original product packaging or the official Hot Wheels website for specific warranty terms and conditions.

Customer Support:

For further assistance, questions, or to purchase additional Hot Wheels products, please visit the official [Hot Wheels Store](#) or contact Mattel customer service.

Documents - Hot Wheels – HTP55



[\[pdf\]](#) User Manual

23F HW HNL97 HTP55 21A G1 IS User Manual Amazon Hot Wheels Track Set Epic Crash Dash with 5 Zones Motorized Booster and 1 64 Scale Toy Car Easy Storage Toys Games B1duqEcxFIL m media amazon images | |||

7 MORE WAYS TO PLAY AUTRES MANIERES DE JOUER WEITERE SPIELMGLICHKEITEN ALTRI MODI PER GIOCARE ME ... P1RKOUKZYIYTONNTNY IOINHGSJAEETSBRZRUNBUKRILKUIASGUTASNIAAINNTWVMIISUJNZTIAINNTGG 1103056611-21A **HTP55**-MA70G1 1103056611-21A 1 INDEX INHALTSVERZEICHNIS INDICE INHOUDSOPGAVE NDICE INNEHLLSF...

lang:i-klngon score:30 filesize: 2.75 M page_count: 9 document date: 2023-03-22