

[Manuals.plus](#) /

› [Logitech G](#) /

› Logitech G PRO X 60 Lightspeed Wireless Gaming Keyboard User Manual

## Logitech G PRO X 60 Lightspeed

# Logitech G PRO X 60 Lightspeed Wireless Gaming Keyboard

MODEL: PRO X 60 LIGHTSPEED (920-011921)

## Introduction


This manual provides essential information for setting up, operating, and maintaining your Logitech G PRO X 60 Lightspeed Wireless Gaming Keyboard. Designed for competitive gaming, this ultra-compact 60% mechanical keyboard offers advanced features for optimal performance.

## What's in the Box

Your Logitech G PRO X 60 Lightspeed Wireless Gaming Keyboard package includes the following items:

- PRO X 60 Wireless Gaming Keyboard
- USB LIGHTSPEED wireless adapter
- USB-A to USB-C charging and data cable (6 ft./1.8 m)
- Logitech G keycap
- Carrying case
- User documentation

# WHAT'S IN THE BOX



*Image: All items included in the Logitech G PRO X 60 Lightspeed Wireless Gaming Keyboard package.*

*Video: An overview of the Logitech G PRO X 60 Wireless Keyboard, showcasing its features and design.*

## Setup

### 1. CONNECTING VIA USB LIGHTSPEED ADAPTER

1. Locate the USB LIGHTSPEED wireless adapter.
2. Plug the adapter into an available USB-A port on your PC.
3. Ensure the keyboard's power switch (located on the side) is in the ON position.
4. The keyboard should automatically connect.

### 2. CONNECTING VIA BLUETOOTH

1. Ensure the keyboard is powered on.

2. Press and hold the Bluetooth button on the keyboard until the indicator light flashes, indicating pairing mode.
3. On your PC, navigate to Bluetooth settings and select the Logitech G PRO X 60 from the list of available devices.
4. Follow any on-screen prompts to complete the pairing process.

### 3. CONNECTING VIA USB-C CABLE

1. Connect the USB-C end of the provided cable to the keyboard's USB-C port.
2. Connect the USB-A end of the cable to an available USB-A port on your PC.
3. The keyboard will function in wired mode and charge simultaneously.



*Image: Side view of the keyboard showing the LIGHTSPEED wireless indicator and power switch.*

## Operating Instructions

## GAME MODE CONTROL

The keyboard features a dedicated Game Mode control. Activating Game Mode can disable certain keys (e.g., Windows key) to prevent accidental presses during gameplay, ensuring an uninterrupted experience.

## MEDIA CONTROLS AND VOLUME ROLLER

Convenient media controls and a volume roller are integrated into the keyboard for easy audio management without interrupting your workflow or game.

## STANDARD KEYBOARD LAYOUTS

The PRO X 60 supports standard keyboard layouts with 3P compatibility, allowing for broad compatibility with various systems and software.




Image: Key features and controls of the Logitech G PRO X 60 keyboard.

## Customization

## KEYCONTROL TECHNOLOGY

Utilize KEYCONTROL technology via the Logitech G HUB software for pro-level customization of every key. Create up to 5 unique layers to transform your compact gaming keyboard into a versatile control center tailored to your needs.

## LIGHTSYNC RGB LIGHTING

Personalize your keyboard's aesthetics with customizable LIGHTSYNC RGB backlighting. Access a spectrum of 16.8 million colors and various lighting effects through the G HUB software to match your setup or mood.



*Image: KEYCONTROL feature for full key customization.*

# LIGHTSYNC RGB



**CUSTOMIZABLE  
WITH G HUB**

*Image: LIGHTSYNC RGB lighting with 16.8 million colors, customizable via G HUB.*

## Optical Switches

The PRO X 60 keyboard is equipped with GX optical switches, offering faster actuation and zero debounce delay. You can choose between tactile or linear switch options to suit your preferred typing and gaming style.

# PRO-INSPIRED 60% DESIGN



**MORE FLEXIBILITY  
AND FREEDOM**

*Image: GX Optical Tactile and GX Optical Linear switches.*

## Maintenance

### CLEANING

- To clean the keyboard, use a soft, lint-free cloth.
- For stubborn dirt, slightly dampen the cloth with water or a mild cleaning solution.
- Avoid using harsh chemicals or abrasive materials.
- You may carefully remove keycaps for deeper cleaning of the switches, if necessary.

### STORAGE AND TRANSPORT

When not in use or during transport, store the keyboard in its included carrying case to protect it from dust, spills, and physical damage.

# Troubleshooting

## CONNECTIVITY ISSUES

- **Wireless (LIGHTSPEED/Bluetooth):** Ensure the keyboard is charged and within range of your PC. Repair the device if connection is lost.
- **USB Receiver:** Confirm the USB LIGHTSPEED adapter is securely plugged into a functioning USB port.
- **Wired:** Check the USB-C cable connection at both the keyboard and the PC. Try a different USB port or cable if issues persist.

## LIGHTING NOT WORKING

- Verify that the keyboard's lighting is enabled via the dedicated lighting button or through the G HUB software.
- Ensure the keyboard has sufficient battery charge if operating wirelessly.

## KEYS NOT RESPONDING

- Restart your PC.
- Check for any physical obstructions under the keycaps.
- Ensure the keyboard firmware is up to date via G HUB.

For further assistance, refer to the Logitech G support website or the G HUB software for detailed diagnostics and solutions.

# Specifications

Feature	Detail
Brand	Logitech G
Series	G PRO X 60 LIGHTSPEED
Model Number	920-011921
Hardware Platform	PC
Operating System	Windows
Connectivity Technology	Wireless (LIGHTSPEED, Bluetooth), USB
Keyboard Description	Gaming, Mechanical, 60% TKL
Special Feature	Backlit (LIGHTSYNC RGB), KEYCONTROL, GX Optical Switches
Color	White
Item Weight	3.04 pounds

Product Dimensions	15.2 x 5.9 x 0.9 inches
Power Source	Battery Powered (1 Lithium Ion battery included)

## Warranty and Support

Logitech G products are designed for durability and performance. For detailed warranty information specific to your region and product, please refer to the user documentation included in your package or visit the official Logitech G support website.

For technical support, troubleshooting guides, and software downloads (including G HUB), please visit the Logitech G support portal online. Keep your product's model number (920-011921) handy for quicker assistance.