

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SOWO](#) /

› [SOWO Small Waterproof Bluetooth Portable Wireless Speaker Instruction Manual](#)

## SOWO Shower Speaker

# SOWO Small Waterproof Bluetooth Portable Wireless Speaker Instruction Manual

Model: Shower Speaker

## 1. INTRODUCTION

Thank you for purchasing the SOWO Small Waterproof Bluetooth Portable Wireless Speaker. This manual provides essential information for the safe and efficient operation of your device. Please read it thoroughly before use and retain it for future reference.

This speaker is designed for portability and durability, featuring a waterproof design, powerful bass, colorful LED lights, and a lightweight build, making it suitable for various indoor and outdoor environments.

## 2. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures (hot or cold).
- Keep the charging port rubber plug securely closed when using the speaker near water to maintain its waterproof rating.
- Do not attempt to disassemble or modify the speaker. This may void the warranty and cause damage.
- Use only the provided charging cable or a certified equivalent.
- Avoid dropping or subjecting the speaker to strong impacts.
- Clean the speaker with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.

## 3. PACKAGE CONTENTS

Verify that all items are present in the package:

- SOWO Small Waterproof Bluetooth Portable Wireless Speaker
- Charging Cable
- Buckle (Carabiner)
- User Manual (this document)

# ENJOY MUSIC OUTDOOR

Easy to carry anywhere



Image: The SOWO speaker, charging cable, and carabiner buckle as included in the package.

## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the speaker's components and controls.



Image: A pink SOWO speaker showing the power button, volume controls, and carabiner attachment point.

## Controls and Indicators:

- **Power Button:** Press and hold to turn on/off. Short press for play/pause.
- **Volume Up (+):** Short press to increase volume. Long press for next track.
- **Volume Down (-):** Short press to decrease volume. Long press for previous track.
- **Light Button:** Short press to cycle through light modes. Long press to turn off lights.
- **Charging Port:** USB-C port for charging. Ensure rubber plug is sealed when not charging.
- **LED Indicator:** Shows power status, charging status, and Bluetooth pairing status.

## 5. SETUP

### 5.1 Charging the Speaker

Before first use, fully charge the speaker. The battery capacity is 1500 mAh, and a full charge takes approximately 2.5 hours.

1. Open the rubber cover of the charging port.
2. Connect the provided USB charging cable to the speaker's charging port.
3. Connect the other end of the USB cable to a USB power adapter (5V) or a computer's USB port.
4. The LED indicator will show charging status (e.g., red while charging, off when fully charged).
5. Once fully charged, disconnect the charging cable and securely close the rubber cover to maintain waterproof integrity.

### 5.2 Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 2-3 seconds until you hear an audible prompt and the LED indicator lights up.
- **To Power Off:** Press and hold the Power button for approximately 2-3 seconds until you hear an audible prompt and

the LED indicator turns off.

## 6. OPERATING INSTRUCTIONS

### 6.1 Bluetooth Pairing

The speaker will automatically enter pairing mode when powered on for the first time or if no device is connected.

1. Ensure the speaker is powered on and the LED indicator is flashing, indicating it's in pairing mode.
2. Enable Bluetooth on your device (smartphone, tablet, computer).
3. Search for "SOWO" in the list of available Bluetooth devices.
4. Select "SOWO" to connect. Once connected, you will hear an audible confirmation, and the LED indicator will stop flashing and remain solid.
5. The speaker will automatically reconnect to the last paired device when powered on, if the device is within range.



Image: A smartphone screen displaying Bluetooth settings, showing the SOWO speaker as a discoverable device.

### 6.2 Playing Audio

- **Play/Pause:** Short press the Power button.
- **Volume Up:** Short press the '+' button.
- **Volume Down:** Short press the '-' button.
- **Next Track:** Long press the '+' button.
- **Previous Track:** Long press the '-' button.

### 6.3 LED Light Modes

The speaker features built-in LED lights with multiple modes.

- **Change Light Mode:** Short press the Light button to cycle through available light patterns.
- **Turn Off Lights:** Long press the Light button to turn off the LED lights.

### 6.4 Wireless Stereo Pairing (TWS Function)

You can pair two SOWO speakers together for a stereo sound experience.

1. Ensure both SOWO speakers are powered off.
2. Power on both speakers. They will enter Bluetooth pairing mode.
3. On one of the speakers (this will be the primary speaker), double-press the Power button. The speakers will attempt to connect to each other.
4. Once successfully paired, you will hear an audible confirmation. The LED indicator on the primary speaker will flash, and the secondary speaker's LED will be solid.

5. Now, connect your device to the primary speaker via Bluetooth as described in section 6.1.
6. To disconnect TWS, double-press the Power button on either speaker.



Image: Two SOWO speakers placed on a blanket, illustrating wireless stereo pairing for an enhanced audio experience.

## 7. MAINTENANCE

- Cleaning:** Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Storage:** Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures when not in use for extended periods.
- Waterproof Seal:** Always ensure the charging port's rubber plug is fully sealed when the speaker is exposed to water to maintain its IP67 waterproof rating.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair with Bluetooth device.	Bluetooth is off on your device; speaker is too far; speaker is already connected to another device.	Ensure Bluetooth is enabled on your device. Move speaker closer. Disconnect from other devices. Restart speaker and device.
No sound or low volume.	Volume too low on speaker or device; speaker not connected properly.	Increase volume on both speaker and device. Re-pair the Bluetooth connection.
Sound distortion.	Volume too high; low battery; interference.	Reduce volume. Charge speaker. Move away from other electronic devices.
LED lights not working.	Lights turned off; malfunction.	Short press the Light button to cycle modes. Long press to turn on if off. If issue persists, contact support.
Power button failed.	Internal component failure.	This indicates a potential defect. Contact SOWO customer support for assistance or warranty claim.

If the problem persists after trying these solutions, please contact SOWO customer support.

## 9. SPECIFICATIONS

Feature	Detail
Model Name	SOWO Shower Speaker
Connectivity Technology	Bluetooth
Wireless Communication Technology	Bluetooth
Bluetooth Range	40 Feet
Speaker Type	Portable
Speaker Maximum Output Power	12 Watts
Audio Output Mode	Mono (Stereo with TWS pairing)
Frequency Response	20 KHz
Signal-to-Noise Ratio	72 dB
Impedance	3 Ohm
Battery Capacity	1500 mAh Lithium Polymer
Charging Time	2.5 Hours
Item Weight	6.4 Ounces
Product Dimensions	1"D x 4"W x 5"H
Water Resistance Level	IP67 Waterproof
Control Method	Touch (Buttons)
Material	Plastic and PCB
Included Components	Charging cable, buckle

## 10. WARRANTY AND SUPPORT

---

SOWO products come with a limited warranty. For specific warranty details and duration, please refer to the warranty card included with your product or visit the official SOWO website.

For technical support, troubleshooting assistance, or warranty claims, please contact SOWO customer service through the following channels:

- **Email:** [Insert SOWO Support Email Here, if available]
- **Website:** [SOWO Official Store on Amazon](#)
- **Phone:** [Insert SOWO Support Phone Number Here, if available]

Please have your product model number (Shower Speaker) and purchase date ready when contacting support.

## Related Documents - Shower Speaker

	<p><a href="#"><b>SOWO Soundwave Mage Portable Speaker User Manual</b></a></p> <p>User manual for the SOWO Soundwave Mage wireless portable speaker, detailing its features, setup, operation, and specifications. This IP67 waterproof Bluetooth speaker offers 24-hour playtime and pro sound for various outdoor and indoor activities.</p>
	<p><a href="#"><b>SOWO Surgeboom 2 User Guide and Specifications</b></a></p> <p>Comprehensive guide for the SOWO Surgeboom 2 portable Bluetooth speaker, covering setup, operation, features like TWS pairing and LED light themes, technical specifications, and troubleshooting.</p>
	<p><a href="#"><b>SOWO Surgeboom 2 Quick Start Guide: IPX7 Waterproof Bluetooth Speaker</b></a></p> <p>This guide provides essential information for the SOWO Surgeboom 2 portable Bluetooth speaker, covering setup, features like IPX7 waterproofing and TWS connectivity, specifications, and safety guidelines.</p>
	<p><a href="#"><b>SOWO Surgeboom 2 Portable Bluetooth Speaker User Manual</b></a></p> <p>User guide for the SOWO Surgeboom 2 portable Bluetooth speaker, covering setup, operation, features like TWS pairing, and troubleshooting.</p>
	<p><a href="#"><b>SOWO Surgeboom 2 Portable Bluetooth Speaker User Guide &amp; Specifications</b></a></p> <p>Learn how to use your SOWO Surgeboom 2 portable Bluetooth speaker. This guide covers setup, operation, TWS pairing, troubleshooting, and technical specifications.</p>
	<p><a href="#"><b>SOWO Surgeboom 3 Portable Bluetooth Speaker Quick Start Guide</b></a></p> <p>A quick start guide for the SOWO Surgeboom 3 portable Bluetooth speaker, covering setup, features like TWS connection, IPX7 waterproofing, LED disco lights, and technical specifications.</p>



[\[pdf\] Guide](#)

5 Bluetooth Shower Speaker Waterproof Small Portable Wireless with Louder Volume and Powerful Bass Colorful Lights 10H Playtime Lightweight Carabiner TWS Black User Guide SOWO B0C1J8SCCR B0BRSV29H6 B0BRSTSPQ4 B0C1JK57CQ B159gAQvXvL m media amazon images I |||

...

lang: score:20 filesize: 2.1 M page\_count: 19 document date: 2023-04-13