

[Manuals.plus](#) /

› [VASAGLE](#) /

› VASAGLE LWD041B56 Computer Desk Instruction Manual

VASAGLE LWD041B56

VASAGLE LWD041B56 Computer Desk Instruction Manual

Model: LWD041B56

INTRODUCTION

Thank you for choosing the VASAGLE LWD041B56 Computer Desk. This manual provides essential information for the safe and correct assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: The VASAGLE LWD041B56 Computer Desk, fully assembled and ready for use.

SETUP AND ASSEMBLY

Before you begin, ensure all components are present and undamaged. It is recommended to assemble the desk on a soft, clean surface to prevent scratches.

Included Components:

- Tabletop (Particleboard)
- Legs (Steel)
- Reinforcement Bars (Steel)
- Adjustable Feet
- Assembly Hardware (Screws, Allen Key)

Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all parts and compare them with the component list in your separate assembly guide (PDF).
2. **Attach Legs to Tabletop:** Place the tabletop upside down on a soft surface. Align the steel legs with the pre-drilled holes on the underside of the tabletop. Secure them using the provided screws and an Allen key.
3. **Install Reinforcement Bars:** Attach the steel reinforcement bars to the corners of the desk frame. These bars enhance stability. Ensure all screws are tightened securely.



Image: Detail of the steel frame with reinforcement bars for enhanced stability.

4. **Attach Adjustable Feet:** Screw the adjustable feet into the bottom of each leg.



Image: An adjustable foot being installed, allowing for leveling on uneven surfaces.

- 5. Final Tightening and Placement:** Once all parts are assembled, gently turn the desk upright. Ensure all screws are fully tightened. Adjust the feet to level the desk and prevent wobbling.

For detailed visual instructions, please refer to the separate PDF assembly guide provided with your product.

OPERATING INSTRUCTIONS

The VASAGLE LWD041B56 Computer Desk is designed for use as a workstation for computers, writing, or other office tasks. Its robust construction supports a maximum load of 50 kg.

Key Features:

- **Versatile Workspace:** The 100 x 50 cm tabletop provides ample space for your computer, accessories, and work materials.
- **Adjustable Feet:** Use the adjustable feet to ensure the desk remains stable and level, even on slightly uneven floors. This also helps protect your flooring from scratches.
- **Sturdy Construction:** The combination of a thick particleboard tabletop and a high-quality steel frame ensures durability and stability.



Image: The desk in a typical usage scenario, set up with a computer and chair.

MAINTENANCE

To ensure the longevity and appearance of your VASAGLE computer desk, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the desk surface and frame with a soft, dry cloth. For stubborn marks, a slightly damp cloth can be used, followed immediately by a dry cloth to prevent moisture damage.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, strong detergents, or solvents, as these can damage the finish.
- **Protect from Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters for drinks to prevent water rings.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

TROUBLESHOOTING

Most common issues with the VASAGLE LWD041B56 Computer Desk can be resolved with simple adjustments.

Common Issues and Solutions:

- **Desk is Wobbly:**
 - Ensure all assembly screws are fully tightened.
 - Adjust the leveling feet on the bottom of each leg. Turn them clockwise or counter-clockwise until the desk is stable on

your floor.

• **Scratches on Floor:**

- The adjustable feet are designed to protect floors. Ensure they are properly installed and adjusted. Avoid dragging the desk across the floor.

• **Missing Parts or Damaged Components:**

- If you find any parts missing or damaged upon opening the package, please contact customer support immediately for assistance.

SPECIFICATIONS

Attribute	Detail
Model Number	LWD041B56
Brand	VASAGLE
Product Dimensions (W x D x H)	100 x 50 x 76 cm (39.4 x 19.7 x 29.9 inches)
Item Weight	10 kg (22 lbs)
Recommended Maximum Load	50 kg (110 lbs)
Material Type	Particleboard, Steel
Color	Ebony Black + Ink Black
Assembly Required	Yes
Special Feature	Adjustable Feet
UPC / GTIN	194343042886



Image: Technical diagram illustrating the desk's dimensions and weight capacity.

WARRANTY AND SUPPORT

The VASAGLE LWD041B56 Computer Desk comes with a limited warranty. For specific details regarding warranty coverage, duration, and terms, please refer to the warranty information included in your product packaging or contact VASAGLE customer support.

Customer Support:

If you have any questions, require assistance with assembly, or encounter any issues with your product, please contact VASAGLE customer support through the retailer where you purchased the item or visit the official VASAGLE website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

What are the length, width, and height of the metal frame for the VASAGLE LWD039B56 Computer Desk?

Based on the specifications for this series of VASAGLE computer desks, the overall external dimensions for the LWD039B56 model are 120 cm in length, 60 cm in width, and 76 cm in height.While the...

[Read full answer](#)