

[Manuals.plus](#) /

> [SIBRILLE](#) /

> SIBRILLE 36W LED Tree Floor Lamp Instruction Manual

SIBRILLE FLH-036-F1

SIBRILLE 36W LED Tree Floor Lamp Instruction Manual

Model: FLH-036-F1

PRODUCT OVERVIEW

This SIBRILLE 36W LED Tree Floor Lamp features a unique 3-light design, offering versatile illumination with 350° rotation and 180° vertical adjustment for each light. It provides 2500 lumens of bright, dimmable light with 4 adjustable color temperatures (2700K-6500K). Control is convenient via both remote and touch, with individual light control and smart plug compatibility. Designed for eye protection, it ensures stable, flicker-free lighting. Its sturdy metal base provides stability, making it safe for homes with children and pets.

WHAT'S IN THE BOX

- Floor Lamp
- Remote Control
- User Manual



Image: The SIBRILLE 36W LED Tree Floor Lamp with its remote control, showcasing its three rotatable light heads and touch control area on the pole.

SETUP AND ASSEMBLY

This tall lamp is very easy to put together. Follow the steps below to assemble it from the top of the lamp to the base. Assembly can be completed in approximately 5 minutes.

1. Unpack all components: lamp heads, pole sections, and the heavy base.
2. Connect the pole sections by twisting them clockwise until secure. Ensure the electrical wires pass through freely.
3. Attach the lamp head section to the top pole.
4. Secure the assembled pole to the sturdy base.
5. Plug the power adapter into a wall outlet.

OPERATING INSTRUCTIONS

Power On/Off and Brightness Control

The lamp can be controlled using both the included remote control and the touch-sensitive buttons on the lamp pole.

Remote Control

- **Power Button:** Press to turn the lamp on or off.
- **Brightness Adjustment:** Use the "BRT+" and "BRT-" buttons to dim the light from 10% to 100% brightness.
- **Color Temperature Adjustment:** Use the "Warm" and "White" arrows to cycle through 4 color temperatures: 2700K (warm), 4000K (warm white), 5000K (cool white), and 6500K (daylight white).
- **Individual Light Control:** Buttons labeled "1", "2", and "3" allow you to turn each of the three light heads on or off independently.
- **Night Light Mode:** Press the moon icon for a soft, low-light setting suitable for sleeping.
- **Reading Mode:** Press the book icon for a brighter, focused light suitable for reading.
- **1-Hour Timer:** Press the "1H" button to set a timer for the lamp to automatically turn off after one hour.

Touch Control (on lamp pole)

- **Short Press:** Cycle through 2700K, 4000K, 5000K, 6500K, and Off.
- **Long Press:** Continuously adjust brightness.

Adjustable Light Heads

Each of the three light heads can be rotated 350° horizontally and adjusted 180° vertically. This allows you to direct light precisely where needed, whether for ambient room lighting, task lighting for reading, or highlighting specific areas.



Image: Close-up view of the rotatable and vertically adjustable light heads on the SIBRILLE floor lamp, demonstrating their flexibility.

MAINTENANCE

To ensure the longevity and optimal performance of your SIBRILLE LED Tree Floor Lamp, follow these simple maintenance guidelines:

- **Cleaning:** Disconnect the lamp from the power source before cleaning. Use a soft, dry cloth to wipe down the lamp pole and light heads. Avoid abrasive cleaners or solvents, as they may damage the finish.
- **Bulb Replacement:** The lamp features an integrated LED design, meaning there is no need to install or replace extra bulbs. The LEDs are designed for durability and long-lasting performance.
- **Stability Check:** Periodically check that all pole sections are securely tightened and the base remains stable.




Image: The sturdy metal base of the SIBRILLE floor lamp, highlighting its stability and compact design.

TROUBLESHOOTING

If you encounter any issues with your SIBRILLE LED Tree Floor Lamp, please refer to the following common troubleshooting tips:

Lamp Not Turning On

- Ensure the power cord is securely plugged into a working electrical outlet.
- Check if the wall switch (if connected to one) is in the ON position.
- Verify that the remote control batteries are not depleted.
- If the remote control fails to work, try re-pairing it: Turn on the power switch, unplug the power cord three times in a row and reconnect it. The floor lamp lights will flash quickly. Then, long press the "M" button on the remote control until the lights flash quickly again, indicating successful pairing.

Lights Flickering or Dimming Unexpectedly

- Ensure the lamp is connected to a stable power source.
- Avoid using the lamp with incompatible dimmer switches or smart plugs not designed for LED lighting.

Remote Control Not Responding

- Replace the AAA batteries in the remote control.
- Ensure there are no obstructions between the remote control and the lamp's sensor.
- Re-pair the remote control as described above.

SPECIFICATIONS

Feature	Detail
Model Number	FLH-036-F1
Power Source	Corded Electric

Wattage	36 Watts (12W per light)
Brightness	2500 Lumens
Color Temperatures	2700K (Warm), 4000K (Warm White), 5000K (Cool White), 6500K (Daylight White)
Control Method	Remote Control, Touch Control
Light Head Adjustment	350° Rotation, 180° Vertical
Base Material	Metal
Item Weight	9.2 Pounds
Product Dimensions	9.89"D x 17.71"W x 67.71"H
Average Life	50000 Hours

WARRANTY AND SUPPORT

SIBRILLE offers a full 2-year warranty and a 30-day refund for quality-related issues.

If you have any problems or suggestions, please contact SIBRILLE customer service via the Amazon message box. They are committed to resolving issues promptly and ensuring customer satisfaction.

For additional support and product information, visit the official SIBRILLE Store: [SIBRILLE Store on Amazon](#).