Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Nokia G400 5G

Nokia G400 5G Smartphone User Manual

Model: G400 5G (TA-1448)

Introduction

This manual provides essential information for the safe and efficient use of your Nokia G400 5G smartphone. Please read through these instructions carefully to ensure optimal performance and longevity of your device. The Nokia G400 5G is a versatile smartphone designed for modern communication and entertainment needs.

What's in the Box

Upon unboxing your Nokia G400 5G, verify that all the following components are included:

- Nokia G400 5G Smartphone (Meteor Grey)
- USB Type-C Cable
- Power Adapter
- SIM Tray Ejector Tool



Image: Contents of the Nokia G400 5G retail box, including the phone, charging accessories, and SIM tool.

Physical Overview

Familiarize yourself with the key physical features of your Nokia G400 5G:

- **Front:** 6.58-inch immersive Full HD+ display with a teardrop notch for the front camera.
- **Right Side:** Volume up/down buttons and a power button, which may also integrate a fingerprint sensor.
- **Bottom:** USB Type-C charging port, 3.5mm audio jack, and speaker grille.
- **Back:** Triple-rear camera system with a 48MP main sensor and LED flash. The Nokia logo is prominently displayed.



Image: Front view of the Nokia G400 5G.



Image: Front and back view of the Nokia G400 5G.

Setup

1. **Insert SIM Card:** Use the provided SIM tray ejector tool to open the SIM card slot on the side of the phone. Insert your Nano-SIM card(s) and/or a microSD card (for expandable memory up to 1TB) into the tray, then carefully reinsert the tray into the phone.
2. **Power On:** Press and hold the power button on the right side of the phone until the Nokia logo appears.

3. **Initial Setup:** Follow the on-screen prompts to select your language, connect to Wi-Fi, sign in to your Google account, and set up security features like fingerprint unlock.
4. **Charge Battery:** Connect the USB Type-C cable to the phone's charging port and the power adapter. Plug the adapter into a wall outlet. Ensure the phone is fully charged before extensive use.

Operating Your Device

General Usage

The Nokia G400 5G runs on **Android 12**, offering a highly intuitive and responsive user experience. Navigate through apps and menus with smooth gestures and taps.



Image: The Nokia G400 5G displaying its Android 12 interface.

Camera Features

Capture high-quality photos and videos with the Nokia G400 5G's advanced camera system. It features a **48 MP triple-**

rear camera with A.I. enhancements, allowing for detailed and vibrant shots. The**16 MP front-facing camera** is ideal for selfies and video calls, and includes a Super Night mode for improved low-light performance.



Image: Detail of the Nokia G400 5G's 48 MP triple-rear camera.

Battery Life

The Nokia G400 5G is equipped with a**5000 mAh battery**, designed for long-lasting performance. With typical usage, you can expect up to 2 days of battery life on a single charge. The device also supports fast charging.



Image: The Nokia G400 5G displaying its battery status and settings.

Connectivity

Experience fast and reliable connections with **5G connectivity** powered by the Qualcomm® Snapdragon™ 480+ 5G Mobile Platform. The phone also supports Bluetooth, NFC (Near Field Communication) for contactless payments, USB, and Wi-Fi for comprehensive connectivity options.



Image: Key features of the Nokia G400 5G, including 5G connectivity.

Carrier Compatibility

The Nokia G400 5G is designed for **Universal Carrier Compatibility**. While it is unlocked for all carriers, some users have reported better compatibility with T-Mobile and Mint Mobile networks. It is advisable to confirm compatibility with your specific carrier prior to purchase or activation.



Image: The Nokia G400 5G demonstrating universal carrier compatibility.

Maintenance

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the phone. Avoid abrasive materials or harsh chemicals.
- **Software Updates:** Regularly check for and install software updates to ensure your device has the latest features, security patches, and performance improvements.
- **Storage Management:** Periodically review and manage your phone's storage. Delete unnecessary files, apps, and clear cache to maintain optimal performance.
- **Battery Care:** To prolong battery life, avoid extreme temperatures. While the phone supports fast charging, occasional slower charging can be beneficial.

Troubleshooting

Common Issues and Solutions

Issue	Possible Solution
Phone not turning on	Ensure the battery is charged. Press and hold the power button for at least 10-15 seconds to perform a forced restart.
Apps crashing or freezing	Clear the app's cache (Settings > Apps > [App Name] > Storage > Clear cache). If the issue persists, reinstall the app or perform a factory reset (backup data first).
Poor network signal	Check your SIM card insertion. Restart the phone. Verify with your carrier if there are network issues in your area.
Battery draining quickly	Reduce screen brightness, disable unnecessary background apps, turn off Wi-Fi/Bluetooth/GPS when not in use. Check battery usage in settings to identify power-hungry apps.

SPECIFICATIONS

Feature	Detail
Model Name	G400 5G
Item Model Number	G400 5G
ASIN	B0BS1QM974
Product Dimensions	6.55 x 3.02 x 0.35 inches
Item Weight	7 ounces
Operating System	Android 12.0
RAM	4 GB
Internal Storage	64 GB
Expandable Memory	Up to 1 TB (via microSD, not included)
Screen Size	6.58 Inches
Display Resolution	1920 x 1080 (FHD+)
Rear Camera	48 MP Triple-rear camera
Front Camera	16 MP
Battery Capacity	5000 mAh
Phone Talk Time	24 Hours
Charging Time	3 Hours
Connectivity	5G, Bluetooth, NFC, USB, Wi-Fi
Audio Jack	3.5 mm

Feature	Detail
Color	Meteor Grey
Manufacturer	HMD Global Oy

Warranty and Support

For information regarding warranty coverage, technical support, and service, please refer to the official Nokia website or contact their customer service. As this product is listed as "Amazon Renewed," specific warranty details may vary and should be confirmed with the seller, "Techrific Deals," or Amazon Renewed's policy. Protection plans are available for purchase separately.
For further assistance, you may visit the Nokia Support Page.

© 2024 Nokia. All rights reserved. Information subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BS1QM974

More documents and user manuals: **https://manuals.plus/**