

BRUNO BOE104-BGY

BRUNO Compact Coffee Maker with Integrated Mill BOE104-BGY Instruction Manual

Model: BOE104-BGY

1. IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Do not immerse the appliance, cord, or plug in water or other liquids.
- Ensure the voltage indicated on the appliance matches your local power supply before connecting.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may result in fire, electric shock, or injury to persons.
- Do not use outdoors.
- Do not let the cord hang over the edge of a table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach the plug to the appliance first, then plug the cord into the wall outlet. To disconnect, turn any control to 'off', then remove the plug from the wall outlet.
- Do not use the appliance for other than intended use.
- Scalding may occur if the lid is removed during the brewing cycle.
- This appliance is for household use only.

2. PRODUCT OVERVIEW

The BRUNO Compact Coffee Maker with Integrated Mill is designed for convenient brewing of fresh coffee from whole beans or pre-ground coffee. It features an automatic grinding function and a reusable mesh filter.



Image: The BRUNO Compact Coffee Maker BOE104-BGY in blue gray, showing its compact design and glass carafe.

Components:

- Main Unit
- Water Tank (removable)
- Dripper Cover
- Dripper
- Mesh Filter (reusable)

- Glass Carafe
- Measuring Spoon



Image: Close-up of the transparent water tank with clear measurement markings for 2 to 5 cups.



Image: The control panel featuring the power button and grind setting buttons.

3. SETUP

Before first use, wash all removable parts (water tank, dripper cover, dripper, mesh filter, glass carafe) with warm, soapy water, then rinse thoroughly and dry.

1. **Place the Appliance:** Position the coffee maker on a stable, flat, heat-resistant surface, away from water sources.
2. **Install Water Tank:** Ensure the removable water tank is securely placed on the main unit.
3. **Insert Dripper and Filter:** Place the dripper into its designated slot, then insert the mesh filter into the dripper. Ensure both are properly seated.
4. **Place Glass Carafe:** Position the glass carafe on the warming plate beneath the dripper.



Image: Hands demonstrating the removal and installation of the water tank.

4. OPERATING INSTRUCTIONS

Follow these steps to brew coffee using your BRUNO Compact Coffee Maker.

Brewing Coffee from Whole Beans:

1. **Add Coffee Beans:** Open the dripper cover and add the desired amount of whole coffee beans into the mesh filter. Use the included measuring spoon for accurate portions (e.g., 1 scoop per cup).
2. **Add Water:** Fill the removable water tank with fresh, cold water up to the desired level indicated by the cup markings.
3. **Close Dripper Cover:** Ensure the dripper cover is securely closed and locked into place.
4. **Select Grind Setting:** Press the grind setting button (usually indicated by a coffee bean icon) to select

the desired grind time/fineness. Refer to the manual for specific settings based on bean quantity.

5. **Start Brewing:** Press the power button () to start the grinding and brewing process. The machine will automatically grind the beans, then brew the coffee.
6. **Serve:** Once brewing is complete, the machine will automatically switch to keep-warm mode. Carefully remove the carafe and pour your fresh coffee.

POINT 2

3ステップの簡単な使い方

1

コーヒー豆（粉）を入れる。



2

本体に水を入れる。



3


スイッチを押して、
ドリップするのを待つだけ！



Image: A visual guide showing the three main steps: adding coffee beans, filling the water tank, and pressing the start button.

POINT 1

シャワーのようにまんべんなく降り注ぐ
蒸らしながら抽出



※画像はイメージです。

ドリップ時、シャワーのようにお湯がまんべんなく降り注ぎ、蒸らしながら抽出することで豆本来の旨味を引き出します。

Image: Close-up of coffee being brewed, with hot water evenly distributed over the coffee grounds, extracting flavor.

Brewing Coffee from Pre-Ground Coffee:

1. **Add Ground Coffee:** Open the dripper cover and add the desired amount of pre-ground coffee directly into the mesh filter.
2. **Add Water:** Fill the removable water tank with fresh, cold water up to the desired level.
3. **Close Dripper Cover:** Ensure the dripper cover is securely closed and locked.
4. **Start Brewing:** Press the power button () to start the brewing process. The machine will bypass the grinding cycle and proceed directly to brewing.
5. **Serve:** Once brewing is complete, the machine will automatically switch to keep-warm mode. Carefully remove the carafe and pour your fresh coffee.

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your coffee maker. Always unplug the appliance before cleaning.

Daily Cleaning:

- **Discard Grounds:** After the carafe has cooled, remove the dripper cover, dripper, and mesh filter. Discard used coffee grounds.
- **Wash Removable Parts:** Wash the dripper cover, dripper, mesh filter, water tank, and glass carafe with warm, soapy water. Rinse thoroughly and dry completely before reassembling.
- **Wipe Exterior:** Wipe the exterior of the main unit with a soft, damp cloth. Do not use abrasive cleaners or scourers.

分解洗浄可能 取り外してお手入れラクラク



使用頻度の高いものだから、洗いやすさは重要！
ドリッパーカバー、ドリッパー、メッシュフィルター、
水タンク、ガラスサーバーは外して丸洗いが可能です。

Image: Demonstrates how to easily remove the water tank and dripper assembly for thorough cleaning.

POINT 5

メッシュフィルター採用でエコ&経済的 紙フィルター不要



メッシュフィルターを採用し、コーヒーを淹れる度に紙のフィルターを用意する必要がなく、エコで経済的です。

Image: Close-up of the reusable mesh filter, highlighting its design that eliminates the need for paper filters.

Descaling (Monthly or as needed):

To remove mineral deposits, descale your coffee maker regularly. Use a commercial descaling solution or a mixture of white vinegar and water (1:2 ratio).

1. Fill the water tank with the descaling solution or vinegar mixture.
2. Place the empty carafe on the warming plate.
3. Run a brewing cycle without coffee grounds.
4. After the cycle, let the solution sit in the carafe for 15-30 minutes.
5. Discard the solution and rinse the carafe and water tank thoroughly.
6. Run 2-3 cycles with fresh water only to flush out any remaining descaling solution.

6. TROUBLESHOOTING

If you encounter issues with your coffee maker, refer to the following common problems and solutions:

- **Problem: Dripper cover does not close.**

Solution: Ensure the dripper and mesh filter are correctly set. Push the dripper all the way in, and align

the mesh filter with the concave position of the dripper.

- **Problem: Dripper cover opens during use, and the indicator light blinks and stops.**

Solution: Ensure the dripper cover is correctly set to the locked position. Push the dripper cover until it locks securely, ensuring the entire button on the left side is protruding outwards.

- **Problem: When pulling out the dripper, parts become loose and cannot be reassembled.**

Solution: The dripper valve may come off when pulling out the dripper. Please contact customer support for assistance.

- **Problem: Some coffee beans remain unground.**

Solution: Are the bean quantity and grinding time appropriate? Adjust the grinding time according to the bean quantity. Due to the propeller-type mill used in this product, some coffee beans may remain unground inside the dripper. This is a characteristic of the mill type.

- **Problem: After washing, the dripper cover's locking tab is stuck inwards, preventing the cover from closing.**

Solution: The locking mechanism for the dripper cover is designed to move only on one side. Ensure it is not jammed and try to gently reset it.

- **Problem: Coffee overflows from the dripper and leaks onto the table.**

Solution: The dripper may not be set correctly (not pushed into the correct position), or the valve part may be clogged with coffee grounds. Check the dripper's position and clean the valve if necessary.

7. SPECIFICATIONS

Brand:	BRUNO
Model Number:	BOE104-BGY
Color:	Blue Gray
Product Dimensions:	W175 × H270 × D285 mm (6.9 x 10.6 x 11.2 inches)
Product Weight:	2.1 kg (4.6 lbs)
Rated Power Consumption:	550W
Power Supply:	AC100V
Auto-off Function:	40 minutes
Temperature Fuse:	240°C
Included Components:	Measuring Spoon
Country of Origin:	China









Image: Diagram showing the dimensions of the BRUNO Compact Coffee Maker: 17.5cm width, 27cm height, 28.5cm depth.

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official BRUNO website. Keep your purchase receipt as proof of purchase for warranty claims.

If you experience any issues not covered in the troubleshooting section, please contact BRUNO customer service for further assistance.

Related Documents - BOE104-BGY

	<p>BRUNO POKÉMON HOT SAND MAKER DOUBLE BOE132 User Manual</p> <p>Official user manual for the BRUNO POKÉMON HOT SAND MAKER DOUBLE (Model BOE132). Learn about safety precautions, parts, how to use, cleaning, troubleshooting, and specifications.</p>
	<p>Bruno Crafting / Pyro & Mini Wood Stove User Manual and Technical Data</p> <p>Comprehensive user manual and technical specifications for Bruno Crafting, Pyro, and Mini series wood-burning stoves. Includes installation, operation, maintenance, safety guidelines, and detailed technical data.</p>
	<p>BRUNO BRN-0253 Waffle Maker User Manual</p> <p>Comprehensive user manual for the BRUNO BRN-0253 Waffle Maker, covering safety instructions, operation, cleaning, maintenance, and specifications. Learn how to make perfect waffles safely and efficiently.</p>
	<p>BRUNO BRN-0085 Popcorn Maker User Manual</p> <p>Comprehensive user manual for the BRUNO BRN-0085 popcorn maker, detailing safety instructions, operation, cleaning, maintenance, and technical specifications.</p>
	<p>Bruno Sofa Bed & Chaise Longue Assembly Instructions</p> <p>Detailed assembly instructions for the Bruno Sofa Bed and Chaise Longue, including safety warnings, tools, parts lists, and step-by-step guides for assembly and attachment.</p>
	<p>BRUNO BRN-0252 Crepe Maker User Manual Instructions & Safety Guide</p> <p>Detailed user manual for the BRUNO BRN-0252 Crepe Maker. Learn how to safely operate, clean, and maintain your crepe maker for perfect results every time. Includes specifications and disposal information.</p>

