

NutriBullet Pro 900

NutriBullet Pro 900 Watt Hi-Speed Blender/Mixer Instruction Manual

Model: Pro 900

INTRODUCTION

The NutriBullet Pro 900 is a powerful personal blender designed for efficient nutrition extraction. Its 900-watt motor and specialized extractor blades process ingredients into smooth beverages quickly. This manual provides essential information for the safe and effective use of your NutriBullet Pro 900.

SAFETY INFORMATION

Please read all instructions carefully before operating your NutriBullet Pro 900. Failure to follow these guidelines may result in injury or damage to the appliance.

- Always ensure the unit is unplugged when not in use, before assembly or disassembly, and before cleaning.
- Keep hands and utensils away from the moving blade during operation.
- Ensure the Extractor Blade is securely twisted onto the cup before placing it on the motor base.
- Do not overfill the cup beyond the MAX line indicated.
- Never blend hot liquids in the NutriBullet cups, as pressure buildup can cause hot contents to eject and cause injury.
- Keep the appliance out of reach of children.
- Do not operate the blender with damaged cords or plugs.

PACKAGE CONTENTS

Your NutriBullet Pro 900 Watt Hi-Speed Blender/Mixer 9-Piece Set includes the following components:

- 900W Motor Base
- Extractor Blade
- To-Go Lid
- Cup (various sizes may be included in the 9-piece set)
- Lip Ring
- Recipe Book



This image displays the NutriBullet Pro 900 Watt Hi-Speed Blender/Mixer in a matte cinnamon (dark red) color. The main blending cup is shown attached to the motor base, filled with various ingredients including kale, pineapple, oranges, berries, almonds, and ice, ready for blending. To the left, a separate cup containing a green smoothie is visible, along with a grey lip ring. To the right, a grey to-go lid is shown. This illustrates the primary components of the 9-piece set.

SETUP

1. Place the 900W Motor Base on a clean, dry, and level surface.
2. Fill the cup with your desired ingredients. For optimal blending, add liquids first, followed by soft ingredients, then harder ingredients, and finally ice or frozen items. Do not exceed the MAX fill line.
3. Twist the Extractor Blade onto the open end of the cup until it is securely tightened. Ensure there are no gaps.
4. Invert the cup assembly and place it onto the Motor Base, aligning the three tabs on the cup with the slots on the base.

OPERATING INSTRUCTIONS

The NutriBullet Pro 900 features a simple, intuitive design for quick blending.

- **Continuous Blending:** Once the cup and blade assembly are correctly placed on the motor base, press down firmly on the cup and twist clockwise until the tabs lock into place. The motor will engage, and blending will begin.
- **Pulsing:** For shorter bursts of blending, press down on the cup without twisting. Release pressure to stop. Repeat as needed for desired consistency.
- **Stopping:** To stop continuous blending, twist the cup counter-clockwise and lift it off the motor base. The motor will disengage.
- **Blending Time:** For best results and to prevent overheating, blend for no more than 60 seconds at a time. If ingredients are too thick, add more liquid to achieve the desired consistency.

MAINTENANCE AND CLEANING

Proper cleaning and maintenance will ensure the longevity and performance of your NutriBullet Pro 900.

- **Motor Base:** Always unplug the motor base before cleaning. Wipe the motor base with a damp cloth. *Never immerse the motor base in water or any other liquid.*
- **Cups and Lids:** After each use, twist off the Extractor Blade from the cup. Rinse cups, To-Go Lids, and Lip Rings with warm water and dish soap immediately. Cups and lids are top-rack dishwasher safe.
- **Extractor Blade:** Hand wash the blade with warm, soapy water. Use a brush to clean around the blades thoroughly. Ensure the gasket on the blade is clean and properly seated after washing.

TROUBLESHOOTING

If you encounter issues with your NutriBullet Pro 900, refer to the following common problems and solutions:

- **Blender not starting:**
 - Ensure the unit is securely plugged into a functional power outlet.
 - Verify that the cup and blade assembly are correctly seated and twisted onto the motor base, engaging the activation tabs.
- **Leaking during blending:**
 - Confirm the Extractor Blade is tightly secured to the cup.
 - Check the gasket on the blade for proper seating and any signs of damage.
 - Do not overfill the cup beyond the MAX line.
- **Motor stops during operation:**
 - The unit may have overheated. Unplug the blender and allow it to cool down for approximately 15-20 minutes before attempting to use it again.
 - Reduce the amount of ingredients in the cup or add more liquid to ease the blending load.

SPECIFICATIONS



Brand	NutriBullet
Model	Pro 900





Power	900 Watts
Voltage	127 Volts
Control Type	Manual with Digital Touch Controls
Blade Material	Stainless Steel
Container Material	Plastic
Product Dimensions	7.32"D x 10.63"W x 11.6"H
Item Weight	8.58 pounds
Special Feature	Multiple Speeds
Recommended Use	Blending

WARRANTY AND SUPPORT

Your NutriBullet Pro 900 Watt Hi-Speed Blender/Mixer comes with a Limited Warranty. For complete details regarding warranty coverage, terms, and conditions, please refer to the warranty information provided in your product packaging or visit the official NutriBullet website. For customer support, service inquiries, or to purchase replacement parts, please consult the contact information available on the NutriBullet website.

Related Documents - Pro 900

	<p>NutriBullet User Guide: Safety, Cleaning, and Usage Instructions</p> <p>Comprehensive user guide for NutriBullet blenders, covering safety precautions, cleaning instructions, and best practices for optimal performance. Includes information for various models like Magic Bullet, Baby Bullet, and series 600, 900, 1000, and 1200.</p>
	<p>Magic Bullet Quick Guide: Blend, Mix, and Create Healthy Recipes</p> <p>Discover the versatility of the Magic Bullet blender with this quick guide. Learn essential techniques, usage tips, and how to create delicious recipes for a healthier lifestyle.</p>

 <p>Recipe guide.</p> <p>Recipes, tips, & more.</p> <p>nutribullet turbo</p>	<p>NutriBullet Turbo™ Recipe Guide: Smoothies, Dips, and Sweets</p> <p>Discover delicious and easy recipes for your NutriBullet Turbo™ personal blender, from energizing smoothies and healthy dips to decadent sweets. Includes tips for building the perfect smoothie and ingredient guides.</p>
 <p>User guide.</p>	<p>NutriBullet Blender Combo User Guide Safety, Operation, and Maintenance</p> <p>This user guide provides comprehensive instructions for the NutriBullet Blender Combo (Model NBF07500-1210DG, NBC-12A). It covers essential safety precautions, assembly, operation of the pitcher and cups, blending control panel functions, care and maintenance, replacement parts, and the one-year limited warranty. Learn how to safely and effectively use your NutriBullet Blender Combo for optimal results.</p>
 <p>nutribullet FLEX PORTABLE BLENDER</p>	<p>nutribullet FLEX™ Portable Blender User Guide</p> <p>Comprehensive user guide for the nutribullet® FLEX™ Portable Blender, covering safety, setup, usage, troubleshooting, and maintenance. Learn how to use your portable blender effectively.</p>
 <p>User guide.</p>	<p>NutriBullet Pro+ User Guide: Operation, Safety, and Maintenance</p> <p>Explore the official user guide for the NutriBullet Pro+ blender. This guide provides essential information on safe operation, assembly, cleaning, maintenance, and warranty details for your NutriBullet Pro+.</p>