

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Roll-N-Lock](#) /
- › [Roll-N-Lock Cargo Manager CM845 User Manual](#)

## Roll-N-Lock CM845

# Roll-N-Lock Cargo Manager CM845 User Manual

Model: CM845

## 1. PRODUCT OVERVIEW

---

The Roll-N-Lock Cargo Manager is an innovative, movable truck bed divider designed to enhance cargo organization and security. This accessory works seamlessly with Roll-N-Lock retractable truck bed covers, allowing users to efficiently manage and contain lightweight cargo within the truck bed. Its design ensures cargo remains snug and in place, preventing shifting during transit.



Image: The Cargo Manager installed in a truck bed, demonstrating its position near the tailgate.

## Key Features:

- **Movable Design:** Can be positioned every 3 inches along the truck bed length.
- **Driver-Side Control:** Easily repositioned using control levers accessible from the driver's side.
- **Spring-Activated Mechanism:** Automatically pins the divider to the sidetracks for secure placement.
- **Lightweight and Removable:** Weighing approximately 22 pounds, it can be quickly removed for larger cargo.
- **Flip-Up Feature:** Allows the divider to swivel up and lock into a parallel position, 12 inches above the bed floor, for hauling longer items.
- **Compatibility:** Specifically designed to work with Roll-N-Lock retractable truck bed covers.



Image: Visual representation of the Cargo Manager's benefits: versatile organization, secure goods, and custom cargo management.

## 2. SETUP AND INSTALLATION

---

The Cargo Manager is designed for straightforward integration with your existing Roll-N-Lock retractable truck bed cover. It attaches directly to the rails of the tonneau cover.

### Initial Placement:

1. Ensure your Roll-N-Lock tonneau cover is properly installed and secured.
2. Align the Cargo Manager with the tracks on the tonneau cover rails.
3. Gently lower the Cargo Manager onto the rails, ensuring the spring-activated pins engage with the slots in the sidetracks.



Image: Hands demonstrating the adjustment of the Cargo Manager along the truck bed rails.

## Removing the Cargo Manager:

For hauling larger items that cannot slide underneath the divider, the Cargo Manager can be easily and quickly removed.

1. Locate the control levers on the driver's side of the Cargo Manager.
2. Squeeze the control levers to disengage the pins from the sidetracks.
3. Lift the Cargo Manager straight up and out of the truck bed.

## 3. OPERATING INSTRUCTIONS

---

### Repositioning the Cargo Manager:

The Cargo Manager can be moved along the length of the truck bed to accommodate various cargo sizes and needs.

1. From the driver's side, locate the control levers on the Cargo Manager.
2. Squeeze both control levers simultaneously. This will disengage the spring-activated pins from the sidetracks.
3. Slide the Cargo Manager to your desired position along the rails.
4. Release the control levers. The spring-activated mechanism will automatically pin the divider into the nearest available slot, securing its position.



Image: Detail of the control levers used to reposition the Cargo Manager.

### Securing Cargo:

Once positioned, the Cargo Manager helps prevent items from shifting in the truck bed, especially during sudden stops or turns.

- Place your cargo in the desired section of the truck bed, either in front of or behind the Cargo Manager.
- Adjust the Cargo Manager's position to snugly contain the cargo. For optimal security, ensure the cargo is pressed firmly against the divider or the front of the bed.
- For additional security, especially with smaller or irregularly shaped items, consider using bungee cords or tie-downs in conjunction with the Cargo Manager.



Image: A cooler secured in the truck bed by the Cargo Manager, demonstrating its cargo containment capability.

### Using the Flip-Up Feature:

The flip-up feature allows you to haul longer items while still utilizing the Cargo Manager for organization.

1. To activate, lift the Cargo Manager from its horizontal position.
2. Swivel the divider upwards until it locks into a parallel position, approximately 12 inches above the bed floor.
3. This creates an elevated barrier, allowing longer items to slide underneath while still providing a stop for other cargo.



Image: A user loading long items into the truck bed, illustrating how the Cargo Manager can be positioned or flipped up to accommodate various cargo lengths.

## 4. MAINTENANCE

---

To ensure the longevity and optimal performance of your Roll-N-Lock Cargo Manager, follow these simple maintenance guidelines:

- **Cleaning:** Regularly clean the Cargo Manager and its tracks with mild soap and water. Rinse thoroughly and dry to prevent dirt and debris buildup, which can impede smooth operation.
- **Inspection:** Periodically inspect the control levers, spring mechanisms, and pins for any signs of wear, damage, or obstruction. Ensure they move freely and engage securely.
- **Lubrication:** If the Cargo Manager becomes difficult to slide, apply a silicone-based lubricant to the tracks. Avoid petroleum-based lubricants as they can attract dirt.

## 5. TROUBLESHOOTING

---

If you encounter any issues with your Cargo Manager, consider the following common solutions:

- **Difficulty Sliding:**

- Check the tracks for any debris, dirt, or obstructions. Clean thoroughly.
- Ensure the control levers are fully squeezed when attempting to move the divider.
- Apply a silicone-based lubricant to the tracks if friction is present.

- **Pins Not Engaging:**

- Verify that the Cargo Manager is properly aligned with the slots in the sidetracks.
- Inspect the spring-activated pins for damage or blockages.
- Ensure the control levers are fully released after positioning the divider.

- **Cargo Shifting:**

- Ensure the Cargo Manager is positioned snugly against the cargo.
- Consider using additional tie-downs or bungee cords for very loose or heavy items.

If problems persist after attempting these solutions, please refer to the [Warranty and Support](#) section for further assistance.

## 6. SPECIFICATIONS

---

Attribute	Detail
Brand	Roll-N-Lock
Model Name	Cargo Manager
Model Number	CM845
Material	Aluminum, Plastic
Exterior Finish	Painted
Item Weight	22 pounds
Package Dimensions	66 x 18 x 3 inches
Country of Origin	USA
UPC	194839062992
Compatibility	Works only with Roll-N-Lock Tonneau Covers. Fits 2022 - 2025 Nissan Frontier, Crew Cab 5' 0" Bed (58.6").



Image: "Made in the USA with Global Materials" emblem.

## 7. WARRANTY AND SUPPORT

---

### Warranty Information:

The Roll-N-Lock Cargo Manager is backed by a **three-year warranty** from Roll-N-Lock. This warranty covers defects in

materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

## Customer Support:

For technical assistance, warranty claims, or any questions regarding your Roll-N-Lock Cargo Manager, please contact Roll-N-Lock customer support directly.

*Contact details (e.g., phone number, website) are typically provided with your product packaging or on the manufacturer's official website.*

