

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VTech](#) /

› **VTech Kidi Superstar Jr. Karaoke Machine User Manual**

**VTech 80-552400**

# VTech Kidi Superstar Jr. Karaoke Machine User Manual

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before using this product. Keep this manual for future reference. Adult supervision is recommended during use.

- **Battery Safety:** Requires 4 AA batteries. Batteries are included for demo purposes only; new batteries are recommended for regular use. Ensure batteries are inserted with correct polarity. Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries. Remove exhausted batteries from the product. Remove batteries if the product is not to be used for an extended period.
- **Choking Hazard:** This product contains small parts and is not suitable for children under 3 years of age.
- **Electrical Safety:** Use only the power adapter specified by the manufacturer. Do not operate the product if the cord or plug is damaged.
- **General Care:** Keep the product away from water and moisture. Clean with a soft, dry cloth.

## WHAT'S INCLUDED

The VTech Kidi Superstar Jr. Karaoke Machine package includes:

- Kidi Superstar Jr. Karaoke Unit
- 2 Wheel Brackets
- Wired Microphone
- Quick Start Guide



Image: Packaging of the VTech Kidi Superstar Jr. Karaoke Machine, illustrating the main unit, microphone, and other components.

## SETUP

### 1. Battery Installation

Locate the battery compartment on the underside of the main unit. Use a screwdriver to open the compartment. Insert 4 new AA batteries, ensuring correct polarity (+/-). Close the compartment securely.

### 2. Assembling the Stand and Wheels

1. Attach the two wheel brackets to the bottom of the main karaoke unit.

2. Insert the microphone stand into the designated slot on the main unit.
3. Adjust the height of the microphone stand by loosening the clamp, extending the pole, and then tightening the clamp.
4. Attach the wired microphone to the microphone holder on the stand.





Image: The VTech Kidi Superstar Jr. Karaoke Machine with its adjustable microphone stand fully extended.

### 3. Connecting the Microphone

Plug the wired microphone's jack into the microphone input port on the main unit. Ensure it is securely connected.

## OPERATING INSTRUCTIONS

---

### 1. Power On/Off

Press the **Power Button** (usually marked with a circle and a vertical line) on the main unit to turn the machine on. Press it again to turn it off.

### 2. Microphone Usage

Speak or sing directly into the microphone. Use the **Microphone Volume Knob** on the control panel to adjust the microphone's output level. The microphone also has an on/off switch directly on its body.



Image: A detailed view of the control panel, showing the various buttons and knobs for operation.

### 3. Music Playback

The unit comes with 10 built-in lyrical songs and popular melodies. Use the numbered buttons (1-10) on the control panel to select a song. Use the **Previous**, **Play/Pause**, and **Next** buttons to control playback. Adjust the overall music volume using the **Volume Knob** on the control panel.

### 4. Bluetooth Connectivity

To play your favorite music from an external device, activate Bluetooth mode on the karaoke machine. On your external device (e.g., smartphone, tablet), search for and connect to the VTech Kidi Superstar Jr. Karaoke. Once connected, you can stream music through the machine's speaker.

### 5. Voice Effects

Experiment with various voice effects to change your singing voice. These effects may include robot voice, high-pitched, low-pitched, and echo. Refer to the Quick Start Guide for specific button functions related to voice effects.

### 6. Party Lights

Activate the colorful party lights by pressing the **Light Button**. The lights will project onto the surrounding area, enhancing the performance atmosphere. Press the button again to cycle through different light modes or turn them off.



Image: The karaoke machine in action, projecting vibrant, colorful lights onto the floor and wall, creating a party ambiance.

## 7. Adjustable Handle and Portability

The unit features an adjustable handle and easy-to-roll wheels for portability. Extend the handle to easily move the

karaoke machine from one location to another.



Image: A child demonstrating the portability of the karaoke machine by pulling it with its extended handle and wheels.

## Official Product Video



Video: An official VTech product video showcasing the features and fun of the Kidi Superstar Jr. Karaoke Machine, including music, lights, and portability.

## Maintenance

- **Cleaning:** Wipe the surface of the karaoke machine with a slightly damp cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the unit in a cool, dry place away from direct sunlight when not in use. If storing for an extended period, remove the batteries.

## Troubleshooting

Problem	Solution
No power/Unit does not turn on.	Check battery installation and replace with new AA batteries if necessary. Ensure the power button is fully pressed.
No sound from microphone.	Ensure the microphone is securely plugged into the input jack. Check the microphone's on/off switch. Adjust the microphone volume knob.
No music playback.	Check the main volume knob. Ensure a song is selected or a Bluetooth device is properly connected and playing music.
Bluetooth not connecting.	Ensure Bluetooth mode is active on the karaoke machine and your external device. Make sure the device is within range and not connected to another Bluetooth device.
Party lights not working.	Press the Light Button to activate. Check battery levels.

## SPECIFICATIONS

- Product Dimensions:** 7.48 x 9.06 x 14.96 inches
- Item Weight:** 3.37 pounds
- Item Model Number:** 80-552400
- Manufacturer Recommended Age:** 36 months - 5 years
- Batteries:** 4 AA batteries required (included for demo purposes)
- Brand:** VTech
- Special Feature:** Built-In Song Track, Bluetooth Connectivity, Voice Effects, Party Lights, Adjustable Mic Stand
- Color:** Blue

## WARRANTY AND SUPPORT

For warranty information, product support, or to purchase replacement parts, please visit the official VTech website or contact VTech customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.

**VTech Customer Service:** Refer to the contact information provided in your Quick Start Guide or on the VTech official website.