

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Ingenuity](#) /

› [Ingenuity InLighten 2-in-1 Soothing Baby Swing & Rocker, Model 13101 \(Remy\) User Manual](#)

Ingenuity 13101

Ingenuity InLighten 2-in-1 Soothing Baby Swing & Rocker User Manual

Model: 13101 (Remy)

1. INTRODUCTION

This manual provides essential instructions for the safe assembly, operation, and maintenance of your Ingenuity InLighten 2-in-1 Soothing Baby Swing & Rocker. Please read all instructions carefully before use and retain this manual for future reference.



The Ingenuity InLighten 2-in-1 Soothing Baby Swing & Rocker, designed for infant comfort and entertainment.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings and instructions could result in serious injury or death.

- Always use the restraint system. Ensure it is correctly fitted and adjusted.
- Never leave the child unattended.
- Do not use this product once your child can sit up unaided or weighs more than 20 lbs (9 kg), whichever comes first.
- This product is not intended for prolonged periods of sleep.
- Never use this product on an elevated surface (e.g., a table).
- Always check that the product is stable and securely assembled before each use.
- Keep children away from the product during assembly and disassembly.
- Do not use accessories or replacement parts other than those approved by the manufacturer.

- Keep the product away from open flames and other strong heat sources.



Ensure the 5-point harness is securely fastened for your child's safety.

3. SETUP AND ASSEMBLY

Assembly of the Ingenuity InLighten Swing & Rocker is designed to be straightforward. Follow the instructions provided in the packaging for detailed steps. Ensure all components are securely connected before use.

- Unpack all components and verify against the parts list (refer to your product packaging).
- Assemble the frame according to the visual instructions.
- Attach the seat pad and ensure the harness is correctly threaded.
- Install the mobile arm and toys.
- For vibration function, insert 1 C battery (not included) into the designated compartment.
- Power the swing using the included USB cord. A wall AC adapter is not included and must be supplied separately.

4. OPERATING INSTRUCTIONS

4.1. 2-in-1 Functionality: Swing to Rocker

The product easily transitions between a swing and a portable rocker. To convert:


1. Ensure the child is removed from the seat.
2. Locate the release buttons on the sides of the seat where it connects to the swing frame.
3. Press the buttons and lift the plush seat off the swing frame.
4. Place the seat on a flat, stable surface to use as a rocker.



The versatile design allows for use as a swing or a portable rocker.

4.2. Control Panel and Remote Control

The GentleTouch control pad and remote control allow you to manage all functions.



Overview of the control panel features for easy operation.

- **Power Button:** Press to turn the unit on or off.
- **Swing Speeds:** Select from 5 automatic swing speeds.
- **Swing Directions:** The seat rotates 180 degrees and swings in 3 directions. Adjust as desired.
- **Timer Options:** Set the swing to operate for 30, 60, or 90 minutes.
- **Vibrations:** Activate soothing vibrations. Requires 1 C battery (not included).
- **Melodies & Sounds:** Choose from 20 preloaded soothing melodies, white noise, or nature sounds. Adjust volume as needed.
- **Light-Up Mobile:** Activate the mobile for a light show and spinning toys.
- **Recline Positions:** Adjust the seat to one of 2 recline positions for comfort or playtime.



Only swing to offer overhead engaging light show

The light-up mobile provides engaging visual stimulation for the baby.

4.3. Portability

The swing features an easy folding frame, incorporated handle, and wheels for convenient movement around the house.



Fold frame and use the handle and wheels to easily move around the house

Easily move the swing from room to room with its integrated handle and wheels.

5. MAINTENANCE AND CARE

Proper care ensures the longevity and hygiene of your product.

- **Frame:** Wipe the metal frame with a soft, clean cloth and mild soap.
- **Seat Pad:** Remove from frame. Fasten buckles on seat restraint and seat pad. Fasten all hook-and-loop patches to the corresponding patch. Machine wash with cold water, gentle cycle. No bleach. Tumble dry, using low heat.
- **Storage:** When storing the swing, always keep it in a dry location, away from any heat sources, and out of direct sunlight.
- **Toy Bar and Toys:** Wipe clean with a damp cloth and mild soap. Air dry. Do not immerse in water.



Machine-washable fabrics

The seat pad features machine-washable fabrics for easy cleaning.

6. TROUBLESHOOTING

If you encounter issues with your Ingenuity InLighten Swing & Rocker, refer to the following common solutions:

Problem	Possible Cause / Solution
Swing does not turn on or operate.	Ensure the USB cord is securely connected to a power source and the swing. Check if the wall adapter (not included) is functioning correctly.
Vibration function is not working.	Verify that a fresh 1 C battery is correctly installed in the vibration unit.
Music or sounds are not playing.	Check the volume settings on the control panel. Ensure the unit is powered on.

Problem	Possible Cause / Solution
Swing motion is erratic or stops.	Ensure the swing is on a flat, level surface. Check for any obstructions. Verify the child's weight does not exceed 20 lbs (9 kg).
Seat is difficult to remove or attach.	Ensure release buttons are fully pressed. Align the seat correctly with the frame connectors.


7. SPECIFICATIONS

- **Model Number:** 13101
- **Product Dimensions:** 35.83"D x 32.68"W x 39.17"H (91.01 cm D x 83.01 cm W x 99.49 cm H)
- **Item Weight:** 9.53 pounds (4.32 kg)
- **Maximum Weight Recommendation:** 20 pounds (9 kg)
- **Maximum Age Recommendation:** 9 months
- **Material Composition:** 64% Metal, 31% Plastic, 5% Fabric
- **Batteries Required:** 1 C battery for vibration (not included)
- **Power Source:** USB cord (included), wall AC adapter not included
- **Features:** 5 swing speeds, 3 timer options, 2 recline positions, 20 melodies/sounds/white noise, light-up mobile with 2 toys, soothing vibrations, 5-point harness, portable folding frame with handle and wheels, remote control.

ingenuity™

Weight Range:
6-20 lb/ 3-9 kg

Max Age:
9 mos.








Key dimensions and weight/age limits for the Ingenuity InLighten Swing & Rocker.


8. WARRANTY AND SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or visit the official Ingenuity website. Contact their customer service for assistance with product issues, replacement parts, or further inquiries.

Online Support: www.kids2.com/ingenuity

© 2025 Ingenuity. All rights reserved. Ingenuity is a brand of Kids2, Inc.


 <p>Ingenuity InLighten™ Soothing Swing & Rocker - Remy™ Swing, Rocker, Stroller ingenuitybaby.com</p>	<p>Ingenuity InLighten Soothing Swing & Rocker - Remy: User Manual and Assembly Guide</p> <p>Comprehensive user manual and assembly guide for the Ingenuity InLighten Soothing Swing & Rocker - Remy. Includes safety warnings, parts list, assembly instructions, operation details, and care instructions.</p>
 <p>Ingenuity InLighten™ Soothing Swing - Van™ Swing, Rocker, Stroller ingenuitybaby.com</p>	<p>Ingenuity InLighten Soothing Swing - Van Elephant User Manual</p> <p>User manual for the Ingenuity InLighten Soothing Swing in the Van Elephant design. Provides instructions on assembly, use, safety warnings, and care.</p>
 <p>Ingenuity InLighten™ Soothing Swing - Dakota™ Swing, Rocker, Stroller ingenuitybaby.com</p>	<p>Ingenuity InLighten Soothing Swing - Dakota User Manual</p> <p>This document provides comprehensive instructions for the Ingenuity InLighten Soothing Swing - Dakota, covering assembly, usage, safety precautions, and care instructions.</p>
 <p>Ingenuity InLighten™ Soothing Swing - Kitt™ Swing, Rocker, Stroller ingenuitybaby.com</p>	<p>Ingenuity InLighten Soothing Swing - Kitt™ User Manual and Safety Guide</p> <p>This comprehensive user manual provides detailed instructions for assembling, using, and caring for the Ingenuity InLighten Soothing Swing - Kitt™. It includes essential safety warnings, operational guidance for the control module, and maintenance tips, presented in English, Spanish, and French.</p>
 <p>Ingenuity SimpleComfort™ Compact Soothing Swing & Rocker™ - Raylan™ Swing, Rocker, Stroller, High Chair, Stroller, High Chair ingenuitybaby.com</p>	<p>Ingenuity SimpleComfort Compact Soothing Swing & Rocker - Raylan User Manual</p> <p>This user manual provides essential safety information, assembly instructions, battery guidelines, and care tips for the Ingenuity SimpleComfort Compact Soothing Swing & Rocker™ in the Raylan™ design.</p>
 <p>Ingenuity InLighten™ Soothing Swing & Rocker - Spruce™ Swing, Rocker, Stroller, High Chair, Stroller, High Chair ingenuitybaby.com</p>	<p>Ingenuity InLighten Soothing Swing & Rocker - Spruce User Manual</p> <p>Comprehensive user manual for the Ingenuity InLighten Soothing Swing & Rocker in the Spruce design. Includes safety warnings, assembly instructions, battery information, and care and cleaning guidelines.</p>



[\[pdf\]](#) User Manual Guide

Dialcord Stringing Guide DC 3 1953 worldradiohistory BOOKSHELF ARH Sams Books |||

1.00 DC-3 FIRST EDITION JANUARY 1954 Reproduction or use, without express permission, of editoria ... RION CI00, C101 C102 C103, C104, C105 C105A C108 11011 1305 11801,11802V- M 12110M. 12310W.. 12708 **13101** 14601 1 1 1 1 1 1 2 2 2 . 2 2 2 CLEARSON1C 699 699 5C66 1 640 640 COLLINES AUDIO PROD... lang:en score:18 filesize: 2.12 M page_count: 96 document date: 2020-01-06



[\[pdf\]](#) Guide


Barwick Radio Buyer s Guide 1927 worldradiohistory Archive Early Assorted |||

0. - 77. II-ID A Barawik Triumph, in Super Radio Values: Is This Splendid Single Control Illumin ... Caokemrp.leteL,ist,wi t1h5o0u.t00.acces so7ri9es., 5bu0t NET WHOLESALE For Battery Operation 113 **13101**--Set Completo with All Accessories for Battery Operation including four 201A type, one 200A ... lang:en score:17 filesize: 13.85 M page_count: 130 document date: 2021-08-06



[\[pdf\]](#) Guide Catalog


12th Annua Guide to Mink Attorneys Music Connection 1998 07 20 worldradiohistory Archive All 90 ||| 12th Annua 1GuCide to Mink Attorneys Vol. XXII, No. 15 7/20/98 to 8/2/98 U.S. \$2.95 Canada \$3.95 ... Of The Art equipment or you can come to me I reate Professional Modern Tracks g Arrangements PHONE, **13101** 535-6089 *Dissolve http://members.aol.com/chsolv Dogman htlei/www.surf to/dogman -Dogwood Moo... lang:en score:16 filesize: 6.71 M page_count: 64 document date: 2023-09-18



[Billboard International Buyer's Guide 1981-1982: Music Industry Directory](#)

A comprehensive directory of the music and recording industry for 1981-1982, featuring extensive listings of record companies, music publishers, wholesalers, services, supplies, accessories, and detailed market data from Billboard.

lang:en score:16 filesize: 39.27 M page_count: 352 document date: 2019-10-07




[\[pdf\] User Manual Documentation](#)

x Apple III Service Reference Manual OCR 1982 mirrors apple2 org za ftp apple asimov net documentation apple3 service reference manual

Apple III Computer Information Apple III Level 2 Service Reference Manual Apple III Computer Infor ... 0 R94-1 41 DEVSEL4* 315-41 1376-11 42 DI 315-42 314-42 313-42 312-42 1368-12 316-24 13111-12 **13101**-5 U91-7 1369-12 P15-9 43 D6 315-43 J14-43 313-43 312-43 U68-13 316-23 U111-9 1391-13 1369-...

lang:en score:13 filesize: 12.21 M page_count: 730 document date: 2010-08-05




[\[pdf\] User Manual Declaration of Conformity](#)

x apple iii doc service manual 1982 Old Crap Vintage Computing oldcrap org 2023 04 |||

Apple III Computer Information Apple III Level 2 Service Reference Manual Apple III Computer Infor ... 0 R94-1 41 DEVSEL4* 315-41 1376-11 42 DI 315-42 314-42 313-42 312-42 1368-12 316-24 13111-12 **13101**-5 U91-7 1369-12 P15-9 43 D6 315-43 J14-43 313-43 312-43 U68-13 316-23 U111-9 1391-13 1369-...

lang:en score:12 filesize: 54.01 M page_count: 730 document date: 2019-05-12



[\[pdf\]](#) User Manual

Nerrina Ct Karana Downs SPS SP287 Switchboard OM Manual tms699 brisbane sp287 sewage pump station nerrina ct karana downs sps switchboard om manual operations and maintenance pumping electrical id 178 archive box 28 power electric switchboards 2003 number bne01467034 scanned file name design manufacture supply factory testing of parkage no 3 court TMS699 urbanutilities au media quu s suppliers info technical manuals waste water la en hash

B521FE6C2B0270FA1E85D2FDE31EEA4E6C1858AB |||

Nerrina Ct Karana Downs SPS SP287 Switchboard OM Manual POWER ELECTRIC SWITCHBOARDS PTY LTD ACN 052 ... 5150000 4306813 8643534. 6000000 30000000 Q-Pulse Id TMS699 Active 29/01/2014 Page 67 of **13101** Nerrina Ct Karana Downs SPS SP287 Switchboard OM Manual I I == =1IM M=11.10iM. =Mi11l=l1l1...

lang:en **score:11** filesize: 14.37 M page_count: 130 document date: 2014-01-28