

[Manuals.plus](#) /

› [Naturehike](#) /

› Naturehike P-PLUS Ultralight 3-4 Person Family Dome Tent Instruction Manual

Naturehike P-PLUS

Naturehike P-PLUS Ultralight 3-4 Person Family Dome Tent Instruction Manual

Model: P-PLUS

1. INTRODUCTION AND OVERVIEW

Thank you for choosing the Naturehike P-PLUS Ultralight 3-4 Person Family Dome Tent. This manual provides essential information for the proper setup, use, maintenance, and care of your tent to ensure a comfortable and safe outdoor experience. The P-PLUS tent is designed for 3-4 individuals, offering a spacious and waterproof shelter suitable for 4-season camping and hiking.



Image: The Naturehike P-PLUS tent featuring its large hall design, providing an extended sheltered area at the entrance. Two individuals are shown comfortably seated outside the tent.

Key features include its ultralight design, robust aluminum poles for easy assembly, a spacious interior with a separate living area, and advanced waterproofing for reliable protection against the elements.

2. SETUP INSTRUCTIONS

The Naturehike P-PLUS tent is designed for quick and easy assembly, even for first-time users. Follow these steps for proper setup:

1. **Unpack and Lay Out:** Remove the tent and all components from the carry bag. Lay the inner tent flat on your chosen campsite, ensuring the ground is clear of sharp objects.
2. **Assemble Poles:** Connect the aluminum alloy tent pole sections. The poles are equipped with simple fasteners for quick assembly.
3. **Insert Poles:** Slide the assembled poles through the sleeves or attach them to the clips on the inner tent.
4. **Secure Inner Tent:** Lift the tent structure and secure the pole ends into the grommets or pins at the corners of the inner tent.
5. **Attach Rainfly:** Drape the rainfly over the inner tent, aligning the doors and vestibules. Secure the rainfly to the inner tent and poles using the attached buckles or straps.
6. **Stake Down:** Use the provided stakes to secure all tent corners, guylines, and vestibule points to the ground. Ensure guylines are taut to maximize stability and wind resistance.
7. **Adjust Ventilation:** Open or close the D-shaped zippers and ventilation windows as needed for airflow.




Image: A detailed view of the aluminum alloy tent poles, highlighting the simple fasteners that facilitate quick and easy assembly.

DETAIL DRAWING



150D Polyester oxford fabric tent bottom



Tent lamp hook



Inner tent storage bag



Ventilation window



Hook connection

Image: The Naturehike P-PLUS tent fully erected in an outdoor setting, demonstrating its complete setup next to a natural water body.

3. OPERATING (USAGE)

The P-PLUS tent offers a comfortable and functional space for your outdoor adventures:

- **Spacious Interior:** The tent features a layout divided into one main room and one living room (large hall design), accommodating 3-4 people. This design expands the entrance area into a small shelter, enhancing usable space.
- **Ventilation:** Utilize the D-shaped zippers on both sides and the ventilation windows at the top to manage airflow and minimize condensation. The inner tent is constructed with B3 mesh for optimal breathability.
- **Weather Protection:** The outer tent is made from double-layer 210T polyester fabric with a waterproof rating of 2000mm. The inner tent's floor is 150D Oxford polyester fabric with multi-layer laminated adhesive technology, ensuring the tent remains dry even in rainy conditions.

- **Internal Features:** The tent includes practical features such as a tent lamp hook for lighting and an inner tent storage bag for organizing small items.



Image: A diagram detailing the ultralight and waterproof construction of the tent, highlighting the double-layer polyester fabric and its resistance to rain, wind, and sun.

ALL ALUMINUM ALLOY TENT POLE

With the simple fasteners, it is easy and fast to build



Image: A detailed drawing showcasing various internal features of the tent, such as the durable tent bottom, lamp hook, storage bag, ventilation window, and pole connection points.



Image: An interior view of the tent, illustrating the spacious living area where two people are comfortably seated at a small table, demonstrating the tent's capacity and design.

4. MAINTENANCE

Proper maintenance will extend the life of your Naturehike P-PLUS tent:

- **Cleaning:** After each use, gently brush off any dirt or debris. For stubborn stains, use a mild soap and water solution with a soft sponge. Do not use harsh detergents, bleach, or a washing machine, as this can damage the fabric and waterproof coating.
- **Drying:** Always ensure the tent is completely dry before packing it away. Packing a damp tent can lead to mildew, odors, and degradation of the fabric and coatings. Hang it in a shaded, well-ventilated area until thoroughly dry.
- **Storage:** Store the tent in a cool, dry place away from direct sunlight and extreme temperatures. Avoid compressing the tent too tightly for extended periods, as this can affect the waterproof coatings and fabric integrity. The tent's compact packed size (φ17 × 50 cm) makes storage convenient.
- **Zippers:** Keep zippers clean and free of dirt. Lubricate them periodically with a silicone-based zipper

lubricant to ensure smooth operation.

- **Poles:** Inspect aluminum poles for any bends or damage. Clean them if necessary.

5. TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Condensation Inside Tent:** This is common in humid conditions. Ensure proper ventilation by opening D-shaped zippers and ventilation windows. Choose a campsite with good airflow.
- **Water Leaks:** Check for proper rainfly placement and tension. Ensure all seams are sealed (factory-sealed, but inspect for wear). If leaks persist, a seam sealer can be applied to affected areas.
- **Difficulty Assembling Poles:** Ensure all pole sections are fully connected. If a pole is bent, try to gently straighten it or replace the section if severely damaged.
- **Zipper Snagging:** Gently pull the fabric away from the zipper teeth while operating. Clean any dirt or debris from the zipper. Apply zipper lubricant if needed.
- **Tent Instability:** Ensure all stakes are firmly in the ground and guylines are properly tensioned. In windy conditions, use all available guylines and consider adding extra stakes.

6. SPECIFICATIONS

Detailed specifications for the Naturehike P-PLUS Tent:

Dimensional drawing



Suggested number:
3-4 Person



Weight:
3.5 kg





Image: A dimensional drawing providing key measurements of the Naturehike P-PLUS tent, including its packed size, erected dimensions, and weight.

Feature	Detail
Brand	Naturehike
Model Name	P-PLUS
Product Dimensions (L x W x H)	210 cm x 370 cm x 130 cm (unfolded)
Packed Dimensions	φ17 cm x 50 cm
Product Weight	3.5 kg (Minimum Tent Weight)
Number of Occupants	3-4 people
Seasons	4-Season
Tent Construction	Camping Tent (Dome Shape)
Outer Tent Material	210T Polyester Fabric

Feature	Detail
Waterproof Level (Outer Tent)	2000mm
Tent Floor Material	150D Oxford Polyester Fabric with multi-layer laminated adhesive technology
Pole Material	Aluminum Alloy
Number of Rooms	2 (one room, one living room)
Closure Type	Zipper
Color	Green
Assembly Required	Yes

7. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Naturehike website or contact the seller directly. Keep your proof of purchase for any warranty claims.

If you have questions regarding the setup, operation, or maintenance of your Naturehike P-PLUS tent that are not covered in this manual, please reach out to Naturehike customer service or the retailer from whom you purchased the product.