

Nerf F7634

NERF Pro Gelfire Raid Blaster Instruction Manual

Model: F7634

INTRODUCTION

This manual provides essential instructions for the safe and effective use of your NERF Pro Gelfire Raid Blaster. Please read all instructions carefully before operating the blaster. This product is designed for users aged 14 and up.

SAFETY INFORMATION

WARNING: Small parts may be generated. Not for children under 3 years.

- Always wear the included protective eyewear when using this blaster.
- Do not aim at eyes or face.
- Use only official NERF Pro Gelfire rounds. Other projectiles may not meet safety standards.
- Do not modify the blaster or gel rounds.
- Outdoor use is recommended.

WHAT'S IN THE BOX

- NERF Pro Gelfire Raid Blaster
- 10,000 Dehydrated NERF Pro Gelfire Soft Super Absorbent Polymer Projectiles
- 800-Round Capacity Hopper
- Protective Eyewear
- Instruction Manual (this document)



Image: The NERF Pro Gelfire Raid Blaster, showing the blaster, two packets of dehydrated gel rounds, protective eyewear, and a visual representation of 10,000 gel rounds.

SETUP

1. Hydrating Gel Rounds

1. Empty the dehydrated gel rounds into a large container.
2. Add a sufficient amount of water to fully submerge the rounds.
3. Allow the rounds to soak for at least 3-4 hours, or until they have expanded to their full size (approximately 7-8mm).
4. Drain any excess water before use. Store hydrated rounds in an airtight container away from direct sunlight.



Image: Illustration showing small dehydrated gel rounds transforming into larger, hydrated gel rounds after adding water.

2. Loading the Hopper

- Ensure gel rounds are fully hydrated and drained of excess water.
- Open the lid of the 800-round capacity hopper.
- Carefully pour the hydrated gel rounds into the hopper. Do not overfill.
- Securely close the hopper lid.



Image: A hand holding the clear, orange-filled 800-round capacity hopper, ready for attachment to the blaster.

3. Attaching the Hopper

- Locate the hopper attachment point on top of the blaster.
- Align the hopper with the attachment point and firmly press it into place until it clicks securely.

OPERATION

1. Engaging the Trigger Lock

- Before handling, ensure the trigger lock is engaged to prevent accidental firing. The trigger lock is typically a switch located near the trigger.



Image: A user wearing protective eyewear, demonstrating the location of the trigger lock on the blaster.

2. Priming the Blaster

- Disengage the trigger lock.
- Grip the pump-action handle located under the barrel.
- Pull the handle fully backward, then push it fully forward until it locks into place. This action primes the blaster and loads gel rounds into the firing mechanism.



Image: A user demonstrating the pump-action motion required to prime the blaster, indicated by white arrows.

3. Firing

- Once primed, aim the blaster at a safe target.
- Pull the trigger to fire. The Raid Blaster features scattershot blasting, firing 5 rounds with each trigger pull.



Image: A close-up view of the blaster's muzzle, showing five gel rounds being fired simultaneously.



Image: A user aiming the blaster, highlighting its capability to fire rounds at up to 150 feet per second (FPS).

MAINTENANCE

Cleaning

- After each use, wipe down the exterior of the blaster with a clean, damp cloth.
- Ensure no gel rounds or debris are lodged in the firing mechanism or hopper.
- Do not submerge the blaster in water.

Storage

- Store the blaster in a cool, dry place away from direct sunlight.
- Remove any remaining hydrated gel rounds from the hopper before storing for extended periods.
- Engage the trigger lock when storing the blaster.

TROUBLESHOOTING

- **Blaster not firing:**
 - a. Check if the trigger lock is disengaged.

- b. Ensure the blaster is fully primed by pulling the pump-action handle completely back and then forward.
- c. Verify that the hopper contains hydrated gel rounds and is securely attached.
- **Gel rounds not feeding properly:**
 - a. Ensure gel rounds are fully hydrated and not too small or too large. Improperly hydrated rounds can cause feeding issues.
 - b. Check for any obstructions in the hopper or feeding mechanism.
- **Reduced firing velocity:**
 - a. Ensure the blaster is properly primed with a full pump-action cycle.
 - b. Use only official NERF Pro Gelfire rounds.

SPECIFICATIONS




Model Number	F7634
Product Dimensions	24 x 2.63 x 9 inches
Item Weight	1.75 pounds
Recommended Age	14 years and up
Hopper Capacity	800 rounds
Projectile Type	Hydrated Gel Rounds
Manufacturer	Hasbro




WARRANTY AND SUPPORT

For warranty information, product support, or to purchase additional gel rounds and accessories, please visit the official Nerf website or contact Hasbro customer service. Keep your proof of purchase for any warranty claims.

Nerf Official Website: www.hasbro.com/en-us/brands/nerf

Related Documents - F7634

	<p>Nerf Pro Gelfire Legion Blaster: Instructions, Safety, and Operation</p> <p>Comprehensive guide to the Nerf Pro Gelfire Legion Blaster, covering setup, hydration of Gelfire rounds, firing modes, safety precautions, and storage. Includes official Hasbro product information.</p>
	<p>Nerf Hyper MACH-100 Blaster: Operating and Safety Instructions</p> <p>Comprehensive guide for the Nerf Hyper MACH-100 blaster, detailing how to load, fire, clear jams, store the blaster, and important safety precautions. Includes battery information and product compatibility.</p>
	<p>Nerf Roblox Arsenal Pulse Laser Blaster Instructions</p> <p>Comprehensive guide on how to operate, load, fire, and clear jams for the Nerf Roblox Arsenal Pulse Laser motorized dart blaster. Includes safety warnings and battery information.</p>

	<p>NERF Modulus ECS-10 Blaster: Instructions and Safety Guide</p> <p>Official instructions and safety information for the NERF Modulus ECS-10 blaster by Hasbro. Learn how to load, fire, maintain, and safely use your NERF blaster.</p>
	<p>Nerf Ultra One Blaster: Assembly, Loading, and Firing Instructions</p> <p>A comprehensive guide to assembling, loading, and operating the Nerf Ultra One Motorized Blaster, including important safety information and troubleshooting tips.</p>
	<p>Nerf Fortnite AR-L Blaster: Instructions and Features</p> <p>This document provides instructions and details for the Nerf Fortnite AR-L Blaster, including how to clear jams, insert batteries, load and fire darts, and store the blaster. It features multilingual support and highlights key components like the trigger, flip-up sight, tactical rail, and acceleration button.</p>

Documents - Nerf – F7634

[\[pdf\]](#) Instructions

Nerf Pro Gelfire Raid Blaster Fire 5 Rounds At Once 10 000 800 Round Hopper société Règles
Instructions du fabricant HasbroF76340920 INST NER PRO GELFIRE RAID FARassets us 01 kc
usercontent 443 500e0a65 283d 00ef 33b2 7f1f20488fe2 afec77e0 c945 48ca a024 2e28ab724a51
F76340920 FAR |||

BLASTER STORAGE 1. Make sure trigger lock is in locked position when storing the
blaster. 2. Prior ... ro. Hasbro, Pawtucket, RI 02861-1059 USA. US/CANADA TEL. 1-
800-255-5516. Patent: patent.hasbro.com **F7634** PN00084858 TRIGGER LOCK
PULL-BACK PRIMING HANDLE CREATIVE DEVELOPMENT STUDIOS //
CREATIVE ...

lang:en score:32 filesize: 4.04 M page_count: 4 document date: 2023-01-04



[Nerf Pro Gelfire Raid Blaster: Instructions and Safety Guide](#)

Official instructions and safety information for the Nerf Pro Gelfire Raid blaster,
covering round hydration, blaster operation, storage, and important warnings.
lang:en score:30 filesize: 4.04 M page_count: 4 document date: 2023-01-04

