

PELONIS 0750545106520

Pelonis Personal Mini Fan Forced Heater User Manual

Model: 0750545106520 | Brand: PELONIS

INTRODUCTION

Thank you for choosing the Pelonis Personal Mini Fan Forced Heater. This compact and efficient heater is designed to provide supplemental warmth to small personal spaces such as offices, bedrooms, or bathrooms. Its adjustable thermostat and multiple heat settings allow for personalized comfort. Please read this manual thoroughly before operation to ensure safe and effective use.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons. This heater is for indoor use only.

- **DO NOT COVER:** Never cover the heater or block the air intake/outlet openings. This can lead to overheating and fire.
- **Tip-Over Protection:** The heater is equipped with a safety switch that automatically turns the unit off if it is accidentally tipped over.
- **Overheat Protection:** A red indicator light will illuminate if the heater gets too hot, and the unit will automatically shut off to prevent overheating.
- Keep combustible materials (furniture, pillows, bedding, papers, clothes, and curtains) at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- Do not use in bathrooms, laundry areas, or similar indoor locations where water is present.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).

PRODUCT OVERVIEW

Familiarize yourself with the components of your Pelonis Personal Mini Fan Forced Heater:

- **Thermostat Dial:** Adjusts the desired temperature (Min to Max).
- **Heat Setting Dial:** Selects fan-only mode or one of three heat levels (Off, Fan, 1, 2, 3).
- **Indicator Light:** Illuminates when the heater is operating or if an overheat condition occurs.
- **Front Grille:** Air outlet for heated or fan-only air.
- **Rear Air Intake:** Where air is drawn into the unit.

- **Carrying Handle:** Integrated handle for easy portability.
- **Tip-Over Safety Switch:** Located on the bottom of the unit.



Figure 1: Front and top view of the Pelonis Personal Mini Fan Forced Heater, highlighting the thermostat and heat setting dials.



Figure 2: Close-up front view of the heater, showing the protective grille over the fan.



Figure 3: Rear view of the heater, illustrating the power cord connection and the location of the tip-over safety switch on the base.

SETUP

1. Unpack the heater from its packaging and remove all protective materials.
2. Place the heater on a firm, level surface. Ensure it is at least 3 feet (0.9 meters) away from walls, furniture, and other objects.
3. Ensure the power cord is not obstructed or placed under rugs.
4. Plug the heater directly into a 120V AC wall outlet. Do not use extension cords or power strips.

OPERATING INSTRUCTIONS

Turning On/Off and Heat Settings

1. To turn the heater on, rotate the **Heat Setting Dial** clockwise from the "OFF" position.
2. Select your desired mode:
 - **Fan Only (Fan icon):** Provides cool air circulation without heat.
 - **Heat Setting 1:** Low heat output.
 - **Heat Setting 2:** Medium heat output.
 - **Heat Setting 3:** High heat output.
3. To turn the heater off, rotate the **Heat Setting Dial** counter-clockwise to the "OFF" position.

Adjusting the Thermostat

1. Once a heat setting (1, 2, or 3) is selected, rotate the **Thermostat Dial** to your desired temperature.
2. Turn the dial towards "MAX" for higher heat and "MIN" for lower heat.
3. The heater will cycle on and off to maintain the set temperature.

MAINTENANCE

Regular maintenance helps ensure the longevity and safe operation of your heater.

- **Cleaning:** Always unplug the heater and allow it to cool completely before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the heater in a cool, dry place. It is recommended to store it in its original packaging to protect it from dust and damage.
- Do not attempt to open or repair the heater yourself. Refer all servicing to qualified service personnel.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	Not plugged in; power outlet not working; tip-over switch activated; overheat protection activated.	Ensure unit is securely plugged into a working outlet. Check if the heater was tipped over (reset by placing upright). Allow unit to cool down if overheat light is on.
Heater stops working unexpectedly.	Overheat protection activated; tip-over switch activated.	Unplug the unit, allow it to cool for 10-15 minutes, then plug back in. Ensure unit is on a stable, flat surface.
Heater is on but no heat is produced.	Set to "Fan Only" mode; thermostat set too low.	Ensure the Heat Setting Dial is on 1, 2, or 3. Adjust the Thermostat Dial to a higher setting.

SPECIFICATIONS

- **Brand:** PELONIS
- **Model Number:** 0750545106520
- **Form Factor:** Pedestal
- **Indoor/Outdoor Usage:** Indoor
- **Room Type:** Home Office

- **Fuel Type:** Electric
- **Number of Speeds:** 3 (Heat settings) + Fan Only
- **Voltage:** 120 Volts (AC)
- **Amperage:** 12.5 Amps
- **Max Temperature Setting:** 450 Degrees Fahrenheit
- **Item Weight:** 3.66 pounds
- **Package Dimensions:** 10.35 x 8.62 x 4.72 inches
- **UPC:** 750545106520

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the warranty card included with your product or visit the official PELONIS website. Do not attempt to repair the unit yourself.

© 2024 PELONIS. All rights reserved.