

Casio AP-270 CELVIANO

Casio AP-270 CELVIANO Digital Piano User Manual

Model: AP-270 CELVIANO

INTRODUCTION

This manual provides essential information for the setup, operation, and maintenance of your Casio AP-270 CELVIANO Digital Piano. Designed to offer a natural playing feel and rich, authentic tones, this instrument combines advanced technology with elegant design. Please read this manual thoroughly to ensure proper use and to maximize your musical experience.

WHAT'S INCLUDED

Your Casio AP-270 CELVIANO Digital Piano package includes the following components:

- Casio AP-270 CELVIANO Digital Piano (Brown)
- Furniture Bench
- Headphones
- AC Adapter
- Austin Bazaar Instructional DVD
- Polishing Cloth
- User Manual (this document)



Image: The complete Casio AP-270 CELVIANO Digital Piano bundle, showcasing the brown digital piano, matching bench, headphones, and various instructional materials.

KEY FEATURES

- **Multi-dimensional Morphing AiR Sound Source:** This advanced sound source meticulously reproduces the rich, resonating tones inherent to a grand piano, with expanded memory for longer sampling duration and enhanced waveform data quality.
- **Tri-sensor Scaled Hammer Action Keyboard II:** Experience a natural playing feel that closely mimics a grand piano. The three-sensor system accurately detects key touches, replicating the unique sounding timing of an acoustic instrument.

- **Simulated Ebony and Ivory Keys:** The keys provide a luxurious feel and texture, along with a smooth touch. The detailed crimp surface finish helps prevent finger slippage during extended play.
- **Two Legendary Grand Piano Sounds:** Select between two distinct world-renowned grand piano sounds to suit various musical genres and performance environments. One offers powerful, richly reverberating performances, ideal for classical pieces, while the other provides crisp, straightforward sound, suitable for jazz and pop.
- **Damper Resonance:** A stereo resonance simulator on all 88 keys naturally reproduces the deep, beautiful resonance created by using a damper pedal, including the resonance from the lifting of the dampers.
- **Concert Play:** Features high-quality audio data recordings of 10 live orchestra performances, allowing pianists to play along and experience a magnificent performance.
- **Connectivity:** Class-compliant USB connects to the Casio Music Space iOS/Android app for lessons, score viewing, and more. Includes headphone outputs for quiet practice.

SETUP

Follow these steps to set up your digital piano:

1. **Unpacking:** Carefully remove all components from the packaging. Ensure all items listed in the "What's Included" section are present.
2. **Assembly:** Assemble the digital piano cabinet and attach the keyboard unit according to the separate assembly guide provided in the box. Ensure all screws are tightened securely.
3. **Bench Assembly:** Assemble the furniture bench as per its instructions.
4. **Power Connection:** Connect the supplied AC adapter to the DC IN terminal on the piano and then plug it into a standard wall outlet.
5. **Headphones:** For private practice, plug your headphones into one of the 3.5mm headphone jacks located on the front of the piano.
6. **USB Connection (Optional):** To connect to a computer or smart device for use with the Casio Music Space app, use a standard USB cable (not included) to connect the piano's USB port to your device.



Image: A side perspective of the Casio AP-270 CELVIANO Digital Piano, highlighting its cabinet design and the accompanying bench.

OPERATING INSTRUCTIONS

Power On/Off

- To turn on: Press the **POWER** button.
- To turn off: Press and hold the **POWER** button until the display turns off.

Adjusting Volume

Use the **VOLUME** knob located on the front panel to adjust the overall sound output level.

Selecting Tones

Your piano features a variety of tones, including two distinct grand piano sounds. Refer to the detailed tone list in the full user manual for specific tone selection procedures. Generally, tones are selected using dedicated buttons or a combination of function and key presses.

Using Pedals

The Casio AP-270 includes three pedals: Damper (Sustain), Soft, and Sostenuto. These function similarly to an acoustic grand piano, allowing for expressive control over your sound.

- **Damper Pedal (Right):** Sustains notes. The piano features advanced Damper Resonance for realistic sound.
- **Soft Pedal (Left):** Softens the sound.
- **Sostenuto Pedal (Middle):** Sustains only the notes held down at the moment the pedal is pressed.

Concert Play

Engage the Concert Play feature to play along with pre-recorded orchestral performances. Detailed instructions for selecting and playing along with Concert Play tracks are available in the comprehensive manual.

Casio Music Space App

Enhance your learning and playing experience by connecting your piano to the Casio Music Space app via USB. The app offers interactive lessons, score viewing, and additional features. Download the app from your device's app store and follow the in-app instructions for connection.

MAINTENANCE

- Cleaning:** Use the provided polishing cloth or a soft, dry cloth to wipe the piano's surface. For stubborn dirt, slightly dampen the cloth with water and wipe gently, then dry immediately. Avoid abrasive cleaners, waxes, or solvents.
- Key Care:** Wipe the keys with a soft, dry cloth. Do not use chemical cleaners on the keys as they may damage the simulated ebony and ivory finish.
- Storage:** When not in use for extended periods, cover the piano to protect it from dust. Store in a stable environment, away from direct sunlight, extreme temperatures, and high humidity.
- Power Off:** Always turn off the piano and unplug the AC adapter when not in use or during electrical storms.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound from speakers/headphones.	Volume too low; AC adapter not connected; headphones not fully inserted.	Increase VOLUME knob; ensure AC adapter is securely connected; re-insert headphones firmly.
Keys feel unresponsive or sticky.	Dust or debris under keys; environmental factors (humidity).	Gently clean around keys with a soft brush; ensure piano is in a stable environment. If problem persists, contact support.
Piano does not power on.	AC adapter not connected or faulty; power outlet issue.	Check AC adapter connection to piano and wall outlet; try a different power outlet.
Sound is distorted or noisy.	Volume too high; external interference; faulty cable.	Lower volume; move piano away from other electronic devices; check headphone/audio cables.

For issues not listed here, please refer to the comprehensive troubleshooting section in the full user manual or contact Casio customer support.

SPECIFICATIONS

- Model Name:** CELVIANO
- Item Model Number:** CAS-AP270BN-COMBO-PRO
- Number of Keys:** 88
- Keyboard Type:** Tri-sensor Scaled Hammer Action Keyboard II
- Sound Source:** Multi-dimensional Morphing AiR Sound Source
- Color:** Brown
- Product Dimensions:** 60 x 17 x 23 inches

- **Power Source:** AC adapter
- **Headphones Jack:** 3.5mm Jack
- **Connectivity Technology:** Auxiliary, USB
- **Supported Software:** Casio Music Space
- **Skill Level:** Beginner
- **Age Range:** Adult

WARRANTY AND SUPPORT

For detailed warranty information, please refer to the warranty card included with your product or visit the official Casio website. Casio provides comprehensive support for its products.


- **Online Lessons:** Register on the Casio website to unlock one free month of access to Playground Sessions, offering step-by-step lessons for learning your favorite songs.
- **Casio Music Space App:** Utilize the Casio Music Space app for additional learning resources and interactive features.
- **Customer Service:** For technical assistance or service inquiries, please contact Casio customer support through their official website or the contact information provided in your product documentation.



Always ensure you are using official Casio resources for support and information.

© 2024 Casio Computer Co., Ltd. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

Related Documents - AP-270 CELVIANO

 CELVIANO AP-550 GUÍA DEL USUARIO AP-S450 PT	<p>Guia do Usuário CASIO AP-550 e AP-S450: Configuração e Funções</p> <p>Guia do usuário completo para os pianos digitais CASIO CELVIANO AP-550 e AP-S450. Aprenda a configurar, operar, usar efeitos, gravar e conectar seu instrumento. Inclui informações sobre o aplicativo CASIO MUSIC SPACE.</p>
 CELVIANO AP-550 GUÍA DEL USUARIO AP-S450 ES	<p>Ceviano AP-550 y AP-S450: Guía del Usuario</p> <p>Guía del usuario completa para los pianos digitales Casio Celviano AP-550 y AP-S450, cubriendo configuración inicial, operación, efectos de sonido, grabación y solución de problemas.</p>

	<p>CASIO AP-300 AP-S200 User's Guide</p> <p>User's Guide for the CASIO AP-300 and AP-S200 digital pianos, covering setup, playing features, sound settings, recording, connectivity, and troubleshooting.</p>
	<p>CASIO CELVIANO AP-460 User's Guide</p> <p>Explore the features and functions of the CASIO CELVIANO AP-460 digital piano with this comprehensive user's guide. Learn about setup, tone selection, recording, and more. Visit CASIO for support.</p>
	<p>CASIO AP-750 Guía del Usuario: Piano Digital</p> <p>Explore el piano digital CASIO AP-750 con esta completa guía del usuario. Aprenda sobre la configuración, funciones, técnicas de interpretación, grabación y conectividad para una experiencia musical mejorada.</p>
	<p>Manuale Utente Pianoforte Digitale CASIO CELVIANO AP-550 e AP-S450</p> <p>Guida completa per configurare, suonare e sfruttare tutte le funzioni del pianoforte digitale CASIO CELVIANO AP-550 e AP-S450, inclusi suoni, effetti, registrazione e connettività.</p>