

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Nerf](#) /

› [Nerf Roblox Build A Boat for Treasure: Spacelock Ray Blaster User Manual](#)

## Nerf F7595

# Nerf Roblox Build A Boat for Treasure: Spacelock Ray Blaster Instruction Manual

Model: F7595

## PRODUCT OVERVIEW

---

The Nerf Roblox Build A Boat for Treasure: Spacelock Ray Blaster is inspired by the popular Roblox experience 'Build A Boat For Treasure' by Chillz Studios. This dart blaster features a futuristic ray gun design and an 8-dart rotating drum, allowing for rapid firing. It is designed for both indoor and outdoor play and includes 8 Nerf Elite foam darts. A special code for an exclusive virtual item on Roblox is also included with the blaster.



Image: The Nerf Roblox Spacelock Ray Blaster, showcasing its red and green design, along with the included 8 green Nerf Elite darts.

## WHAT'S IN THE BOX

---

- 1 x Nerf Roblox Build A Boat for Treasure: Spacelock Ray Blaster
- 8 x Nerf Elite Darts
- 1 x Exclusive Virtual Item Code for Roblox



Image: The Nerf Roblox Spacelock Ray Blaster shown alongside its retail packaging, illustrating the product as it appears in its box.

## SETUP

- Unpack Contents:** Carefully remove the blaster, darts, and virtual item code from the packaging.
- Load Darts:** Insert one Nerf Elite dart into each of the 8 chambers in the rotating drum. Ensure darts are fully seated.



Image: A close-up view of hands inserting a green Nerf Elite dart into the rotating drum of the Spacelock Ray Blaster.

## OPERATING INSTRUCTIONS

---

- 1. Priming the Blaster:** With darts loaded, firmly pull back the priming handle located at the rear of the blaster until it clicks into place. This action prepares the blaster to fire.
- 2. Aim and Fire:** Point the blaster safely away from faces and eyes. Press the trigger to fire one dart. The drum will automatically rotate to the next dart.
- 3. Continuous Firing:** To fire subsequent darts, repeat the priming and firing steps for each dart until the drum is empty.



Image: A person's hands pulling back the priming handle of the Spacelock Ray Blaster, demonstrating the priming action.



Image: A person holding the Spacelock Ray Blaster in a firing position, aiming forward in an outdoor setting.

## MAINTENANCE

---

- **Cleaning:** Wipe the blaster with a clean, damp cloth as needed. Do not submerge in water.
- **Dart Care:** Use only official Nerf Elite darts. Inspect darts regularly for damage; bent or torn darts can affect performance.
- **Storage:** Store the blaster and darts in a cool, dry place away from direct sunlight to prevent material degradation.

## TROUBLESHOOTING

---

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Dart does not fire or fires weakly.	Blaster not fully primed; dart not fully loaded; damaged dart.	Ensure priming handle is pulled back completely until it clicks. Push dart fully into the drum. Replace damaged darts with new, official Nerf Elite darts.
Dart jams in the blaster.	Damaged dart; foreign object in barrel.	Remove the jammed dart carefully. Inspect the barrel for any obstructions and clear them. Use only undamaged, official Nerf Elite darts.

## SPECIFICATIONS

---

**Product Dimensions:** 2.63 x 16 x 9 inches

**Item Weight:** 1.03 pounds

**Model Number:** F7595

**Manufacturer Recommended Age:** 8 years and up

**Release Date:** April 25, 2023

**Manufacturer:** Hasbro

## SAFETY INFORMATION

---

**WARNING:** Small parts may be generated. Not for children under 3 years.

**EYEWEAR:** Eyewear is recommended for players and people within range. Do not modify darts or blaster.

**DO NOT AIM AT EYES OR FACE.**

## WARRANTY AND SUPPORT

---

For information regarding product warranty, returns, or technical support, please refer to the official Hasbro or Nerf website, or contact their customer service directly. Specific warranty details may vary by region and retailer.

© 2023 Hasbro. All Rights Reserved. ROBLOX is a registered trademark.