

[Manuals.plus](#) /

› [Pretty Love](#) /

› Pretty Love Piper Double Pulsation Vibe User Manual

Pretty Love DEDEBRA01505

Pretty Love Piper Double Pulsation Vibe User Manual

Model: DEDEBRA01505

1. INTRODUCTION

Thank you for choosing the Pretty Love Piper Double Pulsation Vibe. This device is designed to provide targeted stimulation through its dual vibration and pulsation functions. This manual contains important information regarding the safe and effective use, maintenance, and care of your device. Please read it thoroughly before first use and retain it for future reference.

2. SAFETY INFORMATION

- **Consult a Physician:** If you have any health concerns, pre-existing medical conditions, or are pregnant, consult a healthcare professional before using this device.
- **Hygiene:** Always clean the device thoroughly before and after each use to maintain hygiene.
- **Lubrication:** For comfortable use, apply a generous amount of water-based lubricant. Do not use silicone-based lubricants as they may damage the silicone material of the device.
- **Damage Inspection:** Do not use the device if it appears damaged or if the silicone material is torn or compromised.
- **Storage:** Keep the device out of reach of children and pets.
- **Water Exposure:** While the device is waterproof, avoid prolonged submersion, especially when the charging port is exposed or not properly sealed.

3. PRODUCT OVERVIEW

The Pretty Love Piper is a personal massager featuring a curved design with two distinct stimulation points. It incorporates both vibration and pulsation functions, each with multiple settings, to provide varied sensations. The device is made from body-safe silicone and ABS plastic, and is USB rechargeable.



Image 1: Pretty Love Piper Double Pulsation Vibe and its packaging. The device is purple with a curved shape, designed for dual stimulation. The packaging highlights key features like USB rechargeability and multiple functions.

Key Components:

- **Main Body:** Ergonomically shaped silicone for comfortable handling and insertion.
- **Control Panel:** Located at the base, typically includes a power button, a vibration control button, and a pulsation control button.
- **Charging Port:** A small port, usually located near the control panel, for connecting the USB charging cable.

4. SETUP

Initial Charging:

1. Locate the charging port on the device, typically covered by a silicone flap for waterproofing.

2. Insert the small end of the provided USB charging cable into the device's charging port.
3. Connect the larger USB end of the cable to a compatible USB power source (e.g., computer USB port, USB wall adapter).
4. Allow the device to charge fully before its first use. Charging indicators (e.g., an LED light) will typically show charging status and completion.



Image 2: The Pretty Love Piper device shown with its USB charging cable. An arrow points to the DC charging port located on the base of the device, indicating where the cable should be connected for recharging.

Preparation for First Use:

- Before the first use, and after each subsequent use, clean the device as described in the Maintenance section.

5. OPERATING INSTRUCTIONS

The Pretty Love Piper features intuitive controls for easy operation.

1. **Power On/Off:** Press and hold the power button (usually marked with a power symbol) for 2-3 seconds to turn the

device on or off.

- 2. **Vibration Control:** Once powered on, press the vibration button (often marked with a wave or vibration symbol) to cycle through the 12 distinct vibration patterns. Each press will advance to the next pattern.
- 3. **Pulsation Control:** Similarly, press the pulsation button (if separate, or the same button if combined) to cycle through the 12 pulsation settings.
- 4. **Combined Functions:** You can activate both vibration and pulsation functions simultaneously to experience a wider range of sensations. Experiment with different combinations to find your preferred settings.

6. MAINTENANCE

Proper care and maintenance will extend the lifespan of your Pretty Love Piper.

Cleaning:

- After each use, wash the device with warm water and a mild, antibacterial soap.
- Rinse thoroughly to remove all soap residue.
- Pat dry with a lint-free cloth or allow it to air dry completely before storing.
- Do not use harsh chemicals, alcohol-based cleaners, or petroleum-based products, as these can damage the silicone.

Storage:

- Store the device in a clean, dry, and cool place.
- Keep it away from direct sunlight and extreme temperatures.
- Avoid storing with other toys made of different materials to prevent material degradation.

7. TROUBLESHOOTING

If you encounter any issues with your device, refer to the following common solutions:

- **Device not turning on:** Ensure the device is fully charged. Press and hold the power button firmly for 2-3 seconds.
- **Weak vibration/pulsation:** The battery may be low. Recharge the device fully.
- **Device not charging:** Check that the USB cable is securely connected to both the device and the power source. Try using a different USB port or wall adapter. Ensure the charging port on the device is clean and free of debris.
- **Unresponsive buttons:** Ensure the device is not locked (if a lock function exists, though not specified for this model). If the issue persists after charging, contact customer support.

8. SPECIFICATIONS

Model Number	DEDEBRA01505
Brand	Pretty Love
Material	Acrylonitrile Butadiene Styrene (ABS), Silicone
Functions	12 Vibration settings, 12 Pulsation settings
Power Source	USB Rechargeable
Water Resistance Level	Waterproof
Approximate Dimensions	7.87 x 5.91 x 3.94 inches

Approximate Weight	7.68 ounces
--------------------	-------------

9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the product packaging or contact the retailer from whom you purchased the device. Keep your proof of purchase for any warranty claims.

© 2023 Pretty Love. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BS62PVBFB>

More documents and user manuals: <https://manuals.plus/>