

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko 4 Pieces Patio Furniture Set User Manual

Devoko DVC2268-BG

Devoko 4 Pieces Patio Furniture Set User Manual

Model: DVC2268-BG | Brand: Devoko

INTRODUCTION

This manual provides essential information for the assembly, operation, maintenance, and care of your Devoko 4 Pieces Patio Furniture Set. Designed for outdoor use, this set features a durable metal frame, weather-resistant acacia wood accents, and comfortable, thick cushions. Please read this manual thoroughly before assembly and use to ensure proper setup and longevity of your furniture.



Image: The complete Devoko 4 Pieces Patio Furniture Set, featuring two single chairs, a two-seater sofa, and a coffee table, all with grey cushions and acacia wood armrest details.

The set includes:

- 2 x Single Chairs
- 1 x Twin Chair (Sofa)
- 7 x Cushions (for seats and backs)

- 1 x Coffee Table

SETUP AND ASSEMBLY

Your Devoko patio furniture set arrives in two packages. Careful assembly is required. It is recommended to have two people for assembly to ensure stability and ease of construction. Please refer to the detailed [Installation Manual \(PDF\)](#) for step-by-step instructions.

Package Contents and Dimensions

- **Package 1:** Dimensions: 45"(L) x 24"(W) x 16"(H), Weight: 70 lbs
- **Package 2:** Dimensions: 27"(L) x 25"(W) x 16"(H), Weight: 44 lbs



4 Piece Patio Furniture Sets



Image: Detailed dimensions for the two single chairs, the twin chair (sofa), and the coffee table, indicating their respective lengths, widths, and heights.

Assembly Guidelines

- Unpack all components and verify against the parts list in the PDF manual.
- Lay out all parts on a soft, clean surface to prevent scratches.
- Do not fully tighten screws until all components are loosely assembled. This allows for adjustment and proper alignment.
- Be aware of sharp edges and small parts during assembly. Keep small parts away from children.
- Ensure all connections are secure before using the furniture.

OPERATING INSTRUCTIONS

The Devoko 4 Pieces Patio Furniture Set is designed for comfortable outdoor relaxation and conversation. Its ergonomic design, including a slightly tilted backrest, provides optimal support.



Image: The Devoko patio furniture set positioned on an outdoor rug, demonstrating its suitability for various outdoor scenes.

Usage Recommendations

- Place the furniture on a flat, stable surface to prevent wobbling.
- Arrange the single chairs, sofa, and coffee table to create your desired conversation area.
- The thick, skin-friendly cushions provide enhanced comfort for extended periods of sitting.
- The coffee table is suitable for holding beverages, books, or small decorative items.
- This set is ideal for various outdoor environments such as patios, balconies, gardens, and poolside areas.

Modern & Comfortable

Suitable for any outdoor space, such as balconies, porches, patio, living room.....



■ Skin-friendly



■ Elastic

Image: A close-up view of the thick, grey cushion, emphasizing its soft and elastic texture, suitable for comfortable seating.

MAINTENANCE AND CARE

Proper maintenance ensures the longevity and appearance of your Devoko patio furniture set. The materials are selected for durability and weather resistance.



Image: An infographic illustrating key features such as the sturdy and durable frame, UV protection for cushions, waterproof fabric, and secure cushion fastenings.

Frame Care

- The metal frame features a rust-resistant powder coating. To clean, wipe with a dry cloth.
- Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- Periodically check all bolts and screws to ensure they remain tight. Retighten as necessary.

Wood Care

- The acacia wood accents are weather-resistant. Clean with a dry cloth.
- To maintain the wood's appearance and protect it from prolonged exposure to elements, consider applying a suitable outdoor wood sealant annually.

Cushion Care

- The cushion fabric is skin-friendly, UV protected, and designed to be waterproof and easy to clean.

- For general cleaning, wipe spills with a damp cloth. For deeper cleaning, the cushion covers can be removed and spot cleaned with mild soap and water. Allow to air dry completely.
- Store cushions in a dry place during heavy rain or off-season to prolong their life.

General Care

- Keep the furniture clean and dry to prevent damage from weather elements.
- During extreme weather conditions (heavy rain, snow, strong winds), it is advisable to cover the furniture or store it indoors.
- Always supervise children while they are using the furniture to prevent injuries.

TROUBLESHOOTING

This section addresses common issues you might encounter with your patio furniture set.

Assembly Issues

- **Screws not fitting or misaligned holes:** Ensure all parts are correctly oriented according to the instruction manual. Do not overtighten screws until all components are in place. If a hole seems misaligned, try loosening adjacent screws to allow for slight adjustment. If the issue persists, contact customer support.
- **Missing parts:** Carefully check all packaging materials. If parts are genuinely missing, contact customer support with your product model and a description of the missing components.

Stability Issues

- **Wobbling furniture:** Ensure the furniture is placed on a flat, even surface. Check that all assembly bolts and screws are securely tightened.

Damage Upon Arrival

- **Scratches or dents:** If the product arrived with significant damage, document it with photos and contact customer support immediately for assistance.

SPECIFICATIONS

Feature	Detail
Brand	Devoko
Model Number	DVC2268-BG
Color	Grey
Size	4 Piece set
Material	Steel, Acacia Wood, CD Fabric
Product Dimensions (L x W x H)	45 x 24 x 16 inches (Overall)
Item Weight	118 pounds
Product Care Instructions	Wipe with Dry Cloth

Cushion Thickness	Up to 4 inches
-------------------	----------------

WARRANTY AND SUPPORT

While specific warranty details are not provided in this manual, Devoko is committed to customer satisfaction. Optional protection plans may be available for purchase separately to extend coverage beyond any standard manufacturer's warranty.

Customer Support

For any questions, concerns, or assistance with your Devoko patio furniture set, please contact Devoko customer support via Amazon. We aim to respond to all inquiries within 24 hours.

You can also visit the official [Devoko Store on Amazon](#) for more product information and support resources.

© 2025 Devoko. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question