

[Manuals.plus](#) /

› [Devoko](#) /

› Devoko Home Acacia Wood Dining Table Instruction Manual

Devoko DEVOKO213D6

Devoko Home Acacia Wood Dining Table Instruction Manual

Model: DEVOKO213D6

PRODUCT OVERVIEW

The Devoko Home Acacia Wood Dining Table is a versatile and sturdy furniture piece designed for both indoor and outdoor use. Crafted from natural acacia wood with robust iron legs, this table offers a blend of rustic charm and modern design. It comfortably accommodates up to 6 people, making it ideal for family meals and entertaining guests. The tabletop features a sandblast finish and natural staining, enhancing its aesthetic appeal and durability.



Image: The Devoko Acacia Wood Dining Table set up in a dining room, showcasing its natural wood finish and sturdy design.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- Assembly requires tools and may pose safety risks. Exercise caution during the assembly process.
- Ensure all bolts and screws are securely tightened before using the table. Periodically check and re-tighten fasteners as needed.
- Do not exceed the maximum weight recommendation of 150 pounds on the tabletop.
- This product is a table only; chairs are not included and are shown for display purposes only.
- Keep small parts and packaging materials away from children to prevent choking hazards.

PARTS LIST

Before beginning assembly, ensure all parts listed below are present. If any parts are missing or damaged, please contact customer support.

Part	Description	Quantity
A	Acacia Wood Tabletop	1
B	Iron Legs	4
C	Hardware Pack (Screws, Washers, Allen Wrench)	1
D	Assembly Guide	1




Image: A diagram illustrating the dimensions of the table: 69 inches long, 33 inches wide, and 30 inches high.

SETUP AND ASSEMBLY

Assembly of the Devoko dining table is designed to be straightforward and can typically be completed by one person in approximately 10 minutes. An assembly guide is included in the package.

- Unpack Components:** Carefully remove all parts from the packaging and lay them out on a soft, clean surface to prevent scratches. Verify all parts from the Parts List are present.
- Attach Legs:** Align each iron leg (Part B) with the designated mounting points on the underside of the acacia wood tabletop (Part A).
- Secure with Hardware:** Use the provided screws and an Allen wrench from the Hardware Pack (Part C) to firmly attach the legs to the tabletop. Ensure all connections are tight and secure.
- Upright the Table:** With assistance if necessary due to the table's weight (approx. 75.3 lbs), carefully flip the table upright onto its legs.
- Final Check:** Gently push on the table to ensure it is stable and does not wobble. Re-tighten any loose fasteners if needed.



Image: A close-up view of the flexible folding hinges, indicating the table's design for potential compact storage or assembly.

OPERATING INSTRUCTIONS

The Devoko dining table is designed for straightforward use as a dining or utility surface. No complex operations are required.

- Place the table on a flat, stable surface to ensure proper balance and prevent tipping.
- Distribute weight evenly across the tabletop to avoid undue stress on any single point.
- When moving the table, lift it rather than dragging to prevent damage to the legs or floor.
- For outdoor use, consider placing the table on a level patio or deck.

MAINTENANCE

Proper maintenance will extend the life and preserve the appearance of your Devoko dining table.

- **Cleaning:** The tabletop is treated for resistance and is easy to clean. Wipe stains with a wet rag. Avoid abrasive cleaners or harsh chemicals that could damage the wood finish.
- **Outdoor Protection:** If the table is left outdoors for extended periods, it is highly recommended to cover it when not in use and periodically oil the wood to protect its gloss and prevent weathering.
- **Wood Care:** Acacia wood is durable, but like all natural wood, it can be affected by extreme temperature changes and humidity. Avoid placing hot items directly on the surface without protection.
- **Legs:** The painted steel pipe legs are designed for durability. Clean with a damp cloth as needed.



Image: The Devoko dining table positioned outdoors by a pool, emphasizing its strong weathering resistance and the benefit of covering it for extended life.

Troubleshooting

If you encounter any issues with your Devoko dining table, refer to the following common solutions:

Problem	Possible Cause	Solution
Table wobbles after assembly.	Loose fasteners or uneven floor.	Ensure all screws are tightened. If on an uneven surface, use shims under the legs to stabilize.
Surface appears dull or dry (outdoor use).	Lack of oiling or prolonged exposure to elements.	Apply a suitable wood oil designed for outdoor furniture. Consider using a protective cover.
Scratches or minor dents on wood.	Normal wear and tear or impact.	For minor scratches, wood repair kits or furniture markers can be used. For deeper damage, professional repair may be needed.

Specifications

Feature	Detail
Brand	Devoko
Model Name	Home Acacia Wood Dining Table
Model Number	DEVOKO213D6
Product Dimensions	69"W x 33"D x 30"H (175.26 cm W x 83.82 cm D x 76.2 cm H)
Item Weight	75.3 Pounds (34.16 kg)
Maximum Weight Recommendation	150 Pounds (68.04 kg)
Seating Capacity	6 Persons
Top Material Type	Acacia Wood
Frame Material Type	Metal (Iron Legs)
Finish Types	Sandblast Finish, Natural Stained, Painted (legs)
Indoor/Outdoor Usage	Indoor, Outdoor
Recommended Tools for Assembly	Screw Driver (Allen wrench included)

Warranty and Support

For information regarding product warranty, returns, or technical support, please refer to the documentation included with your purchase or contact Devoko customer service directly. Keep your purchase receipt for warranty claims. You can also visit the official Devoko store on Amazon for more information:[Devoko Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BS6C9CMG>

More documents and user manuals: <https://manuals.plus/>