

[Manuals.plus](#) /

› [ODK](#) /

› ODK 40 Inch L-Shaped Computer Desk Instruction Manual

ODK B01XS011501

ODK 40 Inch L-Shaped Computer Desk Instruction Manual

Model: B01XS011501



Official ODK Product

1. INTRODUCTION

Thank you for choosing the ODK 40 Inch L-Shaped Computer Desk. This manual provides essential information for the safe assembly, operation, and maintenance of your new desk. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image 1.1: The ODK 40 Inch L-Shaped Computer Desk, designed for home office and study use.

2. SAFETY INFORMATION

To ensure safe use and prevent injury or damage, please adhere to the following safety guidelines:

- Always assemble the desk according to the provided instructions.
- Ensure the desk is stable and properly positioned on a level surface to prevent tipping.
- Do not exceed the maximum weight recommendation of 110 pounds (50 kg) for the desk surface.
- Keep small parts and packaging materials away from children to avoid choking hazards.
- Regularly check all fasteners to ensure they remain tight.

3. PACKAGE CONTENTS

Before assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Desk Panels (L-shaped main desktop, shelf panels)
- Metal Frame Components
- Hardware Kit (screws, bolts, Allen wrench)
- Adjustable Non-slip Foot Pads
- Desk Organizer (side storage bag)
- PC Stand (integrated into shelf design)
- Instruction Manual



Image 3.1: The desk includes a convenient side storage bag for small items.



Image 3.2: Detail of the integrated two-tier open shelves and PC stand area.

4. SETUP AND ASSEMBLY

Assembly of the ODK L-Shaped Computer Desk is designed to be straightforward. Follow the step-by-step instructions provided in the included manual. All parts are clearly labeled to assist with identification.

4.1 Reversible Configuration

The L-shaped design allows for the storage shelves and PC stand to be configured on either the left or right side of the main desktop, depending on your preference and room layout. Carefully review the assembly steps to select your desired orientation before securing components.

4.2 Assembly Tips

- Clear a spacious area for assembly.
- Lay out all parts and hardware before starting.
- Do not overtighten screws until all components are loosely assembled, then tighten fully.
- Ensure the adjustable non-slip foot pads are properly installed and adjusted to level the desk on uneven floors.



Image 4.1: Dimensional diagram of the ODK L-Shaped Computer Desk, useful for planning your space.

5. OPERATING INSTRUCTIONS

The ODK L-Shaped Computer Desk is designed for versatile use in various settings, including home offices, bedrooms, and study areas.

5.1 Desktop Usage

The spacious desktop provides ample room for computers, monitors, keyboards, and other work or study essentials. Arrange your setup to maximize comfort and efficiency.

5.2 Storage Shelves and PC Stand

Utilize the two-tier open shelves for storing books, files, office supplies, or decorative items. The dedicated PC stand area is designed to accommodate your computer tower, keeping it off the floor and easily accessible.



Image 5.1: An overhead view demonstrating the ample desktop space for a complete workstation setup.

6. MAINTENANCE

Proper care will extend the life and appearance of your ODK L-Shaped Computer Desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent moisture damage to the engineered wood.
- **Protection:** Use coasters for drinks and mouse pads to protect the desktop surface from scratches and heat.
- **Inspection:** Periodically check all screws and connections to ensure they are secure.



Image 6.1: Close-up of the desk's engineered wood surface with a black wood grain finish.

7. TROUBLESHOOTING

If you encounter any issues with your ODK L-Shaped Computer Desk, refer to the following common solutions:

- **Desk Wobbles:** Ensure all screws are tightened. Adjust the non-slip foot pads on the bottom of the desk legs to compensate for uneven flooring.
- **Missing Parts:** If any parts were missing upon delivery, please contact ODK customer support with your purchase details.
- **Difficulty Assembling:** Double-check the instruction manual to ensure all steps are followed correctly. Some parts may require firm but gentle pressure to align.
- **Surface Scratches:** While the desk is designed to be scratch-resistant, heavy objects or sharp items can cause damage. Consider using protective mats for high-traffic areas.



Image 7.1: Adjustable non-slip foot pads help stabilize the desk on uneven surfaces.

8. SPECIFICATIONS

Feature	Specification
Brand	ODK
Model Number	B01XS011501
Shape	Rectangular (L-shaped configuration)
Product Dimensions (D x W x H)	40"D x 29.1"W x 29.5"H
Color	Black

Style	Modern
Base Material	Metal (Alloy Steel)
Top Material Type	Engineered Wood
Finish Type	Powder Coated
Special Feature	L-shaped, Reversible Storage Shelves
Recommended Uses	Writing, Working, Studying
Maximum Weight Recommendation	110 Pounds (50 kg)
Number Of Shelves	2 (open shelves)
Item Weight	30.8 Pounds (14 kg)
Required Assembly	Yes

9. WARRANTY INFORMATION

This ODK product comes with a **Limited Warranty**. For specific details regarding warranty coverage, terms, and conditions, please refer to the warranty card included with your purchase or contact ODK customer support.

10. CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact ODK customer support. Our team is available to help resolve any issues you may encounter.

Please have your model number (B01XS011501) and purchase information ready when contacting support.

For more information, you may visit the official ODK store on Amazon:[ODK Store](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BS6GQ4CW>

More documents and user manuals: <https://manuals.plus/>