

[Manuals.plus](#) /

› [Aqua Joe](#) /

› Aqua Joe Telescoping Sprinkler & Mister User Manual

Aqua Joe AJ-6PSTB-XL

Aqua Joe Telescoping Sprinkler & Mister

MODEL: AJ-6PSTB-XL

Your guide to efficient and versatile watering.

Introduction

Thank you for choosing the Aqua Joe Telescoping Sprinkler & Mister. This manual provides detailed instructions for the proper setup, operation, maintenance, and troubleshooting of your new watering device. Designed for durability and versatility, this sprinkler features a robust metal tripod base, six adjustable spray patterns, and a flow control valve to ensure optimal coverage for areas up to 4,900 square feet.





The Aqua Joe Telescoping Sprinkler and Mister, fully assembled and ready for use.

Setup

Follow these steps to set up your Aqua Joe Telescoping Sprinkler & Mister:

1. **Unpack Components:** Carefully remove all components from the packaging. Ensure you have the telescoping sprinkler head, tripod base, and any included accessories.
2. **Assemble Tripod Base:** Extend the legs of the tripod base until they are fully splayed. The base is designed for stability; ensure it rests firmly on a flat surface. For added stability on soft ground, gently push the spiked feet into the soil.
3. **Attach Sprinkler Head:** Securely screw the telescoping sprinkler head onto the top of the tripod base. Hand-tighten to ensure a snug fit without over-tightening.
4. **Connect Water Hose:** Attach your standard garden hose to the flow control valve at the base of the sprinkler. Ensure the connection is tight to prevent leaks. The integrated flow control valve allows for precise water management.

WATER YOUR WAY!

AQUAJOE®

**INDESTRUCTIBLE 6-PATTERN
TURBO DRIVE 360°
TELESCOPING
SPRINKLER**

**With Metal Tripod Base
& Flow Control Valve**

Perfect solution to keep your
garden lush and your lawn
healthy all season long



**SUPERIOR
DURABILITY**

Durable metal build
with strong base for
lasting use



**6 SPRAY
PATTERNS**

Flat, fan, mist, large,
multi and mini



**360° WATERING
COVERAGE**

Provides a maximum
flow rate of 9.3 GPM



**TELESCOPING
TRIPOD**

Extends from 37.5" to
51.7" for a coverage area
of up to 4,900 sq ft

The Aqua Joe sprinkler in operation, demonstrating its reach and coverage in a garden environment.

WATER YOUR WAY!

Telescoping Tripod

Extends from 37.5" to 51.7"
for a coverage area of up to
4,900 sq ft

AQUAJOE

A hand adjusting the flow control valve on the sprinkler's hose connection, ensuring a leak-resistant seal.

Operating Instructions

Your Aqua Joe sprinkler offers versatile controls for customized watering:

- **Telescoping Height Adjustment:** The sprinkler's height can be adjusted from 37.5 inches to 51.7 inches. Loosen the locking collar on the telescoping pole, extend or retract to the desired height, and then tighten the collar to secure. This allows for optimal water distribution over various plant heights and coverage areas.
- **Flow Control Valve:** Use the blue lever on the hose connection to control the water flow. Turn it to the 'ON' position for maximum flow (up to 9.3 GPM) or 'OFF' to stop the water. This valve also helps prevent leaks.
- **Spray Pattern Selection:** The sprinkler head features six distinct spray patterns: Flat, Fan, Large, Multi, Mini, and Mist. Rotate the pattern selector dial on the sprinkler head to choose the desired pattern.
- **Coverage Control:** Adjust the blue ring on the sprinkler head to set the desired watering arc, from partial to a full 360-degree rotation. This ensures precise watering without wasting water on unwanted areas.

- **Distance Control:** Use the distance control knob to adjust the range of the water spray. This allows you to fine-tune the watering area to suit your specific needs.

WATER YOUR WAY!



Coverage Control



On/Off Flow Control



Distance Control



Pattern Control

Turbo Drive 360°

Rotating head ensures full, even coverage every time

AQUAJOE®

Close-up view of the sprinkler's control mechanisms: Coverage Control, On/Off Flow Control, Distance Control, and Pattern Control.

WATER YOUR WAY!

AQUAJOE

FLOW CONTROL

Provides a maximum flow rate of 9.3 GPM

TURBO DRIVE 360° TELESCOPING SPRINKLER

Rotating head covers partial to full circle

6 ADJUSTABLE SPRAY PATTERNS

Flat, fan, large, multi, mini, mist—versatile watering for every garden.

TELESCOPING HEIGHT ADJUSTMENT

From 37.5" to 51.7" for a coverage area of up to 4,900 sq ft

LENGTH

5.5"

13.97 CM

WIDTH

4.75"

12.06 CM

HEIGHT

29"

73.66 CM

GROSS WEIGHT

3.8

LBS.

Visual representation of the six distinct spray patterns available: Flat, Fan, Mist, Large, Multi, and Mini.

WATER YOUR WAY!



Flat



Fan



Mist



Large



Multi



Mini

6 Spray Patterns

Customize your spray to suit various terrain types

AQUAJOE®

The sprinkler providing 360-degree watering coverage in a lawn setting, ensuring even water distribution.

WATER YOUR WAY!

360° Watering Coverage

Rotating head covers partial to full circle for even watering over a large range every time

AQUAJOE®

The telescoping tripod extended, illustrating its adjustable height feature for varied coverage.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your sprinkler:

- **Cleaning:** Periodically inspect the sprinkler nozzles for any debris or mineral buildup. Use a soft brush or a small pin to clear any blockages. Rinse the exterior with clean water.
- **Hose Connection:** Regularly check the hose connection for wear and tear. Replace washers if necessary to maintain a leak-free seal.
- **Winter Storage:** Before the first frost, disconnect the sprinkler from the hose. Drain all water from the unit to prevent freezing and potential damage. Store the sprinkler in a dry, protected area away from extreme temperatures.
- **Tripod Stability:** Ensure the tripod legs are clean and free of dirt that could impede their proper extension or retraction.

Troubleshooting

Refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Sprinkler falls over easily.	Tripod not securely planted; uneven ground; strong water pressure.	Ensure spiked feet are pushed firmly into the ground. Place one leg in line with the hose for better balance. Adjust water pressure if too high.
Uneven or weak spray pattern.	Clogged nozzles; low water pressure; incorrect pattern selection.	Clean nozzles of debris. Check water source for adequate pressure. Ensure the correct spray pattern is selected.
Water leaks from connections.	Loose hose connection; worn washer.	Tighten all connections. Inspect and replace rubber washers if they appear worn or damaged.
Sprinkler head does not rotate or sticks.	Debris in mechanism; insufficient water pressure.	Flush the sprinkler head with clean water to dislodge debris. Ensure adequate water pressure is supplied.

Specifications

Key technical specifications for the Aqua Joe Telescoping Sprinkler & Mister:

- **Brand:** Aqua Joe
- **Model Number:** AJ-6PSTB-XL
- **Color:** Blue
- **Material:** Metal
- **Product Dimensions (L x W x H):** 5.5 x 4.75 x 29 inches (collapsed)
- **Adjustable Height:** 37.5 inches to 51.7 inches
- **Item Weight:** 3.79 pounds
- **Maximum Flow Rate:** 9.3 Gallons Per Minute (GPM)
- **Maximum Coverage Area:** Up to 4,900 square feet
- **Spray Patterns:** 6 (Flat, Fan, Large, Multi, Mini, Mist)
- **UPC:** 842470130401

WATER YOUR WAY!

INDESTRUCTIBLE TURBO DRIVE 360° TELESCOPING SPRINKLER & MISTER



**4,900
SQ FT
MAX COVERAGE**

**6
ADJUSTABLE
SPRAY PATTERNS**

AQUAJOE®

Detailed dimensions of the Aqua Joe Telescoping Sprinkler, including length, width, height, and gross weight.

Warranty and Support

Aqua Joe products are designed for quality and reliability. For specific warranty information, please refer to the warranty card included with your purchase or visit the official Aqua Joe website. The 'Go with Joe' brand family is committed to providing innovative and high-quality tools for your home and garden needs.

If you encounter any issues not covered in the troubleshooting section, or require further assistance, please contact Aqua Joe customer support. Contact details can typically be found on the product packaging or the official brand website.

© 2025 Aqua Joe. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question