

[Manuals.plus](#) /

› [5 Surprise](#) /

› 5 Surprise Unicorn Squad Series 7 Instruction Manual - ZURU Model 77451

5 Surprise 77451

5 Surprise Unicorn Squad Series 7 Instruction Manual

Model: 77451

INTRODUCTION

Welcome to the magical world of 5 Surprise Unicorn Squad Series 7! This manual provides essential information for the proper use and care of your collectible unicorn toys. Discover the enchanting color-changing features and unique accessories that make each unicorn special.



Image: Two 5 Surprise Unicorn Squad spheres are displayed. One sphere is open, revealing a pink unicorn figure, a pink comb, a golden accessory, and a small container of slime. The other sphere remains closed.

SAFETY INFORMATION

Warning: Choking hazard – small pieces! Not for children under 3 years.

SETUP AND UNBOXING

Each 5 Surprise Unicorn Squad Series 7 toy comes in a spherical package. To begin, carefully unwrap the outer layers of the sphere. Peel back the sections to reveal the hidden compartments inside. Each compartment contains a surprise accessory or a unicorn figure.





Image: Two 5 Surprise Unicorn Squad spheres are shown within a clear plastic cylindrical package, indicating a 2-pack. The spheres are primarily pink and purple with "Unicorn Squad" branding.

Once all compartments are open, you will find your unicorn figure, various accessories, and a packet of unicorn slime. Assemble any accessories onto your unicorn as desired.



Image: A wide shot displaying multiple 5 Surprise Unicorn Squad figures, each with unique accessories like combs, headpieces, and small items. A closed sphere is also visible in the center.

OPERATING INSTRUCTIONS

Magic Color Change Feature

To activate the magical color-changing power of your unicorn, immerse the figure in cold water. Observe as the unicorn's colors transform. This feature is reversible; the colors will return to their original state when the unicorn warms up.



Image: A child's hand gently places a unicorn figure into a clear glass bowl filled with water, demonstrating the color-change activation.



Image: A hand holds a unicorn figure, which has visibly changed color after being submerged in water, above a clear glass bowl.

Styling and Play

Use the included comb to brush your unicorn's hair. Mix and match the interchangeable accessories with other Unicorn Squad figures to create unique styles. The super stretchy unicorn slime can be played with separately or incorporated into imaginative play scenarios with your unicorns.



Image: Three children are seated at a table, actively engaged in playing with their 5 Surprise Unicorn Squad figures and various accessories, including combs and small decorative items.



Image: A smiling child stands behind a display of numerous 5 Surprise Unicorn Squad figures, showcasing a complete collection of the toys.

PRODUCT DEMONSTRATION

Watch the official product demonstration video to see the 5 Surprise Unicorn Squad Series 7 in action, including the unboxing process and the color-change feature.

Your browser does not support the video tag.

Video: Official ZURU LLC demonstration of the 5 Surprise Unicorn Squad Series 7, highlighting the unboxing and color-changing features of the unicorns.

SPECIFICATIONS

- **Product Dimensions:** 3.35 x 3.35 x 3.35 inches
- **Item Weight:** 8.5 ounces
- **Item Model Number:** 77451
- **Manufacturer Recommended Age:** 36 months - 15 years

- **Manufacturer:** ZURU
- **Release Date:** July 3, 2023

MAINTENANCE

To maintain the color-changing properties and overall condition of your unicorns, ensure they are kept clean and stored in a dry environment when not in use. Avoid prolonged exposure to extreme temperatures.

© 2023 5 Surprise. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BS8GV65C>

More documents and user manuals: <https://manuals.plus/>