

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Dolphin](#) /

› [Dolphin KaraokeBox 380: Triple 8" Bluetooth Party Speaker Instruction Manual](#)

Dolphin KP-380

Dolphin KaraokeBox 380 Instruction Manual

Model: KP-380

Brand: Dolphin

INTRODUCTION

Welcome to the Dolphin KaraokeBox 380. This powerful triple 8-inch Bluetooth party speaker is designed to deliver exceptional sound and an immersive audio experience. Featuring a long-lasting rechargeable battery, dynamic LED lights, and versatile connectivity options, the KP-380 is perfect for any gathering or personal entertainment. This manual provides detailed instructions to help you set up, operate, and maintain your speaker for optimal performance.

WHAT'S IN THE BOX

- Dolphin KaraokeBox 380 Speaker
- Charging Cable
- Wireless Microphone (requires 2x AA batteries, not included)
- Remote Control (requires batteries, not included)
- User Manual

RECHARGEABLE PARTY SPEAKER

LED LIGHT | Bluetooth®



The Dolphin KaraokeBox 380 speaker shown with its accompanying accessories, including the wireless microphone, charging cable, and remote control.

SETUP

Initial Charging

Before first use, fully charge the speaker using the provided charging cable. Connect the cable to the DC 15V IN port on the speaker and plug the other end into a power outlet. The charging indicator light will show charging status.

Powering On/Off

Locate the POWER switch on the control panel. Flip the switch to the 'ON' position to power on the speaker. To power off, flip the switch to the 'OFF' position.

Microphone Setup

Insert 2x AA batteries into the wireless microphone. Turn on the microphone using its power switch. The

microphone will automatically connect to the speaker. Adjust microphone volume using the 'MIC.VOL+' and 'MIC.VOL-' knobs on the control panel.

Remote Control Setup

Insert batteries into the remote control. The remote can be used to control various functions of the speaker from a distance.

This video provides a visual guide to the unboxing and initial setup of the Dolphin KaraokeBox 380 speaker, demonstrating how to connect components and power on the device.

OPERATING INSTRUCTIONS

Bluetooth Pairing

Turn on the speaker. The display will show 'BLUE' indicating Bluetooth mode. On your device, enable Bluetooth and search for 'Dolphin KP-380'. Select it to pair. Once paired, you can stream audio wirelessly.



The speaker features advanced Bluetooth 5.3 technology for stable and efficient wireless audio streaming.

USB/TF Card Playback

Insert a USB drive or TF (micro SD) card into the respective port on the control panel. The speaker will automatically switch to USB/TF mode and begin playing compatible audio files.

FM Radio

Press the 'MODE' button to cycle through input modes until 'FM' is displayed. The speaker will automatically scan and save available FM stations. Use the 'PREV' and 'NEXT' buttons to navigate between stations.

AUX Input

Connect an external audio device (e.g., smartphone, MP3 player) to the 'LINE IN' port using a 3.5mm audio cable. The speaker will automatically switch to AUX mode.



The speaker supports multiple playback options including FM radio, USB, Bluetooth, SD card, and AUX input.

Karaoke Functions

Use the 'MIC.VOL+' and 'MIC.VOL-' knobs to adjust the microphone volume. The 'ECHO+' and 'ECHO-' knobs control the echo effect for vocals. 'TREBLE+' and 'TREBLE-' adjust high frequencies, while 'BASS+' and 'BASS-' adjust low frequencies for overall sound customization.





The speaker's top panel features illuminated controls for volume, echo, treble, and bass, along with various input ports for versatile connectivity.

LED Light Modes

The speaker features interactive LED ring and rim lights with 7 different modes. Press the 'LIGHT' button to cycle through the modes. The lights can be sound-activated or cycle randomly, enhancing the party atmosphere.



The speaker's LED lights can illuminate your space with dynamic colors, creating an engaging visual experience.

This video demonstrates the various LED light modes and sound performance of the Dolphin KaraokeBox 380, showcasing its

visual and auditory capabilities.

WaveSync (TWS) Pairing

To wirelessly connect two KP-380 speakers for an immersive stereo sound experience:

1. Ensure both speakers are powered on and in Bluetooth mode.
2. On one speaker, press and hold the 'WAVESYNC' button. You will hear a confirmation tone.
3. The speakers will automatically search and pair with each other. Once connected, you will hear another confirmation tone.
4. Connect your device to one of the paired speakers via Bluetooth. Audio will now play through both speakers in stereo.

Power Bank Feature

The speaker includes a built-in power bank feature to charge external devices. Connect your device's charging cable to the USB port on the speaker's control panel. The speaker must be powered on for this feature to function.

MAINTENANCE

Cleaning

Wipe the speaker's exterior with a soft, dry cloth. Do not use abrasive cleaners or solvents. Keep the ports free of dust and debris.

Battery Care

To prolong battery life, avoid fully discharging the speaker frequently. Recharge the battery regularly, even if the speaker is not in use for extended periods.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for a long time, charge the battery to about 50% before storage.

Important: This speaker is NOT water resistant. Avoid exposure to liquids, rain, or excessive moisture to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on.	Low battery; Power switch off.	Charge the speaker; Ensure power switch is in 'ON' position.
No sound.	Volume too low; Incorrect input mode; Device not connected.	Increase volume; Press 'MODE' to select correct input; Re-pair Bluetooth or check cable connection.

Problem	Possible Cause	Solution
Bluetooth not connecting.	Speaker not in pairing mode; Device too far; Interference.	Ensure speaker is in 'BLUE' mode; Move device closer; Turn off other Bluetooth devices.
Microphone not working.	Microphone off; Low mic volume; Batteries dead.	Turn on microphone; Increase 'MIC.VOL+'; Replace AA batteries.
LED lights not working.	Lights turned off.	Press the 'LIGHT' button to activate or change modes.
Sound distortion at high volume.	Volume too high; Audio source quality.	Reduce volume; Use a higher quality audio source.

SPECIFICATIONS

Feature	Detail
Model Name	KP-380
Speaker Type	Portable Bluetooth Party Speaker
Woofer Diameter	3 x 8 Inches
Tweeter Diameter	1 Inch
Speaker Max Output Power	120 Watts
Frequency Response	80 Hz
Wireless Technology	Bluetooth 5.3
Battery Capacity	5500 mAh
Input Voltage	12 Volts
Connectivity Protocols	Bluetooth, USB, TF, AUX, FM Radio
Microphone Included	1 Wireless Microphone
LED Lights	7 different modes, sound-activated
Portability	Built-in handle and wheels
Product Dimensions (DxWxH)	14"D x 11"W x 33.4"H
Item Weight	22.1 Pounds
Water Resistance	Not Water Resistant

WARRANTY AND SUPPORT

Limited Warranty


The Dolphin KaraokeBox 380 comes with a limited warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including coverage details and duration.

Customer Support

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please visit the official Dolphin website or contact customer support through the contact information provided on your product packaging or the brand's official online channels.


Related Documents - KP-380

	<p>Bersa Thunder Series Firearms: Safety, Operation, and Maintenance Manual</p> <p>Comprehensive guide for Bersa Thunder Series pistols, including safety rules, operating instructions, technical specifications for Thunder 380, 380 Combat, 22, 380 Plus, and 380 CC models, spare parts, and warranty information.</p>
	<p>Hampton Bay Outdoor Table Lamp Use and Care Guide</p> <p>Comprehensive guide for the Hampton Bay Outdoor Table Lamp (models HDP06661WH, HDP06662BRNAT, HDP06663NAT), covering assembly, care, troubleshooting, and warranty information.</p>
	<p>Hampton Bay Aspenwood Outdoor Table Lamp Use and Care Guide</p> <p>A comprehensive guide for the Hampton Bay Aspenwood Outdoor Table Lamp, covering assembly, safety precautions, care and cleaning, troubleshooting, and warranty information.</p>




[Danfoss KP Pressure Switch Installation Guide](#)

Comprehensive installation guide for Danfoss KP series pressure switches, covering models KP 1, KP 1W, KP 1A, KP 2, KP 4, KP 5, KP 5A, KP 6W, KP 6B, KP 6S, KP 6AW, KP 6AB, KP 6AS, KP 7W, KP 7B, KP 7S. Includes technical specifications, safety precautions, electrical ratings, and mounting instructions.



[Danfoss KP Pressure Switch Installation Guide](#)

Comprehensive installation guide for Danfoss KP series pressure switches, covering models KP 1, KP 1W, KP 1A, KP 2, KP 4, KP 5, KP 5A, KP 6W, KP 6B, KP 6S, KP 6AW, KP 6AB, KP 6AS, KP 7W, KP 7B, KP 7S. Includes technical specifications, wiring diagrams, safety precautions, and mounting instructions.



[Danfoss KP Pressure Switch Installation Guide](#)

Comprehensive installation guide for Danfoss KP series pressure switches (KP 1, KP 1W, KP 1A, KP 2, KP 4, KP 5, KP 5A, KP 6W, KP 6B, KP 6S, KP 6AW, KP 6AB, KP 6AS, KP 7W, KP 7B, KP 7S). Covers specifications, refrigerants, electrical ratings, safety, and mounting.