

Gewa AIR 2.1

GEWA AIR 2.1 Violin Case User Manual

Model: AIR 2.1 (316210003)

Brand: Gewa

1. INTRODUCTION

This manual provides essential information for the proper use, setup, and maintenance of your GEWA AIR 2.1 Violin Case. Designed and manufactured in Germany, this case offers advanced protection for your instrument. Please read these instructions thoroughly to ensure optimal performance and longevity of your case.



Image 1.1: Exterior view of the GEWA AIR 2.1 Violin Case in black high gloss finish, featuring the main handle and side handle.

2. PRODUCT OVERVIEW

2.1 Key Features

- **Optimal Protection:** Constructed with a specially developed thermoplastic shell, offering high resistance to breakage and impact.
- **High Insulation Properties:** Features a thermal conductivity of 0.025 W/mK, providing excellent temperature stability for your instrument.
- **Lightweight Design:** Weighs approximately 2.1 kg (without accessories), ensuring comfortable portability.

- **Secure Interior:** Padded floating storage, patented GEWA swivel arch holder, and flexible bow bridge for instrument and bow security.
- **Convenient Storage:** Includes a removable accessory pocket and a patch sheet music pocket.
- **Ergonomic Carrying:** Equipped with a main handle, a removable side handle, and two removable neoprene backpack straps.
- **Security:** Integrated combination lock for enhanced protection.
- **Quality Construction:** Made in Germany with a black velour inner lining and protective cover.

2.2 Included Components

The GEWA AIR 2.1 Violin Case package includes:

- GEWA AIR 2.1 Violin Case
- 2 Removable Neoprene Backpack Straps
- Removable Accessory Pocket
- Protective Cover (internal)

3. SETUP

3.1 Initial Inspection

Upon receiving your GEWA AIR 2.1 Violin Case, inspect it for any signs of damage during transit. Ensure all latches, hinges, and handles are functioning correctly.

3.2 Setting the Combination Lock

Your case is equipped with a combination lock. Follow these steps to set your personal combination:

1. The lock is factory set to 0-0-0.
2. With the lock open (set to 0-0-0), locate the small reset button (usually recessed and requires a pen tip to press).
3. Press and hold the reset button.
4. While holding the button, set your desired 3-digit combination by rotating the dials.
5. Release the reset button. Your new combination is now set. Test it by scrambling the numbers and then entering your new combination to open the lock.

Important: Remember your combination. GEWA is not responsible for forgotten combinations.

3.3 Attaching Backpack Straps and Side Handle

The two neoprene backpack straps and the side handle are removable. To attach:

- **Backpack Straps:** Locate the D-rings or attachment points on the back and bottom of the case. Securely clip the straps to these points. Adjust the strap length for comfortable carrying.
- **Side Handle:** If not already attached, secure the side handle to its designated attachment points on the side of the case.



Image 3.1: Detail of a strap attachment point, illustrating how backpack straps connect to the case.

4. OPERATING INSTRUCTIONS

4.1 Placing the Violin

Open the case and carefully place your violin into the padded floating storage. Ensure the instrument rests securely without excessive movement. The interior is designed to cradle the violin, minimizing shock.



Image 4.1: Interior of the case, highlighting the padded floating storage for the violin and the bow holders.



Image 4.2: A closer look at the interior padding and instrument support points.

4.2 Securing Bows

The case features a patented GEWA swivel arch holder and a flexible bow bridge. Place your bows into the designated holders and secure them firmly. This design prevents bows from shifting or being damaged during transport.

4.3 Using Accessory Pockets

Utilize the removable accessory pocket for rosin, tuners, or other small items. The patch sheet music pocket provides space for sheet music or documents.



Image 4.3: The removable accessory pocket, ideal for small items.

4.4 Closing and Locking the Case

Before closing, ensure the protective cover is properly placed over your violin. Close the lid firmly and engage all latches. If using the combination lock, scramble the numbers after locking to secure the case.

4.5 Carrying the Case

Choose your preferred carrying method:

- **Main Handle:** For short distances or when carrying by hand.
- **Side Handle:** Provides an alternative grip, especially useful when navigating tight spaces.
- **Backpack Straps:** For hands-free transport, ideal for longer distances. Adjust straps for even weight distribution.



Image 4.4: Detail of the ergonomic main carrying handle.

5. MAINTENANCE

5.1 Exterior Cleaning

The high-gloss thermoplastic shell can be cleaned with a soft, damp cloth. For stubborn marks, a mild, non-abrasive cleaner suitable for plastics can be used. Avoid harsh chemicals or abrasive materials that could scratch the finish.

5.2 Interior Care

The black velour interior can be gently vacuumed or wiped with a lint-free cloth to remove dust and debris. Ensure the interior is dry before closing the case for extended periods, especially if exposed to humidity.

5.3 Hardware Maintenance

Periodically check all latches, hinges, and strap attachments for tightness and proper function. Lubricate hinges with a small amount of silicone spray if they become stiff. Ensure the combination lock operates smoothly.

6. TROUBLESHOOTING

6.1 Combination Lock Issues

- **Lock will not open:** Ensure you are entering the correct 3-digit combination. If you have forgotten it, there is no master key or universal reset. You may need to try combinations or contact a locksmith.
- **Lock feels stiff:** Apply a small amount of graphite powder or silicone spray to the moving parts of the lock mechanism.

6.2 Latches Not Engaging

Check for any obstructions preventing the latches from closing fully. Ensure the lid is properly aligned with the base of the case. If a latch is bent or damaged, contact customer support for assistance.

6.3 Instrument Movement Inside Case

Verify that the violin is correctly seated in the padded floating storage. Ensure all internal straps or supports are properly engaged. If movement persists, consider adding a small, soft cloth for additional cushioning in specific areas.

7. SPECIFICATIONS

Feature	Detail
Model Name	AIR 2.1
Item Model Number	316210003
Brand	Gewa
Body Material	Thermoplastic shell
Finish Type	High gloss
Color	Black
Item Weight (without accessories)	2.1 kg (approx. 4.63 lbs)
Thermal Conductivity	0.025 W/mK
Included Components	Case, 2 Removable Neoprene Backpack Straps, Removable Accessory Pocket, Protective Cover
Manufacturer	GEWA
Origin	Made in Germany

8. WARRANTY INFORMATION

The GEWA AIR 2.1 Violin Case is covered by a manufacturer's warranty against defects in materials and workmanship. Specific warranty terms and duration may vary by region and retailer. Please retain your proof of purchase. For detailed warranty information, please refer to the official Gewa website or contact your authorized Gewa dealer.

9. SUPPORT


For technical assistance, spare parts, or any questions regarding your GEWA AIR 2.1 Violin Case, please contact Gewa customer service or your local authorized Gewa dealer. Contact information can typically be found on the official Gewa website:

[Visit Gewa Official Website](#)




Related Documents - AIR 2.1

	GEWA G3 Drum-Modul Bedienungsanleitung Umfassende Bedienungsanleitung für das GEWA G3 Drum-Modul von GEWA music GmbH. Erfahren Sie mehr über Einrichtung, Funktionen, Sicherheit und technische Details dieses digitalen Schlagzeugmoduls.
	GEWA G3 Setup Rack Assembly Instructions Step-by-step guide for assembling the GEWA G3 Setup Rack, including a detailed parts list and helpful assembly tips.
	GEWA PP-3 Schnellstartanleitung Diese Schnellstartanleitung führt Sie durch die grundlegende Einrichtung und Bedienung Ihres GEWA PP-3 Digitalpianos, einschließlich Sicherheitshinweisen, Anschlüssen und erster Inbetriebnahme.
	GEWA G3 & G5 Drum Module Quick Start Guide Quickly set up and operate your GEWA G3 or G5 Drum Module with this comprehensive guide. Learn about features, safety, connections, and troubleshooting for an enhanced electronic drumming experience.
	Mode d'emploi Piano numérique GEWA UP 365 Guide complet pour le piano numérique GEWA UP 365, couvrant l'installation, l'utilisation des fonctions, les réglages et la maintenance pour une expérience musicale optimale.



Documents - Gewa – AIR 2.1



GEWA G3 Manuel d'utilisation

Manuel d'utilisation pour le module de batterie électronique GEWA G3. Découvrez les instructions de montage, l'interface utilisateur, les réglages, les effets, la connectivité MIDI et USB, et les spécifications techniques.

[\[pdf\]](#) Installation Guide Guide

Kentaro Yamamoto installation guide GEWA Replacement Handle Oblong Air Idea Cases oblong idea air
v 1649961703 cdn shopify s files 1 0946 6252 |||

Title: Main handle replacement Products: **Air 2.1** Idea Violin/Viola Parts: 396.421
Time: 10-20 minutes Difficulty: Medium. The repair procedure might require tools and supplies that might not be common in a household tool set. 1. Overview a. Many handle repairs require a similar set of procedures a...

lang:en score:21 filesize: 296.13 K page count: 4 document date: 2022-04-14

GEWA 2025 Price List for Musical Instrument Cases

Official 2025 price list from GEWA detailing their range of musical instrument cases, including models for violin, viola, and cello. Features shaped and oblong designs with tax-excluded and tax-included pricing.

lang:tl score:20 filesize: 98.16 K page count: 1 document date: 2025-09-02

[\[pdf\]](#) Instructions Decleration of Conformity


Microsoft Word preview libretto c0nt5efnepihwo45awfu2c5526 doc RG013 Instructions for use and
installation Istruzioni per l'uso e Aspiratör motorunu kullanılan en son hızda Lambaları ve aspiratör
kapatınız 24h Franke S p a Via Pignolini 2 37019 Peschiera del franke fdb9078 manualsplanet
manualPdf |||

GB Instructions for use and installation Cooker Hood IT Istruzioni per l'uso e l'installazione Cappa FR Mode d'emploi et installation Hotte de Cuisine DE Bedienungsanleitung und Einrichtung Dunstabzugshaube TR Kullanım ve montaj talimatları Davlumbaz FDB 6078 FDB 7078 FDB 8078 FDB 9078 FDB 12078 I... lang:i-klon score:15 filesize: 1.61 M page count: 48 document date: 2010-10-28



[pdf] User Manual Instructions Specifications

Download Product ManualMellerware Vacuum Cleaner Bagless Cyclone Plastic Red 1 2L 1200W
Innovac 31120A Creative Housewarescreativehousewares.co.za/site/items/manuals/ownermanual |||
INNOVAC 1200W Bagless vacuum complies with INTERNATIONAL IEC60335
SAFETY SPECIFICATIONS 1200W Mod ... til de plancher 11. Outil de crevaison 12.
Tubes d extension 13. Filtre de sortie d air 14. Entre d **air 2.1**. Environnement d
utilisation ou de travail: 2.1.1. Gardez la zone de travail propre et bien ...
lang:en **score:12** filesize: 533.92 K page_count: 28 document date: 2021-08-04



[pdf] User Manual

YellowV Heartbeat 11'0'' Σερ Paddle Surf Χρυσό Xtremeinn eng yellowv manu heartbeat sup cache
tradeinn images manuales |||
User manual Inflatable SUP platform HEARTBEAT11 ISUP HEARTBEAT8
PLATFORM HEARTBEAT08 ISUP HEARTBEAT09 ISUP NL Gebruikershandleiding 9
Opblaasbare SUP platform EN User manual 22 Inflatable SUP platform DE
Benutzerhandbuch 35 Aufblasbare SUP Plattform FR Manuel d utilisation...
lang:nl **score:10** filesize: 21.67 M page_count: 181 document date: 2022-03-01