Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MOFII SMK-676367AG

MOFII Wireless Keyboard and Mouse Set Bean 2.4G User Manual

Model: SMK-676367AG

1. Introduction

This manual provides detailed instructions for the MOFII Wireless Keyboard and Mouse Set Bean 2.4G, model SMK-676367AG. This set offers a convenient and cable-free input solution for compatible devices, primarily laptops running Windows operating systems. Please read this manual thoroughly before use to ensure proper operation and longevity of your product.



Image 1.1: MOFII Wireless Keyboard and Mouse Set (Green).

2. Package Contents

Verify that all items listed below are present in your package:

- MOFII Wireless Keyboard
- MOFII Wireless Mouse
- 2.4G USB Receiver
- User Manual (this document)

3. Setup Instructions

3.1. Battery Installation

The keyboard and mouse require batteries for operation. Please follow these steps:

1. Locate the battery compartment on the underside of the keyboard and mouse.

2. Open the battery compartment cover.
3. Insert the required batteries (1x AAA for the mouse, typically 2x AAA for the keyboard). Ensure correct polarity (+/-).
4. Close the battery compartment cover securely.

3.2. Connecting the USB Receiver

The 2.4G USB receiver enables wireless communication between the keyboard, mouse, and your computer.

1. Locate an available USB port on your computer.
2. Insert the 2.4G USB receiver firmly into the USB port.
3. Your computer should automatically detect and install the necessary drivers. This may take a few moments.



Image 3.1: Keyboard and mouse with the USB receiver, ready for connection.

3.3. Powering On

After installing batteries and connecting the receiver:

- For the keyboard: There may be a power switch on the underside or side. Slide it to the "ON" position.
- For the mouse: There is typically a power switch on the underside. Slide it to the "ON" position.

The devices should now be connected and ready for use. If they do not respond, refer to the Troubleshooting section.

4. Operating Instructions

4.1. Keyboard Usage

The MOFII Wireless Keyboard features a QWERTY layout and membrane keys. It is compatible with Windows operating systems.

- **Typing:** Use the keys as you would a standard keyboard.
- **Function Keys (Fn):** Some keys may have secondary functions (e.g., media control, volume, brightness). These are

typically accessed by holding down the **Fn** key and pressing the desired function key. Refer to the keycap legends for specific functions.

- **Compatibility:** Designed for use with laptops and desktop computers running Windows.

4.2. Mouse Usage

The MOFII Wireless Mouse uses optical tracking technology for precise cursor control.

- **Movement:** Move the mouse on a flat surface to control the cursor on your screen.
- **Left Click:** Primary button for selecting items, opening links, etc.
- **Right Click:** Secondary button for context menus and additional options.
- **Scroll Wheel:** Roll to scroll through documents and web pages. The scroll wheel may also function as a middle click button.



Image 4.1: User interacting with the MOFII Wireless Keyboard and Mouse Set.

5. Maintenance

5.1. Cleaning

To maintain the appearance and functionality of your keyboard and mouse:

- Disconnect the USB receiver from your computer.
- Turn off both the keyboard and mouse.
- Use a soft, dry, lint-free cloth to wipe the surfaces.
- For stubborn dirt, lightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not spray cleaning solutions directly onto the devices.

5.2. Battery Replacement

When the devices stop responding or performance degrades, it may be time to replace the batteries. Follow the battery

installation steps in Section 3.1.

- Always use new batteries of the specified type (AAA).
- Dispose of old batteries responsibly according to local regulations.

5.3. Storage and Portability

When not in use, especially during travel, turn off the keyboard and mouse to conserve battery life. The compact design allows for easy portability.



Image 5.1: The compact keyboard is suitable for travel and storage.

6. Troubleshooting

If you encounter issues with your MOFII Wireless Keyboard and Mouse Set, try the following solutions:

- **Devices not responding:**
  - Ensure the keyboard and mouse are powered on.
  - Check battery levels and replace if necessary.
  - Ensure the USB receiver is securely plugged into a working USB port. Try a different USB port.
  - Restart your computer.
- **Lagging or intermittent connection:**
  - Move the keyboard and mouse closer to the USB receiver.
  - Ensure there are no large metal objects or other wireless devices (e.g., Wi-Fi routers, cordless phones) interfering with the 2.4G signal.
  - Replace batteries.
- **Mouse cursor erratic or not moving:**

- Ensure the mouse is on a clean, non-reflective surface.
- Check the optical sensor on the underside of the mouse for obstructions.
- Replace batteries.

7. Specifications

Brand	MOFII
Model Number	SMK-676367AG
Color	Green
Connectivity Technology	2.4G Wireless (USB Receiver)
Compatible Operating System	Windows
Compatible Devices	Laptop, Desktop Computer
Keyboard Type	Membrane
Keyboard Layout	QWERTY
Mouse Tracking Technology	Optical
Power Source	Battery Powered
Battery Requirement	1x AAA (Mouse), (Keyboard battery type not specified, typically AAA)
Special Feature	Lightweight design
Country of Origin	China

8. Warranty and Support

Information regarding specific warranty terms and conditions for the MOFII Wireless Keyboard and Mouse Set is not provided in this document. For warranty claims or technical support, please refer to the retailer where the product was purchased or visit the official MOFII website for contact information.

Keep your proof of purchase for any warranty-related inquiries.

© 2023 MOFII. All rights reserved.
This manual is for informational purposes only. MOFII reserves the right to make changes to product specifications without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BS9QY22V

More documents and user manuals: **https://manuals.plus/**