

[Manuals.plus](#) /

› [IFANNY](#) /

› IFANNY Folding Wall Desk User Manual

IFANNY Folding Wall Desk

IFANNY Folding Wall Desk User Manual

Model: Folding Wall Desk (Grey)

1. INTRODUCTION

Thank you for choosing the IFANNY Folding Wall Desk. This versatile and space-saving furniture piece is designed to provide a functional workspace or dining area while maximizing your room's potential. When not in use, it conveniently folds up, blending seamlessly into your living space. This manual provides essential information for assembly, operation, and maintenance to ensure safe and optimal use of your new wall desk.



Image 1.1: The IFANNY Folding Wall Desk shown in both its open, functional state and its compact, closed state, highlighting its space-saving design.

2. SAFETY INFORMATION

WARNING: Failure to follow these safety instructions could result in injury or damage to the product.

- **Secure Mounting:** It is critical to ensure the desk is securely mounted on a wall stud. The tabletop can hold up to 44 LBS (20 kg). Mounting to drywall alone without proper anchors into studs may lead to instability and collapse.
- **Assembly Required:** This product requires assembly. Follow all instructions carefully, step by step, to ensure safe and proper use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 44 LBS (20 kg) on the tabletop. Distribute weight evenly.

- **Children and Pets:** Keep children and pets away from the desk during assembly. Do not allow children to hang on or climb the desk.
- **Tools:** Use appropriate tools for assembly and mounting. Wear safety glasses when drilling.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight and secure.

3. PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

Item	Quantity	Description
Wall Mounted Desk Unit	1	Main desk unit with integrated shelves and chalkboard panel.
Instruction Manual	1	This document.
Mounting Hardware	1 Set	Screws, anchors (if applicable), and other necessary fasteners for wall mounting.
Assembly Tools	(Not Included)	Phillips head screwdriver, drill, level, stud finder, measuring tape.

4. ASSEMBLY INSTRUCTIONS

The IFANNY Folding Wall Desk is designed for straightforward assembly. All parts are clearly labeled. Follow the detailed instructions provided in the included assembly guide step-by-step. The general process involves assembling the main desk unit and then securely mounting it to your wall.




Image 4.1: Detailed dimensions of the desk in both folded and unfolded states, illustrating key components and measurements for assembly planning.

Key Assembly Steps:

1. **Unpack and Identify Parts:** Lay out all components and hardware. Refer to the parts list in your separate assembly guide to ensure everything is accounted for.
2. **Assemble the Main Cabinet:** Follow the instructions to connect the side panels, back panel, and internal shelves of the upper cabinet section. Ensure all cam locks and screws are tightened securely.
3. **Attach the Folding Tabletop:** Secure the main tabletop panel to the cabinet using the provided hinges. Ensure the hinges are correctly aligned for smooth folding operation.
4. **Install the Chalkboard Panel:** Attach the chalkboard panel, which also serves as the leg when the desk is open, to the tabletop using its hinges.
5. **Attach Hooks and Latches:** Install the internal hooks for hanging items and the metal buckle/latch mechanism that

secures the desk in its closed position.



- Fixing Metal Buckle



- Safe Baffle Design

MORE DETAILS



- Flexible Hinges



- Sturdy Triangular Structure

Image 4.2: Close-up view of critical hardware components such as the fixing metal buckle, safe baffle design, flexible hinges, and sturdy triangular structure, which contribute to the desk's stability and functionality.

5. SETUP (WALL MOUNTING)

Proper wall mounting is essential for the stability and safety of your IFANNY Folding Wall Desk. This desk must be mounted into wall studs.

1. **Choose Location:** Select a wall location that can accommodate the desk's dimensions (24" W x 29.5" H when folded, 24" W x 34" D x 57.5" H when unfolded). Ensure there are no electrical wires or plumbing behind the wall where you plan to drill.
2. **Locate Wall Studs:** Use a stud finder to locate at least two vertical wall studs that align with the mounting points on the back of the desk unit. Mark the center of the studs.
3. **Determine Mounting Height:** Decide on the desired height for your desk. The top of the desk unit should be at a

comfortable working height when unfolded. Mark the drill points on the wall according to the desk's pre-drilled mounting holes. Use a level to ensure marks are perfectly horizontal.

4. **Drill Pilot Holes:** Using a drill bit appropriate for your mounting screws and wall material, drill pilot holes at the marked locations.
5. **Mount the Desk:** With assistance, carefully lift the assembled desk unit and align its mounting holes with the pilot holes on the wall. Insert the mounting screws and tighten them securely into the wall studs. Do not overtighten.
6. **Verify Stability:** Once mounted, gently pull on the desk to ensure it is firmly attached to the wall and does not wobble.

6. OPERATING INSTRUCTIONS

Folding and Unfolding the Desk:

1. To Unfold:

- Unlatch the metal buckle located at the top center of the desk unit, which secures the chalkboard panel in its closed position.
- Gently pull the chalkboard panel downwards. As it lowers, the main tabletop will also descend, supported by the chalkboard panel acting as a leg.
- Ensure the chalkboard panel is fully extended and stable on the floor before placing items on the tabletop.

2. To Fold:

- Clear all items from the tabletop.
- Lift the chalkboard panel upwards. The tabletop will simultaneously rise and fold back into the main cabinet.
- Once fully closed, secure the metal buckle to keep the desk unit compact and flush against the wall.



Image 6.1: The IFANNY Folding Wall Desk in an unfolded state, demonstrating its use as a functional workspace with a laptop and chair.

Using Storage Features:

- **Shelves:** The upper cabinet features multiple compartments and shelves of varying sizes. Use these for organizing books, office supplies, decorative items, or small kitchen essentials.
- **Hooks:** Three integrated hooks are located inside the upper cabinet. These are ideal for hanging keys, small bags, or other lightweight items.
- **Chalkboard:** The exterior of the folding panel features a chalkboard surface. Use standard chalk to write notes, lists, or creative drawings.



Image 6.2: A view of the internal storage compartments and hooks within the upper cabinet of the desk, showcasing its organizational capabilities.

Upgraded



WITH WRITING CHALKBOARD

- ✓ Leave a Memo for Your Family
- ✓ Create a Space to Unleash Your Kids' Imagination

WHAT MAKES OURS BETTER?

WITHOUT WRITING CHALKBOARD



Image 6.3: The chalkboard surface on the exterior of the folding panel, demonstrating its use for notes or creative expression.

7. MAINTENANCE

- **Cleaning:** The desk features a smooth and waterproof laminated surface. Wipe clean with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Chalkboard Care:** Use standard chalk and a soft cloth or chalkboard eraser to clean the chalkboard surface. For stubborn marks, a slightly damp cloth can be used, ensuring the surface is dried thoroughly afterward.
- **Hardware:** Periodically inspect all screws, hinges, and the metal buckle for tightness. Tighten any loose fasteners to maintain stability and smooth operation.
- **Avoid Excessive Moisture:** While the surface is waterproof, avoid prolonged exposure to excessive moisture to prevent damage to the engineered wood.

8. TROUBLESHOOTING

- **Desk feels wobbly after mounting:**
Ensure the desk is securely mounted into wall studs. If mounted into drywall without proper stud support, it will not be stable. Re-check all mounting screws for tightness. If the issue persists, consult a professional for secure installation.
- **Tabletop does not fold/unfold smoothly:**
Check the hinges for any obstructions or damage. Ensure all hinge screws are tight. Apply a small amount of silicone lubricant to the hinges if they are stiff.
- **Metal buckle does not secure the desk:**
Verify that the desk is fully folded and aligned correctly. Check if the buckle mechanism is damaged or misaligned. Adjust if possible, or contact customer support for replacement parts.
- **Chalkboard surface is difficult to clean:**
Ensure you are using standard chalk. Some chalk markers or crayons may leave permanent marks. For stubborn residue, try a specialized chalkboard cleaner or a mixture of water and a small amount of vinegar.

9. SPECIFICATIONS

Feature	Detail
Brand	IFANNY
Model Name	Folding Wall Desk
Color	Grey
Material	Engineered Wood (MDF)
Finish Type	Laminated
Folded Dimensions (L x W x H)	24" x 6.5" x 29.5" (61 cm x 16.5 cm x 75 cm)
Unfolded Dimensions (L x W x H)	24" x 34" x 57.5" (61 cm x 86.4 cm x 146 cm)
Net Weight	32.4 LBS (14.7 kg)
Tabletop Weight Capacity	44 LBS (20 kg)
Mounting Type	Wall Mount (into studs)
Special Features	Foldable design, integrated storage shelves, 3 hooks, chalkboard surface.

10. WARRANTY AND SUPPORT

For information regarding warranty coverage, product registration, or technical support, please refer to the documentation included with your purchase or visit the official IFANNY website. Contact details for customer service are typically provided on the product packaging or the brand's online presence.

Manufacturer: IFANNY
Model Number: Folding Wall Desk
UPC: 798470144590

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question