

[manuals.plus](#) /› [LEXiBOOK](#) /› [LEXiBOOK Miraculous Educational Bilingual Laptop JC598Mli2 User Manual](#)

## LEXiBOOK JC598Mli2

# LEXiBOOK Miraculous Educational Bilingual Laptop

**MODEL: JC598Mli2 - USER MANUAL**

## 1. Introduction

This manual provides comprehensive instructions for the setup, operation, and maintenance of your LEXiBOOK Miraculous Educational Bilingual Laptop, model JC598Mli2. Designed for children, this interactive learning toy offers 124 activities in both English and Spanish, covering various educational subjects and games. Please read this manual carefully to ensure proper use and to maximize the learning experience.

## 2. Important Safety Information

**WARNING: Not suitable for children under 36 months. Choking Hazard - Small parts.**

- Always supervise children during play.
- Do not expose the device to water or excessive moisture.
- Avoid dropping the device or subjecting it to strong impacts.
- Batteries should be inserted with the correct polarity. Do not mix old and new batteries. Remove exhausted batteries promptly.
- Keep the device away from direct heat sources.

## 3. Package Contents

Verify that all items are present in the package:

- 1 x LEXiBOOK Miraculous Educational Bilingual Laptop (JC598Mli2)
- 1 x Wired Mouse
- 1 x Instruction Manual



Image: The LEXiBOOK Miraculous Educational Bilingual Laptop shown in its retail box, highlighting the product and its features.

#### 4. Product Overview

The LEXiBOOK Miraculous Educational Bilingual Laptop is designed to resemble a real laptop, featuring a keyboard, a mouse, and an LCD screen. It provides an engaging platform for children to learn and play.



Image: A top-down view of the LEXiBOOK Miraculous Educational Bilingual Laptop, showcasing its red keyboard base, black screen with Miraculous characters, and connected mouse.



*Image: The LEXiBOOK Miraculous Educational Bilingual Laptop in a closed position, displaying the Ladybug character on the screen's exterior.*

## 5. Setup

---

### 5.1. Battery Installation

The laptop requires 2 AA batteries (not included).

1. Locate the battery compartment on the underside of the laptop.
2. Using a screwdriver, open the battery compartment cover.
3. Insert 2 new AA batteries, ensuring correct polarity (+/-).
4. Replace the battery compartment cover and secure it with the screw.

### 5.2. Connecting the Mouse

The wired mouse connects to the side of the laptop. Simply plug the mouse connector into the designated port.

## 6. Operating Instructions

---

### 6.1. Power On/Off

To turn the laptop ON, press the **ON/OFF** button located on the keyboard. To turn it OFF, press the **ON/OFF** button again.

## 6.2. Language Selection

The laptop supports both English and Spanish. To switch between languages, locate the **LANG** button on the keyboard and press it. The screen will display the current language selection.

## 6.3. Navigating Activities

The laptop features 124 activities categorized into different learning areas. Use the arrow keys or the mouse to navigate through the menu options displayed on the screen. Press the **ENTER** key or click the left mouse button to select an activity.



*Image: A detailed view of the laptop's screen interface, displaying icons and labels for different activity categories such as Mathematics, Language, Logic, Games, Typing, Music, and Clock & Time.*

### Activity Categories:

- **Mathematics (1-20):** Numbers and basic calculations (addition, subtraction, multiplication, division).
- **Language (21-36):** Letters, words, spelling, and vocabulary.
- **Typing (37-38):** Dactylography exercises to improve typing skills.
- **Logic (44-51):** Puzzles and challenges to develop logical thinking.
- **Music (39-41):** Notes learning, composing, and playing melodies.
- **Games (52-60):** Fun games to test logic, memory, and speed.
- **Clock & Time (Hour):** Learning to read and understand time.



*Image: A young girl engaged in using the LEXiBOOK laptop, demonstrating its use in a typical home setting.*

## 6.4. Using the Keyboard and Mouse

The laptop features a QWERTY keyboard for inputting answers and interacting with activities. The connected mouse allows for easy navigation and selection, similar to a standard computer mouse.

Your browser does not support the video tag.

*Video: An official product video demonstrating the features and interactive activities of the LEXiBOOK Educational and Bilingual Laptop (JC598i2).*

## 7. Maintenance

### 7.1. Cleaning

To clean the laptop, use a soft, dry cloth. Do not use abrasive cleaners or solvents, as these may damage the surface. For stubborn marks, a slightly damp cloth can be used, followed by immediate drying.

### 7.2. Storage

When not in use, store the laptop in a cool, dry place, away from direct sunlight and extreme temperatures. If the device will not be used for an extended period, remove the batteries to prevent leakage.

## 8. Troubleshooting

Problem	Possible Cause	Solution
Laptop does not turn on.	Batteries are low or incorrectly installed.	Replace with new AA batteries, ensuring correct polarity.

Problem	Possible Cause	Solution
Screen is blank or flickering.	Low battery power or temporary software glitch.	Replace batteries. Turn the device off and on again.
Mouse is not responding.	Mouse not properly connected.	Ensure the mouse cable is securely plugged into the laptop's port.
Sound is not working.	Volume is too low or muted.	Adjust the volume using the dedicated volume buttons on the keyboard.

## 9. Specifications

- Model Number:** JC598Mli2 (also referred to as JC598Mli1 in some documentation)
- Product Dimensions:** 9.45 x 7.09 x 1.42 inches
- Item Weight:** 1.4 pounds
- Power Source:** 2 x AA Batteries (not included)
- Recommended Age:** 3 years and up
- Languages:** English, Spanish
- Activities:** 124 educational activities and games



## 10. Warranty and Support

For warranty information and customer support, please refer to the contact details provided on the product packaging or visit the official LEXiBOOK website. Keep your purchase receipt as proof of purchase for any warranty claims.

© 2023 LEXiBOOK. All rights reserved.

## Related Documents - JC598Mli2

	<a href="#"><u>Lexibook JC598i9 Series Educational Bilingual Laptop User Manual</u></a> Comprehensive user manual for the Lexibook JC598i9 Series educational bilingual laptop, covering setup, activities, care, and warranty information. Features math, language, logic, music, typing, games, and clock activities.
	<a href="#"><u>Lexibook JC598i12series Educational Bilingual Laptop User Manual</u></a> Comprehensive user manual for the Lexibook JC598i12series educational bilingual laptop, detailing unpacking, battery installation, function key descriptions, care, maintenance, warranty, and a wide range of learning activities in mathematics, language, typing, music, logic, games, and timekeeping.

	<p><a href="#"><b>Frozen 2 Educational Bilingual Laptop User Manual and Activities Guide</b></a></p> <p>This guide provides comprehensive instructions for the Lexibook Frozen 2 educational bilingual laptop. It covers unpacking, power supply and battery installation, a detailed description of function keys, care and maintenance advice, warranty information, and a complete list of interactive learning activities categorized into Mathematics, Language, Typing, Music, Logic, Games, and Clock &amp; Time. The laptop is designed to help children learn numbers, letters, spelling, and develop cognitive skills through engaging games and exercises.</p>
	<p><a href="#"><b>Lexibook JC598i2series Educational Bilingual Laptop Instruction Manual</b></a></p> <p>User manual and activity guide for the Lexibook JC598i2series bilingual educational laptop, covering setup, functions, activities, care, and warranty information.</p>
	<p><a href="#"><b>Lexibook JC598i13series Educational Bilingual Laptop User Manual</b></a></p> <p>This user manual provides comprehensive instructions for the Lexibook JC598i13series educational bilingual laptop. It covers setup, operation, maintenance, and details the various learning activities and games available for children.</p>
	<p><a href="#"><b>Lexibook JC598i2series Educational Bilingual Laptop User Manual and Activities Guide</b></a></p> <p>Comprehensive user manual for the Lexibook JC598i2series educational bilingual laptop. Discover its features, setup, battery information, maintenance, and a detailed list of educational activities for children in Mathematics, Language, Typing, Music, Logic, Games, and Clock functions.</p>