

## KROM NXKROMKYARA

# KROM KYARA Mechanical Gaming Keyboard User Manual

Model: NXKROMKYARA

## INTRODUCTION

The KROM KYARA is a compact 60% mechanical gaming keyboard designed for versatility and performance. It offers multiple connectivity options including wired USB, 2.4 GHz wireless, and Bluetooth 5.0, making it compatible with a wide range of operating systems such as Windows, Android, iOS, and Mac. Featuring RGB backlighting and hot-swappable switches, the KYARA provides a customizable and responsive typing experience.

## INITIAL SETUP

### Package Contents

- KROM KYARA Mechanical Gaming Keyboard
- USB-C to USB-A Cable
- 2.4 GHz USB Receiver
- Switch Puller Tool
- Keycap Puller Tool
- 2 Spare Mechanical Switches

### Charging the Keyboard

Before first use, ensure the keyboard is fully charged. Connect the provided USB-C cable to the keyboard's USB-C port and the USB-A end to a power source (e.g., computer USB port, wall adapter). The charging indicator will show the charging status.

### Connectivity Options

The KROM KYARA supports three connection modes:

1. **Wired Connection (USB):** Connect the USB-C cable directly from the keyboard to your device. The

keyboard will automatically switch to wired mode.

## 2. 2.4 GHz Wireless Connection:

- Insert the 2.4 GHz USB receiver into an available USB port on your device.
- On the keyboard, press **Fn + Q** to activate 2.4 GHz mode. The Q key backlight will indicate the connection status.

## 3. Bluetooth 5.0 Connection: The keyboard supports up to three Bluetooth devices.

- Press **Fn + E** (BT1), **Fn + R** (BT2), or **Fn + T** (BT3) to select a Bluetooth channel. The corresponding key (E, R, or T) will flash.
- To enter pairing mode, press and hold **Fn + E/R/T** for 3 seconds. The key will flash rapidly.
- On your device, search for Bluetooth devices and select "KROM KYARA" to pair. The key will stop flashing once connected.

## System Compatibility

The KROM KYARA keyboard is compatible with Windows, Android, iOS, and Mac operating systems. Functionality may vary slightly depending on the specific operating system.

## OPERATING INSTRUCTIONS

---

### Function Key Combinations (Fn)

The Fn key allows access to secondary functions printed on the keycaps. Hold down the **Fn** key and press the desired key to activate its secondary function.

- **Fn + Q/W/E/R/T**: Switch between 2.4 GHz wireless, Wired, and Bluetooth channels (BT1, BT2, BT3).
- **Fn + F1-F12**: Multimedia controls (e.g., volume, play/pause, next/previous track). Specific functions are indicated on the keycaps.
- **Fn + Left Shift**: Toggle Caps Lock.
- **Fn + Win**: Lock/Unlock Windows key.
- **Fn + Spacebar**: Change RGB lighting effects.
- **Fn + Arrow Keys**: Adjust RGB brightness and speed.

### RGB Backlighting Control

The KROM KYARA features customizable RGB backlighting. Use the following key combinations to control the lighting:

- **Fn + Spacebar**: Cycles through various RGB lighting modes.
- **Fn + Up/Down Arrow**: Adjusts the brightness of the backlighting.
- **Fn + Left/Right Arrow**: Adjusts the speed of dynamic lighting effects.

### Anti-Ghosting and Game Mode

The keyboard features full anti-ghosting, ensuring all key presses are registered accurately even during rapid, simultaneous inputs. A dedicated game mode can be activated via Fn combinations (refer to specific keycap legends if available) to prevent accidental presses of system keys like the Windows key.

### Hot-Swappable Switches

The KROM KYARA keyboard is equipped with hot-swappable switches, allowing you to change mechanical

switches without soldering. This enables customization of typing feel and easy replacement of faulty switches.

1. **Removing a Keycap:** Use the keycap puller tool to gently lift the keycap off the switch.
2. **Removing a Switch:** Use the switch puller tool to grasp the top and bottom clips of the switch. Gently pull the switch straight up to remove it from the PCB.
3. **Installing a New Switch:** Align the pins of the new switch with the holes on the PCB. Press the switch firmly until it clicks into place. Ensure the pins are not bent.
4. **Installing a Keycap:** Place the keycap onto the new switch and press down until it is secure.

## CARE AND MAINTENANCE

---

To ensure the longevity and optimal performance of your KROM KYARA keyboard, follow these maintenance guidelines:

- **Cleaning:** Regularly clean the keyboard with a soft, dry cloth. For deeper cleaning, use a can of compressed air to remove dust and debris from between the keycaps. Keycaps can be removed for thorough cleaning using the provided keycap puller.
- **Avoid Liquids:** Do not expose the keyboard to liquids. In case of accidental spills, immediately disconnect the keyboard and allow it to dry completely before reconnecting.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handle with Care:** Avoid dropping the keyboard or subjecting it to strong impacts.

## TROUBLESHOOTING

---

If you encounter issues with your KROM KYARA keyboard, refer to the following common solutions:

- **Keyboard Not Responding:**
  - Ensure the keyboard is charged.
  - Check the connection mode (wired, 2.4 GHz, Bluetooth) and ensure it matches your device's connection.
  - For wired connection, try a different USB port or cable.
  - For 2.4 GHz, ensure the USB receiver is properly inserted and try re-pairing (Fn + Q).
  - For Bluetooth, ensure the keyboard is in pairing mode and your device's Bluetooth is enabled. Try re-pairing (hold Fn + E/R/T).
  - Restart your computer/device.
- **Keys Not Registering:**
  - Check if the specific keycap or switch is properly seated. If not, remove and re-install it.
  - If a switch is faulty, replace it with one of the spare switches using the hot-swap instructions.
  - Ensure Game Mode is not interfering with certain key functions.
- **RGB Backlighting Not Working/Incorrect:**
  - Ensure the keyboard is powered on.
  - Try cycling through RGB modes (Fn + Spacebar) or adjusting brightness (Fn + Up/Down Arrow).
  - A factory reset (if available, consult manufacturer's website) might resolve persistent lighting issues.

- **Connectivity Issues (Intermittent Disconnections):**

- Ensure there are no strong interferences (e.g., other wireless devices, large metal objects) near the keyboard or receiver.
- For Bluetooth, ensure your device is within range.
- Update your device's Bluetooth drivers.

## TECHNICAL SPECIFICATIONS



Angled view of the KROM KYARA keyboard, showcasing its compact 60% layout and vibrant RGB backlighting.



Top-down perspective of the KROM KYARA keyboard, highlighting the Spanish layout and full RGB illumination.



Side profile of the KROM KYARA keyboard, illustrating its ergonomic design and keycap height.



Rear view of the KROM KYARA keyboard, showing the central USB-C port for wired connection and charging.



The KROM KYARA keyboard integrated into a gaming desk setup, demonstrating its compact footprint.





Feature	Detail
Brand	KROM
Model Number	NXKROMKYARA
Connectivity Technology	Bluetooth 5.0, 2.4 GHz Wireless, USB-C Wired
Keyboard Description	Mechanical Gaming Keyboard
Layout	60% Compact, Spanish Layout
Special Features	RGB Backlit, Hot-Swappable Switches, Full Anti-Ghosting, Game Mode
Compatible Devices	Laptop, PC, Android, iOS, Mac
Operating System	Windows, Android, iOS, Mac, Chrome OS

Feature	Detail
Battery Composition	Lithium-ion (1 battery required)
Product Dimensions	29.1L x 10.2W x 4H centimeters
Color	Black

### WARRANTY AND SUPPORT

The KROM KYARA keyboard comes with a manufacturer's warranty. Spare parts availability is guaranteed for 2 years from the date of purchase. Software updates are guaranteed until April 13, 2030. For technical support, warranty claims, or further assistance, please refer to the official KROM website or contact their customer service department. Keep your proof of purchase for warranty validation.


### Related Documents - NXKROMKYARA

	<p><a href="#">KROM KAYROS RGB Advanced Wireless Gamepad User Manual</a></p> <p>Comprehensive user manual for the KROM KAYROS RGB Advanced Wireless Gamepad, detailing setup, pairing, button functions, Turbo/Auto-Fire modes, vibration, RGB settings, macros, and factory reset.</p>
	<p><a href="#">Krom Kyara RGB Wireless Mini Keyboard User Manual</a></p> <p>User manual for the Krom Kyara RGB Wireless Mini Keyboard, detailing connection methods, lighting controls, multimedia functions, and basic operations. Includes instructions for wired, 2.4G, and Bluetooth modes.</p>
	<p><a href="#">Krom Kadoer Multiplatform Wireless Gamepad User Manual</a></p> <p>Official user manual for the Krom Kadoer Multiplatform Wireless Gamepad, detailing functions, connection modes, turbo settings, battery information, and troubleshooting.</p>
	<p><a href="#">Krom Kenzo Advanced Wireless Gamepad User Manual</a></p> <p>User manual for the Krom Kenzo Advanced Wireless Gamepad, detailing specifications, wireless and wired pairing instructions, and turbo function. Compatible with Android, iOS, PC, Switch, PS4, and PS3.</p>



[Krom Kasic TKL Mechanical Gaming Keyboard: Features and Guide](#)

A comprehensive guide to the Krom Kasic TKL Mechanical Gaming Keyboard, detailing its features, functions, backlighting configuration, additional key combinations, EU directives, and warranty information.



[KROM KRYSTAL RGB Advanced Wireless Gamepad User Manual](#)

A comprehensive guide to the KROM KRYSTAL RGB Advanced Wireless Gamepad, covering setup, connectivity for PC, Switch, Android, and iOS, button functions, RGB lighting customization, macro programming, turbo features, vibration, charging, and reset procedures.