Fresh FNT-BR470KT

Fresh FNT-BR470KT 397 Liter Refrigerator User Manual

Model: FNT-BR470KT | Brand: Fresh

Introduction

This user manual provides essential information for the safe and efficient operation of your Fresh FNT-BR470KT 397 Liter Refrigerator. Please read these instructions carefully before installation and use, and keep them for future reference. This appliance features a digital inverter compressor, LED lighting, constant airflow, a Magic Crisper, an Ionic Plasma Filter, and Bio Shield anti-bacterial technology to ensure optimal food preservation.




10 Years / Full Free Warranty
TOTAL NO FROST

Image: The Fresh FNT-BR470KT 397 Liter Refrigerator, showcasing its modern design.

Setup

1. Unpacking and Inspection

Carefully remove all packaging materials. Inspect the refrigerator for any damage that may have occurred during transit. Ensure all included components, such as shelves and accessories, are present. The product includes 1 refrigerator unit.

2. Placement

- Place the refrigerator on a firm, level surface to prevent vibrations and noise.
- Ensure adequate ventilation around the appliance. Maintain a minimum clearance of 10 cm from walls and other objects to allow for proper heat dissipation.
- Avoid placing the refrigerator in direct sunlight or near heat sources such as stoves, radiators, or ovens, as this can increase energy consumption.
- The refrigerator is designed as a freestanding unit.

3. Power Connection

Connect the refrigerator to a dedicated power outlet. The appliance operates on 240V. It is equipped with a Type A two-pin plug (North America). Ensure your electrical supply matches these specifications. Do not use extension cords or multiple outlet adapters.

4. Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and a mild detergent solution. Rinse with clean water and dry thoroughly.

5. First Use

After placement and cleaning, wait at least 2-4 hours before plugging in the refrigerator. This allows the refrigerant to settle. Once plugged in, allow the appliance to run for several hours (e.g., 4-6 hours) to reach its optimal operating temperature before storing food.

Operating Instructions

1. Temperature Control

Your Fresh refrigerator is equipped with a digital inverter compressor for efficient cooling. Use the internal control panel to adjust the temperature settings for both the refrigerator and freezer compartments. Refer to the display for current temperature readings and adjustment options.

2. LED Lighting

The interior of the refrigerator is illuminated with energy-efficient LED lighting, providing clear visibility of your stored items. The lights activate automatically when the door is opened.

3. Constant Airflow System

The constant airflow system ensures uniform cooling throughout the refrigerator, helping to maintain consistent temperatures and preserve food freshness.

4. Magic Crisper

Utilize the Magic Crisper drawer for storing fruits and vegetables. This specialized compartment is designed to maintain optimal humidity levels, extending the freshness of produce.

5. Ionic Plasma Filter

The Ionic Plasma Filter helps to neutralize odors and eliminate airborne bacteria within the refrigerator, contributing to a cleaner and more hygienic storage environment.

6. Bio Shield Anti-Bacterial Feature

The Bio Shield feature incorporates anti-bacterial properties into the door seals, preventing the growth of mold and bacteria and ensuring a hygienic seal.

7. Door Operation and Electronic Lock

This refrigerator has two doors, with the main door hinged on the right. Ensure doors are closed completely to maintain internal temperature. The electronic lock provides added security for your refrigerator contents.

Maintenance

1. Cleaning

- **Interior:** Regularly clean the interior with a solution of mild detergent and warm water. Wipe dry with a soft cloth. Remove shelves and drawers for thorough cleaning.
- **Exterior:** Clean the exterior surfaces with a soft cloth dampened with water and a mild detergent. Avoid abrasive cleaners or solvents.
- **Door Seals:** Clean door seals regularly to ensure they remain flexible and maintain a tight seal. Use warm, soapy water and wipe dry.

2. Automatic Defrost System

Your refrigerator features an automatic defrost system, eliminating the need for manual defrosting of the freezer compartment. If excessive ice buildup occurs, check door seals for proper closure.

3. Ionic Plasma Filter Maintenance

Periodically check and clean the Ionic Plasma Filter according to the instructions provided in the filter's specific manual (if applicable) or as indicated by the appliance. A clean filter ensures optimal odor and bacteria reduction.

4. Power Saving Tips

- Do not open the doors frequently or leave them open for extended periods.
- Allow hot foods to cool to room temperature before placing them in the refrigerator.
- Ensure the refrigerator is not overloaded, as this can impede airflow.

Troubleshooting

Before contacting service, please check the following common issues:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Refrigerator not cooling	Power outage; plug not inserted correctly; temperature setting too high; door left open.	Check power supply; ensure plug is secure; adjust temperature setting; ensure door is closed properly.
Unusual noises	Refrigerator not level; items inside vibrating; normal operating sounds (e.g., refrigerant flow).	Adjust leveling feet; rearrange items; consult manual for normal sounds.
Water leakage inside/outside	Drain hole blocked; door seal not tight; excessive humidity.	Clear drain hole; check and clean door seals; ensure proper ventilation.
Electronic lock not working	Power issue; sensor obstruction; control panel error.	Check power; ensure no obstructions; refer to specific lock instructions or contact support.

If the problem persists after attempting these solutions, please contact Fresh customer support.

Specifications

Feature	Detail
Brand	Fresh
Model Name	FNT-BR470KT
Product Type	Refrigerator
Configuration	Large Bottom Freezer Refrigerator
Total Capacity	397 Liters
Fresh Food Capacity	470 Liters (Note: This value is higher than total capacity, indicating a potential data discrepancy in the source.)
Freezer Capacity	95 Liters
Product Dimensions (D x W x H)	6.5 cm Depth x 175 cm Width x 175 cm Height (Note: These dimensions appear unusual for a refrigerator and may indicate a data entry error in the source.)
Item Weight	80 kg
Color	Assorted
Installation Type	Freestanding
Number of Doors	2
Defrost System	Automatic
Voltage	240V
Cooling Method	Air Compressor
Number of Shelves	5
Power Plug Type	Type A two-pin plug (North America)
Door Hinge Direction	Right

Feature	Detail
Convertible Freezer	No
Lock Type	Electronic
Annual Energy Consumption	408 kWh/year
Energy Efficiency Rating	4 Stars (BEE Rating)
Finish Type	Matte
Style	Plain
Country of Origin	Egypt

Warranty and Support

Warranty Information

Your Fresh FNT-BR470KT Refrigerator comes with a **10-year warranty** from the manufacturer. Please retain your proof of purchase for warranty claims.

Customer Support

For any inquiries, technical assistance, or warranty service, please contact the Fresh Support Hotline:

Hotline: 19059

You can also visit the official Fresh store for more information:Fresh Store

Additional Information

No official product videos were found in the provided data for this model.



Image: A range of Fresh home appliances, including refrigerators, washing machines, and ovens.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question