

- Manuals.plus /
- > [upbright](#) /
 - > UpBright 5V AC/DC Adapter and USB-C Charging Cable User Manual

upbright LaView LV-X2 LVX2 USB-C Cable Power

UpBright 5V AC/DC Adapter and USB-C Charging Cable User Manual

Model: LaView LV-X2 LVX2 USB-C Cable Power

PRODUCT OVERVIEW

This manual provides instructions for the UpBright 5V AC/DC Adapter and Type-C USB Charging Cable, designed for compatibility with devices such as the LaView LV-X2 LVX2 Star Projector. It ensures proper usage, maintenance, and troubleshooting for optimal performance.



Image: The UpBright 5V AC/DC Adapter and its accompanying USB-C charging cable. The adapter is a black wall plug with a USB-A port, and the cable features a USB-A connector on one end and a USB-C connector on the other.

SETUP AND INSTALLATION

Follow these steps to set up your UpBright AC/DC Adapter and USB-C Charging Cable:

1. **Inspect Components:** Ensure all components, including the AC/DC adapter and the USB-C cable, are present and free from visible damage.
2. **Connect Cable to Adapter:** Insert the USB-A end of the charging cable into the USB-A port on the UpBright AC/DC adapter. Ensure a firm connection.
3. **Connect to Device:** Insert the USB-C end of the charging cable into the compatible charging port of your device (e.g., LaView LV-X2 Star Projector).
4. **Plug into Power Outlet:** Plug the AC/DC adapter into a standard wall power outlet (100-240VAC, 50/60Hz).
5. **Verify Connection:** Confirm that your device indicates it is receiving power or charging.



Image: A close-up view of the UpBright AC/DC adapter, showing its input and output specifications. The label indicates "MODEL: PSA03F-050Q1 INPUT: 100-240V~ 0.1A 50-60Hz OUTPUT: 5V."

OPERATING INSTRUCTIONS

The UpBright AC/DC Adapter and USB-C Charging Cable are designed for straightforward operation:

- **Charging:** Once connected to a power source and your device, the adapter will automatically begin supplying power or charging the device's battery.
- **Power Supply:** For devices that operate directly from an external power source without a battery, the adapter provides continuous 5V DC power.
- **Safety Features:** The adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard both the adapter and your connected device.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your UpBright adapter and cable, follow these maintenance guidelines:

- **Cleaning:** Disconnect the adapter from the power outlet and your device before cleaning. Use a soft, dry cloth to wipe the surfaces. Do not use liquid cleaners or abrasive materials.
- **Storage:** When not in use, store the adapter and cable in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Do not pull the cable to disconnect it from the adapter or device; always grasp the plug itself. Avoid bending or crimping the cable excessively.
- **Environmental Conditions:** Do not expose the adapter or cable to water, high humidity, or dusty environments.



Image: The UpBright AC/DC adapter and USB-C cable shown from a different perspective, highlighting the compact design of the adapter and the length of the cable.

TROUBLESHOOTING

If you encounter issues with your UpBright AC/DC Adapter and USB-C Charging Cable, refer to the following common problems and solutions:

• **Device Not Charging:**

- Ensure the adapter is securely plugged into a working wall outlet.
- Verify that the USB-C cable is firmly connected to both the adapter and your device.
- Test the wall outlet with another device to confirm it has power.
- Try using the cable with a different compatible USB-A power source to rule out cable issues.
- Ensure your device is compatible with a 5V DC input.

• **Intermittent Charging:**

- Check for loose connections at both ends of the cable and at the wall outlet.
- Inspect the cable for any visible damage, kinks, or frayed wires.
- Ensure the device's charging port is clean and free of debris.

• **Adapter Overheating:**

- It is normal for adapters to become slightly warm during operation. However, if it feels excessively hot, disconnect it immediately.
- Ensure the adapter is not covered or placed in an enclosed space that restricts airflow.
- Verify that the connected device is not drawing more power than the adapter's rated output (5V, 1A).

If the issue persists after attempting these troubleshooting steps, please contact UpBright customer support.

SPECIFICATIONS

Feature	Detail
Brand	UpBright
Model Number	LaView LV-X2 LVX2 USB-C Cable Power
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	5V DC
Output Current	1 Amps
Connector Type	USB-C (Cable), USB-A (Adapter Port)
Protection Features	OVP (Over Voltage Protection), OCP (Over Current Protection), SCP (Short Circuit Protection)
Product Dimensions	12.7 x 5.08 x 2.54 cm; 85.05 g


WARRANTY INFORMATION

UpBright products are backed by a comprehensive warranty:

- **Refund Policy:** 30 Days Refund.
- **Exchange Policy:** 24 Months Exchange.

For warranty claims or further details, please retain your proof of purchase and contact UpBright customer support.

Come With A Suitable Outlet Adapter (Only One) to Fit
Your Country/Area For International Order



THIS PRODUCT COMES WITH A UPBRIGHT®

LIMITED WARRANTY CERTIFICATE
+ UPBRIGHT® LIMITED WARRANTY



Image: A graphic depicting a "Product Warranty" seal and a sample "Limited Warranty Certificate" from UpBright, indicating the product comes with a warranty.

CUSTOMER SUPPORT

For any inquiries, technical assistance, or warranty support, please contact UpBright customer service. You can find more information and contact details on the official UpBright store page:

[Visit the UpBright Store](#)

© 2024 UpBright. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0BSFZKQ2Y>

More documents and user manuals: <https://manuals.plus/>