

[Manuals.plus](#) /

> [YITAHOME](#) /

> YITAHOME Porch Swing Bed Instruction Manual

YITAHOME MAYIH0000225MA

YITAHOME Porch Swing Bed Instruction Manual

Model: MAYIH0000225MA | Brand: YITAHOME

1. PRODUCT OVERVIEW



The YITAHOME Porch Swing Bed is a versatile 3-seat outdoor patio swing designed for comfort and durability. It features an adjustable canopy for sun protection and a unique design that allows it to convert from a 3-seat swing chair to a comfortable swing bed. Constructed with a heavy-duty steel frame and weather-resistant fabrics, this swing is suitable for various outdoor environments such as gardens, poolside areas, and balconies.

Key features include:

- **Adjustable Swing Bed:** Easily converts from a 3-seat swing to a flat swing bed by lowering the support rod.
- **High Weight Capacity:** Heavy-duty steel spring lock supports up to 595 lbs.
- **Sturdy Construction:** Features a powder-coated steel frame, 180g polyester canopy, and 300D Oxford fabric seat for long-lasting use.
- **Adjustable Canopy:** A rotatable knob allows you to adjust the canopy angle for optimal sun protection throughout the day.
- **Versatile Applications:** Ideal for patios, gardens, backyards, poolside, and balconies.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or damage to the product.

- **Assembly:** Safety measures and professional installation are highly recommended. Ensure all bolts and fasteners are securely tightened before use.
- **Weight Limit:** Do not exceed the maximum weight capacity of 595 lbs. Overloading can cause structural failure and injury.
- **Stability:** Place the swing on a flat, level surface. In windy conditions, consider securing the swing to prevent tipping.
- **Children:** Supervise children when they are using the swing. Ensure they do not stand on the seat or engage in rough play.
- **Maintenance:** Regularly inspect the swing for any signs of wear, damage, or loose parts. Address any issues promptly.
- **Weather Conditions:** While the canopy is UV-resistant and waterproof, it is advisable to store cushions indoors during heavy rain or strong winds to prolong their lifespan.

3. PACKAGE CONTENTS

Before beginning assembly, ensure all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

Typical package contents include:

- Main Frame Components (legs, crossbars, canopy supports)
- Swing Seat Frame
- Canopy Fabric
- Seat Cushions (removable)
- Hardware Pack (bolts, nuts, washers, springs, tools)
- Instruction Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is required for this product. It is highly recommended to have two people for assembly to ensure ease and safety. A power drill may be helpful for certain steps.

1. **Unpack and Identify Parts:** Lay out all components and hardware. Compare them with the parts list in your included manual to ensure everything is accounted for.
2. **Assemble the Main Frame:** Connect the leg sections and crossbars according to the diagrams in your manual.
Important: Do not fully tighten bolts until the entire frame is assembled. This allows for slight adjustments to align holes.
3. **Attach Canopy Supports:** Secure the canopy support arms to the main frame.
4. **Assemble the Swing Seat:** Construct the swing seat frame. Pay close attention to the orientation of front and back pieces.
5. **Hang the Swing Seat:** Using the provided springs and hooks, attach the assembled swing seat to the main frame. Ensure the long eye bolt goes into the correct frame part as indicated in your manual.
6. **Install the Canopy:** Drape and secure the canopy fabric onto the canopy supports.

7. **Place Cushions:** Position the seat cushions on the swing.

8. **Final Tightening:** Once all components are in place and aligned, go back and securely tighten all bolts and fasteners. Ensure the nuts are on the side away from the cushions for comfort.

SOFT SEAT CUSHION



Image: Illustration of the durable steel stand construction.

5. OPERATING INSTRUCTIONS

5.1 Using as a 3-Seat Swing



To use the product as a traditional 3-seat swing, ensure the backrest support rod is in the upright position, securing the backrest in place. The plush cushions provide a comfortable seating experience for multiple individuals.

5.2 Converting to a Swing Bed



ROTATABLE KNOB

STURDY STEEL



SOLIDE HOOK

To convert the swing into a bed, gently lower the support rod located behind the swing seat. This action will allow the backrest to recline, creating a flat surface suitable for lounging or napping. Ensure the support rod is securely engaged in the lowered position before use as a bed.

5.3 Adjusting the Canopy

POLYESTER FABRIC



Fade Resistant



Waterproof



UV-resistant

The canopy can be adjusted to provide optimal shade. Locate the rotatable knobs on the canopy supports. Loosen the knobs, adjust the canopy to your desired angle to block the sun, and then tighten the knobs to secure it in place.

6. MAINTENANCE AND CARE

Proper maintenance will extend the life and appearance of your YITAHOME Porch Swing Bed.

- **Frame Care:** The steel frame is powder-coated for durability. Clean with a mild soap and water solution. Rinse thoroughly and dry completely to prevent rust. Avoid abrasive cleaners or harsh chemicals.
- **Fabric Care:** The canopy and seat cushions are made of polyester and Oxford fabric, designed to be fade-resistant, waterproof, and UV-resistant. Spot clean with a mild soap and water solution. For deeper cleaning, removable cushions can be hand washed. Allow to air dry completely before reattaching or storing.
- **Cushion Storage:** While water-resistant, it is recommended to remove and store cushions indoors during prolonged periods of heavy rain or when the swing is not in use to prevent mildew and prolong their lifespan.
- **Winter Storage:** During winter months or extended periods of non-use, it is advisable to disassemble the swing or cover it with a protective outdoor furniture cover to shield it from harsh weather conditions.

- **Regular Inspection:** Periodically check all bolts, nuts, and connections to ensure they remain tight. Tighten any loose fasteners as needed. Inspect the fabric for any tears or excessive wear.

PRODUCT SIZE




Image: Canopy features: UV-resistant and Waterproof.

7. TROUBLESHOOTING

This section addresses common issues you might encounter with your porch swing.

- **Issue: Cushions slide off the seat.**
Solution: Consider attaching hook-and-loop fasteners (Velcro) to the underside of the cushions and the swing seat frame to keep them securely in place.
- **Issue: Canopy collects water or sags.**
Solution: Ensure the canopy fabric is taut and properly secured to the frame. In some cases, additional support or tensioning might be needed, especially after heavy rain. Regularly clear any accumulated water.
- **Issue: Swing feels unstable or wobbly.**

Solution: Re-check all assembly bolts and nuts. Ensure they are fully tightened. Verify that the swing is placed on a completely flat and level surface.

- **Issue: Difficulty during assembly.**

Solution: Refer back to the assembly instructions. Ensure you have two people assisting. Remember not to fully tighten bolts until all parts are loosely assembled and aligned.

8. SPECIFICATIONS

Attribute	Detail
Brand	YITAHOME
Model Number	MAYIH0000225MA
Color	Brown
Product Dimensions	20"D x 82.67"W x 69"H
Frame Material	Alloy Steel
Finish Type	Powder Coated
Seat Depth	20 inches
Assembly Required	Yes
Item Weight	95.9 pounds
UPC	840265286104



Image: Product dimensions diagram.

9. WARRANTY AND SUPPORT

YITAHOME is committed to providing quality products and customer satisfaction. For any inquiries, assistance with assembly, missing parts, or warranty claims, please contact YITAHOME Customer Support.

Please have your model number (MAYIH0000225MA) and purchase information ready when contacting support to expedite the process.

For more information or to visit the official store, please refer to the brand's presence on the platform where you purchased the product or visit the [YITAHOME Store](#).