

Manuals.plus /

› Cellularline /

› Cellularline Fast Pad 15W Wireless Charging Base User Manual

## Cellularline WIRELESSPAD15WK

# Cellularline Fast Pad 15W Wireless Charging Base User Manual

Model: WIRELESSPAD15WK

## INTRODUCTION

The Cellularline Fast Pad is a wireless charging base designed to provide fast and efficient charging for Qi-compatible smartphones. With an output of up to 15W, it offers a convenient charging solution for home or office use. This manual provides instructions for the safe and optimal use of your Fast Pad.

## SETUP

- Unpack the Device:** Carefully remove the Fast Pad wireless charging base and the included USB-C cable from its packaging.
- Connect to Power:** Insert one end of the provided USB-C cable into the USB-C input port on the Fast Pad. Connect the other end of the USB-C cable to a compatible power adapter. For optimal fast charging performance (up to 15W), it is essential to use an adaptive AC charger with a minimum output of 18W (not included).
- Placement:** Place the Fast Pad on a flat, stable surface, away from direct sunlight, heat sources, and metallic objects.



*This image displays the Cellularline Fast Pad Wireless Charging Base from a top-down perspective. The circular black pad features a subtle green LED light ring around its perimeter, which illuminates when the device is powered or actively charging. The Cellularline logo is centrally placed on the pad.*

## OPERATING INSTRUCTIONS

- Power On:** Once connected to a power source, the Fast Pad is ready for use. The LED indicator may briefly illuminate

to confirm power.

2. **Place Your Device:** Place your Qi-compatible smartphone directly onto the center of the Fast Pad. Ensure the phone is centered for efficient charging.
3. **Charging Indicator:** The LED ring around the Fast Pad will illuminate, typically green, to indicate that your device is charging. If the LED does not light up or flashes, reposition your device or check the power connection.
4. **Remove Device:** Once your device is fully charged or you wish to stop charging, simply lift it from the Fast Pad.



*This image illustrates a smartphone placed on a wireless charging pad, showing a full battery icon on its screen. The phone is positioned vertically on the circular black pad, demonstrating the device in use during charging.*

## MAINTENANCE

---

- **Cleaning:** Disconnect the Fast Pad from the power source before cleaning. Use a soft, dry, lint-free cloth to wipe the surface. Do not use abrasive cleaners, solvents, or chemical sprays.
- **Storage:** When not in use, store the Fast Pad in a cool, dry place, away from extreme temperatures and humidity.
- **Avoid Damage:** Do not drop, disassemble, or attempt to repair the device yourself. Avoid placing heavy objects on the charging pad.

## TROUBLESHOOTING

---

| Problem                                    | Possible Cause   | Solution   |
|--|--|--|
| Device not charging / LED not lighting up. | Loose connection, incompatible power adapter, misaligned device, non-Qi compatible device. | Ensure the USB-C cable is securely connected to both the Fast Pad and the power adapter. Verify that your power adapter meets the 18W minimum requirement for fast charging. Reposition your smartphone on the center of the pad. Confirm your smartphone supports Qi wireless charging. |
| Slow charging.                             | Power adapter output too low, thick phone case, background apps.                           | Use an 18W or higher adaptive AC charger. Remove thick phone cases or cases with metallic components. Close unnecessary background applications on your phone.   |
| Intermittent charging.                     | Device misalignment, foreign objects, overheating.   | Ensure the phone is perfectly centered on the pad. Remove any foreign objects (e.g., coins, cards) between the phone and the pad. Allow the charger and phone to cool down if overheating is suspected.  |

## SPECIFICATIONS

| Feature                 | Detail  |
|-------------------------|---|
| Brand                   | Cellularline                                      |
| Model Number            | WIRELESSPAD15WK                                   |
| ASIN                    | B0BSH64QGC  |
| Power Output            | Up to 15 Watts                                    |
| Input Voltage           | 9 Volts   |
| Output Voltage          | 5 Volts   |
| Current Rating          | 3 A   |
| Connector Type          | USB Type C  |
| Connectivity Technology | Wireless (Qi Standard)                            |
| Compatible Devices      | Qi-enabled Cellular Phones                        |
| Special Feature         | Wireless Charging                                 |
| Color                   | Black   |
| Item Weight             | 53 Grams  |
| Mounting Type           | Table Mount                                       |
| Included Components     | Wireless charging base, USB-C cable, instructions |
| Manufacturer            | CellularLine S.p.A.                               |
| Country of Origin       | China   |

## WARRANTY INFORMATION

For detailed warranty information regarding your Cellularline Fast Pad Wireless Charging Base, please refer to the warranty card included in the product packaging or visit the official Cellularline website. Warranty terms and conditions may vary by region and retailer.

## CUSTOMER SUPPORT

---

If you encounter any issues or have questions not covered in this manual, please contact Cellularline customer support. You can typically find contact information on the official Cellularline website or through your product retailer.

- **Online Support:** Visit the official Cellularline website for FAQs, support articles, and contact forms.
- **Retailer Support:** Contact the retailer from whom you purchased the product for assistance.