Move2Play N_KSK.104

Move2Play Kids Karaoke Microphone (Model N_KSK.104) Instruction Manual

Model: N_KSK.104 | Brand: Move2Play

Introduction

Welcome to the Move2Play Kids Karaoke Microphone instruction manual. This guide will help you understand the features, setup, and operation of your new karaoke microphone. Designed for children, this Bluetooth-enabled microphone offers high-quality sound, fun voice effects, and a rechargeable battery for hours of entertainment. Please read this manual carefully before use.



Image: The Move2Play Kids Karaoke Microphone in Pink/Purple, showcasing its design and color.

Product Features

- **Customizable Design:** Personalize your microphone with the included jewel stickers.
- **Bluetooth Connectivity:** Easily connect to your smartphone or tablet to play music from various streaming

services.

- **High-Quality Sound:** Equipped with acoustic speakers for clear and powerful audio output.
- **4 Voice Effects:** Transform your voice with fun effects including high-pitched, low-pitched, monster voice, and echo.
- **Rechargeable Battery:** Enjoy up to 6 hours of continuous playtime on a single charge.
- **Easy to Use:** Kid-friendly controls for seamless operation.



Image: A visual breakdown of the microphone's internal components, emphasizing high-quality sound, extended playtime, and user-friendly design.

Setup

1. Unpacking and Initial Charge

Carefully remove the microphone and all accessories from the packaging. The package includes the microphone, a battery, and a USB charging cable. Before first use, fully charge the microphone using the provided USB cable. Connect the USB cable to the microphone's charging port and a compatible USB power source (e.g., computer, wall adapter). The charging indicator light will show the charging status.

2. Personalizing Your Microphone

Unleash your creativity! Use the included jewel stickers to decorate your microphone and make it uniquely yours. Apply the stickers gently to the microphone's handle or body as desired.



Image: Close-up of hands decorating the microphone with colorful jewel stickers.

Operating Instructions

1. Power On/Off

To power on the microphone, press and hold the power button (usually located on the control panel) until you hear an audible prompt or see an indicator light. To power off, press and hold the same button.

2. Bluetooth Pairing

1. Ensure the microphone is powered on and in Bluetooth pairing mode (it may automatically enter this mode upon power-on).

2. On your smartphone or tablet, go to the Bluetooth settings.
3. Search for available devices and select "Kid Star" or "Move2Play" from the list.
4. Once connected, you will hear a confirmation sound from the microphone.



Image: A smartphone displaying Bluetooth connection options, with the Move2Play microphone shown connected, ready for music playback.

Your browser does not support the video tag.

Video: An official product video demonstrating the Bluetooth pairing process and general use of the Move2Play Kids Karaoke Microphone.

3. Music Playback

Once paired, open your favorite music app (e.g., Spotify, YouTube, Apple Music) on your connected device and select a song. The music will play through the microphone's built-in speaker. Use the microphone's control buttons to play/pause, skip tracks, and adjust music volume.

4. Microphone Volume and Echo Control

Adjust the microphone's volume using the dedicated "Mic Vol+" and "Mic Vol-" buttons. The "Echo" slider or button allows

you to add or reduce an echo effect to your voice for a more dynamic karaoke experience.

5. Voice Effects

Press the "Voice FX" button to cycle through the 4 available voice effects: high-pitched, low-pitched, monster voice, and echo. Experiment with these effects to add fun and creativity to your singing.



Image: A visual guide to the microphone's voice effects, showing icons for high-pitched, low-pitched, monster voice, and echo.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the exterior of the microphone. Do not use liquid cleaners or immerse the microphone in water.
- **Storage:** Store the microphone in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

Troubleshooting

- **Microphone not turning on:** Ensure the battery is charged. Connect the USB charging cable and try again.
- **Cannot connect via Bluetooth:** Make sure the microphone is in pairing mode and your device's Bluetooth is enabled. Try restarting both the microphone and your device.
- **No sound from speaker:** Check the volume levels on both the microphone and your connected device. Ensure the microphone is properly paired.
- **Voice effects not working:** Ensure you are pressing the correct "Voice FX" button.

Specifications

Brand	Move2Play
Model Name	N_KSK.104
Color	Pink/Purple
Connectivity Technology	Bluetooth
Connector Type	Bluetooth
Special Feature	Volume Control
Compatible Devices	Smartphone
Included Components	Battery, USB Cable
Polar Pattern	Unidirectional
Recommended Uses	Karaoke

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official Move2Play website. Keep your purchase receipt for warranty claims.

© 2026 Move2Play. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question