Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VICLLAX SR0606GYA

VICLLAX Outdoor Roller Shade Instruction Manual

Model: SR0606GYA | Brand: VICLLAX

1. Introduction

Thank you for choosing the VICLLAX Outdoor Roller Shade. This manual provides essential information for the safe and correct installation, operation, and maintenance of your roller shade. Please read these instructions thoroughly before installation and retain them for future reference.

This outdoor roller shade is designed to provide shade and privacy for various outdoor spaces such as porches, gazebos, patios, backyards, decks, balconies, and pergolas. It is constructed from 210GSM HDPE material, offering up to 95% UV block, weather resistance, and fade resistance.



Image: The roller shade effectively blocks UV rays, filters light, creates a cool zone, and is breathable.


2. Safety Information

- Keep the chain clutch and safety tension device out of reach of children and pets to prevent entanglement hazards.
- Ensure all mounting hardware is securely fastened to a stable surface to prevent the shade from falling.
- Do not attempt to modify the product in any way, as this may compromise its safety and functionality.
- Regularly inspect the shade for any signs of wear or damage. Discontinue use if damage is found and contact customer service.

3. Package Contents

Verify that all components are present before beginning installation.

PACKING





Installation Template





Image: Detailed view of the package contents, including fabric, tubes, brackets, and hardware.

- Shade Fabric (1x)
- Upper Tubes (Quantity varies by size)
- Below Tubes (Quantity varies by size)
- Roller Brackets (2x)
- Plugs (2x)
- Bungee Tie-Downs (2x)
- Screws (Multiple)
- Plastic Anchors (Multiple)
- Installation Template (1x)

4. Specifications

Feature	Detail
Model Number	SR0606GYA
Dimensions (6'x6' model)	72 inches (Width including brackets) x 72 inches (Length/Drop)
Fabric Width (6'x6' model)	69.6 inches
Product Dimensions (Packaged)	4 x 4 x 74 inches
Item Weight	8.8 pounds
Material	210GSM HDPE Fabric
UV Block	Up to 95%
Operation	Corded Chain Clutch





Since the size is manual-measured, please allow 0.5-1.5 inch difference.

Listing Size (Feet)	Blind Maximum Height (Inch)	Blind Width Size (Inch)	Fabric Width Size (Inch)	Wand Length (Inch)
4′x6′	72″	48″	45.6″	47.2″
5′x6′	72″	60″	57.6″	47.2″
6′x6′	72″	72″	69.6″	47.2″
7′x8′	96″	84″	81.5″	47.2″
8′x8′	96″	96″	93.5″	47.2″
9′x8′	96″	108″	105.6″	47.2″
10′x8′	96″	120″	117.6″	47.2″

Image: Size chart illustrating blind width (including brackets), fabric width, and blind height for different models.

5. Installation Guide

The VICLLAX Outdoor Roller Shade offers a 2-in-1 installation approach: Wall Mount or Ceiling Mount. Choose the method that best suits your outdoor space.

5.1 Mounting Options



Image: Comparison of Wall Mount (allows side light penetration) and Ceiling Mount (reduces side light for better shading and privacy).

- **Wall Mount:** The shade is mounted directly onto a vertical surface. This option may allow some light to penetrate from the sides.
- **Ceiling Mount:** The shade is mounted to an overhead horizontal surface. This option generally provides better shading and privacy by reducing side light penetration.

5.2 Assembly Steps

Follow these steps to assemble and install your roller shade:



Image: Visual instructions for connecting tubes, attaching fabric, and preparing for mounting.

1. **Prepare the Fabric:** Unfold the one-piece fabric.
2. **Assemble Tubes:** Connect the upper and lower tubes using the provided connectors. Ensure they are securely joined to form the full width of the shade.
3. **Attach Fabric to Tubes:** Carefully attach the shade fabric to the assembled tubes. Ensure the fabric is evenly aligned and secured.
4. **Install Brackets:** Use the installation template to mark drill holes for the roller brackets. Drill pilot holes and secure the brackets using the provided screws and plastic anchors.
5. **Mount the Shade:** Insert the assembled roller shade into the installed brackets. Ensure it clicks securely into place.
6. **Attach Plugs:** Insert the plugs into the ends of the bottom tube.

5.3 Adjusting Chain Direction (Optional)

The chain clutch can be optionally placed on the left or right side. If you need to switch the chain direction or adjust for

wall mounting from a ceiling setup, follow these steps:



Image: Instructions for ensuring the chain pulls towards the ground and how to convert from ceiling to wall mounting.

1. Ensure the pulling direction of the chain is always towards the ground for proper operation.
2. To switch from ceiling to wall mounting, carefully detach the bracket cover, reorient the mechanism as shown in the diagram, and reattach the cover.

6. Operating Instructions

Your VICLLAX Outdoor Roller Shade is operated using a corded chain clutch system.



Image: Close-up of the chain mechanism and the bungee tie-down system.

- **Raising/Lowering the Shade:** Gently pull the chain to raise or lower the shade to your desired position. The chain clutch system allows for smooth and controlled movement.
- **Securing the Shade:** Use the provided bungee tie-downs to secure the bottom of the shade. This prevents the shade from flapping excessively in windy conditions. Attach the bungee cords to the plugs on the bottom tube and secure them to a fixed point.
- **Safety Tension Device:** Ensure the safety tension device for the chain is properly installed and secured to the wall or frame. This keeps the chain taut and reduces the risk of entanglement for children and pets.

7. Maintenance

Proper maintenance will extend the life of your VICLLAX Outdoor Roller Shade.

- **Cleaning:** The HDPE fabric can be cleaned with a soft brush or cloth and mild soap and water. Rinse thoroughly with clean water and allow to air dry completely before rolling up. Do not use harsh chemicals or abrasive cleaners.
- **Inspection:** Periodically check the chain, brackets, and fabric for any signs of wear, damage, or loose connections.

- **Lubrication:** The internal mechanisms generally do not require lubrication. If operation becomes stiff, ensure the chain is clean and free of debris.
- **Storage:** In extreme weather conditions or during long periods of non-use, it is recommended to roll up the shade to protect it from damage.

8. Troubleshooting

Problem	Possible Cause	Solution
Shade does not roll up or down smoothly.	Chain is tangled or obstructed. Mechanism is dirty.	Check the chain for tangles and clear any obstructions. Clean the chain and mechanism if necessary.
Shade falls or is not secure.	Brackets are loose or improperly installed.	Ensure all screws are tightened and brackets are securely mounted to a stable surface. Re-install if necessary.
Shade flaps excessively in wind.	Bungee tie-downs are not used or improperly secured.	Always use the bungee tie-downs to secure the bottom of the shade to prevent flapping.
Chain clutch does not hold position.	Internal clutch mechanism issue.	Contact customer service for assistance.

9. Warranty and Support

VICLLAX is committed to providing quality products and customer satisfaction. This product comes with a hassle-free customer service and free replacement policy for manufacturing defects.

For any questions, concerns, or to report a defect, please contact VICLLAX customer service through the retailer's platform or the official VICLLAX website. Please have your model number (SR0606GYA) and purchase information ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BSL7BX1R

More documents and user manuals: **https://manuals.plus/**