

Casio EFB-680D-1AVUDF

Casio Edifice EFB-680D-1AVUDF Watch Instruction Manual

Model: EFB-680D-1AVUDF

INTRODUCTION

This manual provides detailed instructions for the proper use and care of your Casio Edifice EFB-680D-1AVUDF chronograph watch. Please read this manual thoroughly to ensure optimal performance and longevity of your timepiece. Keep this manual for future reference.

SETUP

1. Time Setting

To set the time on your watch:

1. Pull the crown out to the second click position. The second hand will move to the 12 o'clock position.
2. Rotate the crown to set the hour and minute hands to the desired time. Ensure the AM/PM setting is correct if your watch has a 24-hour indicator.
3. Push the crown back in to the normal position. The second hand will resume movement.



Image: Side view of the watch, illustrating the crown and pushers used for time setting and chronograph operation.

2. Date Setting

To set the date:

1. Pull the crown out to the first click position.
2. Rotate the crown to adjust the date. Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back in to the normal position.

3. Band Adjustment

The stainless steel band can be adjusted by adding or removing links to achieve a comfortable fit. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch technician to prevent damage to the band or clasp.



Image: The watch displayed on a wrist, demonstrating how the band fits. Proper band adjustment ensures comfort and security.

OPERATING THE CHRONOGRAPH

Your Casio Edifice EFB-680D-1AVUDF features a 1/10-second chronograph for measuring elapsed time.

1. **Starting a Measurement:** Press button A (top right pusher) to start the chronograph. The chronograph second hand and 1/10-second hand will begin moving.
2. **Stopping a Measurement:** Press button A again to stop the chronograph. The elapsed time will be displayed.
3. **Resetting the Chronograph:** After stopping, press button B (bottom right pusher) to reset the chronograph hands to the 12 o'clock position.
4. **Split Time Measurement:**
 - Press button A to start.
 - Press button B to record a split time. The chronograph hands will stop to indicate the split time, while internal timing continues.
 - Press button B again to release the split time and display the current elapsed time.
 - Press button A to stop the measurement.

- Press button B to reset.

The chronograph has a measuring capacity of 59 minutes, 59.9 seconds.

MAINTENANCE AND CARE

1. Water Resistance

This watch is water-resistant up to 100 meters (10 ATM). This means it is suitable for everyday use, swimming, and snorkeling. **Do not operate the crown or pushers while the watch is wet or submerged in water**Avoid exposing the watch to hot water or steam, as this can compromise the water resistance seals.

2. Cleaning

Wipe the watch case and band periodically with a soft, dry cloth to remove dirt and moisture. For stainless steel bands, a soft brush and mild soapy water can be used, followed by thorough rinsing and drying. Ensure the crown is pushed in before cleaning with water.

3. Battery Replacement

The watch is powered by an SR920SW battery with an approximate life of 3 years. When the battery runs low, the second hand may start moving at two-second intervals to indicate a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and function.

4. Sapphire Crystal Care

The watch features a sapphire crystal with a glare-resistant coating, known for its high scratch resistance. While highly durable, it is not entirely scratch-proof. Avoid direct impact or contact with extremely hard materials to prevent damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs inaccurately.	Low battery.	Replace the battery at an authorized service center.
Chronograph hands do not reset to 12 o'clock.	Misalignment after impact or battery change.	Refer to the Casio official website for specific chronograph hand alignment procedures for your model, or consult a service center.
Water ingress.	Crown/pushers operated underwater, or seals compromised.	Immediately take the watch to an authorized service center for inspection and repair. Do not attempt to dry it yourself.

SPECIFICATIONS

Model: EFB-680D-1AVUDF

Case / Bezel Material: Stainless Steel

Band Material: Stainless Steel

Crystal: Sapphire crystal with glare-resistant coating

Water Resistance: 100 meters (10 ATM)

Movement: Quartz

Accuracy: ± 20 seconds per month

Battery Type: SR920SW

Approx. Battery Life: 3 years

Chronograph: 1/10-second stopwatch, Measuring capacity: 59'59.9", Measuring modes: Elapsed time, split time, 1st-2nd place times

Dimensions (H x W x D): Approximately 46.0 x 45.8 x 10.5 mm (Case diameter 45.8mm, Case thickness 10.5mm)

Weight: Approximately 151 g

Clasp Type: One-touch 3-fold Clasp, Double Locking Foldover Clasp



Image: A side profile view of the watch, highlighting its slim design and case construction.



Image: Rear view of the watch, showing the screw lock back and engraved model information.

WARRANTY INFORMATION

Your Casio Edifice EFB-680D-1AVUDF watch comes with a manufacturer's warranty. For specific details regarding the warranty period, coverage, and terms, please refer to the warranty card included with your purchase or visit the official Casio website. Extended warranty options may also be available from authorized retailers.

CUSTOMER SUPPORT

For further assistance, technical support, or service inquiries, please contact Casio customer support. You can find contact information and frequently asked questions on the official Casio website:

Manufacturer: Casio India Co Pvt Ltd

Address: A-41, 1st Floor, MCIE, Mathura Road, New Delhi-110044, India

Official Casio Website: www.casio.com/in/

