

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Summer Infant](#) /
- › [Summer Infant 3Dlite Wagon Lightweight Stroller Instruction Manual](#)

## Summer Infant 32123

# Summer Infant 3Dlite Wagon Lightweight Stroller Instruction Manual

Model: 32123

## INTRODUCTION

---

Welcome to the Summer Infant 3Dlite Wagon Lightweight Stroller manual. This guide provides essential information for the safe and proper assembly, operation, and maintenance of your stroller. Designed for convenience and durability, this wagon stroller accommodates two children, offering a comfortable and secure ride for your family's adventures.



Image: The Summer Infant 3Dlite Wagon Lightweight Stroller, showcasing its design and seating for two children.

## IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before using this product. Failure to follow these instructions could result in serious injury or death.

- **Maximum Weight Capacity:** This stroller is designed to accommodate up to 50 pounds per child. Do not exceed this weight limit.
- **Seating Capacity:** Designed for two children. Ensure both children are properly secured.
- **Harness System:** Always use the 3-point harness system to secure your child in the stroller. Ensure straps are adjusted snugly.
- **Adult Supervision:** Never leave children unattended in the stroller.
- **Brakes:** Always engage the brakes when the stroller is stationary.
- **Folding/Unfolding:** Keep children clear of moving parts when folding or unfolding the stroller to prevent injury.
- **Stability:** Do not overload the storage basket or hang bags on the handles, as this may cause the stroller to become

unstable and tip over.

- **Safety Certifications:** This product meets ASTM and JPMA safety standards.

## SETUP AND ASSEMBLY

---

The Summer Infant 3Dlite Wagon is designed for quick and easy assembly. Most components come pre-assembled, requiring only the attachment of the wheels and minor adjustments.

1. **Unboxing:** Carefully remove all components from the packaging. Retain packaging for future storage or transport if needed.
2. **Unfolding the Wagon:** Place the folded wagon on a flat surface. Release any locking mechanisms and gently pull the frame upwards until it clicks into its fully open position. Ensure all frame locks are engaged.
3. **Attaching the Wheels:** Locate the four wheels. Align each wheel with its corresponding axle on the stroller frame and push firmly until it clicks securely into place. Verify that all wheels are properly attached by gently pulling on them.
4. **Canopy and Accessories:** Attach the canopy by sliding its connectors into the designated slots on the frame. Ensure the mosquito nets are properly zipped and secured if desired. Install the child snack trays and parent cup/phone holders as needed by sliding them into their respective attachment points.

Your browser does not support the video tag.

Video: An overview of the 3Dlite Wagon Convenience Stroller, demonstrating its features and ease of use.

## COMPONENTS OVERVIEW

---

- **Adjustable UPF 35+ Canopy:** Provides sun protection for children. Features zip-out mosquito nets for added insect protection.
- **Child Snack Trays & Cup Holders:** Two individual trays with cup holders for each child.
- **Parent Cup & Cell Phone Holder:** Conveniently located on the handle for adult beverages and devices.
- **3-Point Safety Harnesses:** Securely holds children in place.
- **Anti-Shock Front and Rear Wheels:** Designed for a smoother ride over various terrains.
- **Rear Storage Basket:** Provides ample space for essentials.
- **Durable Steel Frame:** Ensures stability and longevity.

Adjustable  
UPF 35+ canopy

Zip-out  
mosquito  
nets

Adult  
cup holder +  
cell phone  
holder



Anti-shock front  
and rear wheels



Rear storage  
basket



2 child snack trays  
and cup holders

Image: Detailed view of the stroller's features, including the canopy, snack trays, and wheels.

## OPERATING INSTRUCTIONS

### Securing Your Child

1. Place your child in the seating area.
2. Fasten the 3-point harness by connecting the buckle. Adjust the straps to ensure a snug and secure fit around your child.



## Holds 2 children at once including 3-point harnesses for safety

Image: Two children seated in the wagon, demonstrating the 3-point harnesses for safety.

### Canopy and Mosquito Net Use

- To extend the canopy, pull it forward until it reaches the desired position.
- To deploy the mosquito nets, unzip them from the canopy and secure them around the seating area using the attached snaps or elastic bands.

### Folding and Unfolding

- **Folding:** Ensure children are removed from the stroller. Engage the brakes. Locate the folding mechanism (typically a lever or button on the handle or frame). Follow the instructions to collapse the stroller until the auto-lock engages.
- **Unfolding:** Release the auto-lock mechanism. Pull the handle upwards until the frame fully extends and locks into place.

Lightweight  
(24 lbs/10.9 kg)  
compact fold



Auto-lock for easy travel and storage

Image: The stroller in its compact folded state, highlighting its portability.

## Brake System

The stroller features individual brakes on the rear wheels. To engage, press down firmly on the brake levers located near each rear wheel until they lock. To release, lift the levers upwards.

## MAINTENANCE

- **Fabric Care:** Clean minor stains on fabric components with cold water and mild soap. Air dry thoroughly.
- **Frame and Plastic Parts:** Clean plastic and metal surfaces with a soft, damp cloth.
- **Regular Checks:** Periodically inspect all parts for wear, damage, or loose fasteners. Do not use if any part is damaged.

## TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly.	Locking mechanisms are not fully disengaged/engaged.	Ensure all levers and buttons are pressed firmly. Check for obstructions.
Wheels are stiff or squeaky.	Dirt or debris in wheel axles; lack of lubrication.	Clean wheels and axles. Apply a small amount of silicone-based lubricant if necessary.
Harness is difficult to buckle/unbuckle.	Debris in buckle; misaligned straps.	Clear any debris from the buckle. Ensure straps are not twisted and are correctly aligned.

## SPECIFICATIONS

Feature	Detail
Brand	Summer Infant
Model Number	32123
Maximum Weight Recommendation	50 Pounds
Seating Capacity	2 Children
Harness Type	3 Point
Item Weight	24 Pounds
Folded Size	23.5"L x 31"W x 17"H
Item Dimensions (L x W x H)	39.37"L x 21.26"W x 44.49"H
Frame Material	Alloy Steel
Material Type	Metal, Fabric, Plastic
Specification Met	ASTM, JPMA



Image: Stroller dimensions for reference.

## WARRANTY AND SUPPORT

This Summer Infant 3Dlite Wagon Lightweight Stroller is covered by a **90 Days Limited Manufacturer Warranty**. For support or warranty claims, please contact Summer Infant customer service directly.