Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Samsung SM-X200NZAQXAR

SAMSUNG Galaxy Tab A8 10.5" Tablet User Manual

Model: SM-X200NZAQXAR

1. Product Overview

The SAMSUNG Galaxy Tab A8 is a versatile 10.5-inch tablet designed for general entertainment, productivity, and on-the-go use. It features a vibrant LCD screen, ample storage, and a long-lasting battery, making it suitable for various daily tasks.



Figure 1: The SAMSUNG Galaxy Tab A8 tablet, showcasing its sleek design and 10.5-inch display. The tablet is gray and appears to be lying flat on a textured surface.

Key Features:

- **Immersive Screen Experience:** Enjoy content on a 10.5-inch LCD screen.
- **Power and Storage:** Equipped with an upgraded chipset, 32GB of storage, and 3GB RAM for smooth performance.
- **Long-lasting Battery:** Go for hours on a single charge with a 15 Watt Hours battery and fast-charging USB-C port.
- **Dual Cameras:** Features a Rear Camera (13 MP) and a Front Camera (5 MP) for photos and video calls.
- **Dolby Atmos Sound:** Experience enhanced audio with Dolby Atmos surround sound speakers.
- **Connectivity:** Supports Wi-Fi and Bluetooth wireless technologies.

2. Setup

Follow these steps to set up your new SAMSUNG Galaxy Tab A8.

1. **Charge the Tablet:** Before first use, fully charge the tablet using the provided USB-C cable and power adapter. Connect the USB-C cable to the tablet's USB Type C port and the adapter to a power outlet.
2. **Power On:** Press and hold the Power button (usually located on the side or top edge) until the Samsung logo appears on the screen.
3. **Initial Setup:** Follow the on-screen prompts to select your language, connect to a Wi-Fi network, accept terms and conditions, and sign in with your Google account or create a new one.
4. **Transfer Data (Optional):** If you are upgrading from another device, you may be prompted to transfer data using Samsung Smart Switch or Google's data transfer tools.
5. **Install Apps:** Once setup is complete, you can download applications from the Google Play Store.

3. Operating Instructions

This section covers basic operation of your Galaxy Tab A8.

Power On/Off and Restart:

- **To Power On:** Press and hold the Power button until the Samsung logo appears.
- **To Power Off:** Press and hold the Power button, then tap "Power off" on the screen.
- **To Restart:** Press and hold the Power button, then tap "Restart" on the screen.

Screen Navigation:

- **Home Screen:** Swipe left or right to navigate between home screens.
- **App Drawer:** Swipe up from the bottom of the home screen to access all installed applications.
- **Notifications Panel:** Swipe down from the top of the screen to view notifications and quick settings.
- **Gestures:** Use pinch-to-zoom, tap, and swipe gestures for interaction.

Connecting to Wi-Fi:

1. Go to **Settings** > **Connections** > **Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.

Camera Usage:

- Open the **Camera** app.
- Tap the shutter button to take a photo.
- Switch between front and rear cameras using the camera icon.
- Select video mode to record videos.

4. Maintenance

Proper maintenance ensures the longevity and optimal performance of your tablet.

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive materials or harsh chemicals.
- **Software Updates:** Regularly check for and install software updates to ensure your tablet has the latest features and security patches. Go to **Settings** > **Software update**.
- **Battery Care:** To maximize battery life, avoid extreme temperatures. Do not leave the tablet fully charged or fully discharged for extended periods.

- **Storage Management:** Periodically clear unnecessary files and uninstall unused apps to free up storage space and improve performance.
- **Backup Data:** Regularly back up important data to a cloud service or external storage to prevent data loss.

5. Troubleshooting

Refer to this section for solutions to common issues.

- **Tablet Not Powering On:**
  - Ensure the battery is charged. Connect the charger and wait a few minutes before attempting to power on again.
  - Perform a forced restart by holding the Power button and Volume Down button simultaneously for about 7-10 seconds.
- **Screen Unresponsive:**
  - Restart the tablet.
  - If the screen remains unresponsive, try a factory reset (note: this will erase all data).
- **Wi-Fi Connectivity Issues:**
  - Ensure Wi-Fi is enabled in Settings.
  - Restart your Wi-Fi router and the tablet.
  - Forget the network in tablet settings and reconnect.
- **Apps Crashing or Freezing:**
  - Close and reopen the app.
  - Clear the app's cache and data in **Settings** > **Apps**.
  - Ensure the app and tablet software are up to date.

6. Specifications

Detailed technical specifications for the SAMSUNG Galaxy Tab A8 (SM-X200NZAQXAR).

Feature	Detail
Brand	Samsung
Model Name	Galaxy Tab A8
Model Number	SM-X200NZSAXAC (Note: SM-X200NZAQXAR is a variant)
Screen Size	10.5 Inches
Display Type	LED
Native Resolution	1920 x 1200
Memory Storage Capacity	32 GB
RAM Memory Installed	3 GB
Operating System	Android
Processor Brand	ARM

Feature	Detail
Processor Description	arm cortex a8
CPU Model Speed Maximum	2 GHz
Graphics Coprocessor	Mali-G52 MP2
Rear Facing Camera Photo Sensor Resolution	13 MP
Front Photo Sensor Resolution	5 MP
Video Capture Resolution	HD 720p
Battery Power	15 Watt Hours
Connectivity Technology	Wi-Fi
Wireless Technology	Bluetooth, Wi-Fi
Hardware Interface	USB Type C
Total USB Ports	1
Item Weight	1.1 Pounds
Color	Gray
Speaker Description	Dolby Atmos surround sound speakers
Other Special Features	Fast Charging, Lightweight

7. Warranty and Support

The SAMSUNG Galaxy Tab A8 comes with a limited manufacturer's warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official Samsung support website.
For technical assistance, troubleshooting, or service requests, please contact Samsung Customer Support. You can find contact information and additional resources on the official Samsung website.

- **Online Support:** Visit Samsung Support for FAQs, downloads, and service options.
- **Phone Support:** Refer to your product documentation for regional contact numbers.

© 2023 Samsung. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BSN64ST7

More documents and user manuals: **https://manuals.plus/**