Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Catnapper Warner 764862172416

Catnapper Warner Power Headrest Lumbar Power Lift Lay Flat Recliner User Manual

Model: Warner 764862172416

Introduction

This manual provides detailed instructions for the safe and efficient use of your Catnapper Warner Power Headrest with Lumbar Power Lift Lay Flat Recliner. This recliner is designed for enhanced comfort and ease of use, featuring a dual motor system for independent adjustments, a power lift function, and specialized support options.

Please read this manual thoroughly before operating the recliner and retain it for future reference. Ensure all users are familiar with the operating procedures and safety guidelines.



Figure 1: Catnapper Warner Recliner in its standard, upright position. This image shows the overall design and plush chenille fabric.

Setup

While the Catnapper Warner Recliner is largely pre-assembled, some minor setup is required to ensure proper functionality and safety. Follow these steps carefully:

1. **Unpacking:** Carefully remove the recliner from its packaging. Retain all packaging materials until you are satisfied with the product.
2. **Placement:** Position the recliner in your desired location, ensuring there is adequate space behind and in front of the unit for full reclining and ottoman extension. Allow at least 12 inches (30 cm) from any wall for full recline.
3. **Power Connection:** Locate the power cord extending from the recliner's base. Plug the power cord into a grounded 120V AC electrical outlet. Ensure the connection is secure.
4. **Initial Check:** After connecting power, perform a brief test of the controls to ensure all functions (recline, lift, headrest, lumbar) are operational.



Figure 2: Dimensional view of the recliner, indicating height, width, and depth. Ensure sufficient space for operation.

Operating Instructions

Your Catnapper Warner Recliner features advanced power functions for personalized comfort. The recliner is operated via a hand-held remote control (if included) or integrated side panel buttons.

Basic Reclining and Ottoman Control (Dual Motor)

- **Backrest Adjustment:** Use the designated button to recline the backrest backward or bring it forward. The dual motor allows independent movement from the ottoman.
- **Ottoman Extension/Retraction:** Use the designated button to extend the footrest (ottoman) for leg support or retract it. The ottoman can be adjusted independently of the backrest.
- **Lay-Flat Recline:** Continue to recline the backrest and extend the ottoman to achieve a full lay-flat position for maximum relaxation.



Figure 3: The recliner with the ottoman extended, demonstrating a partially reclined position for leg support.



Figure 4: The recliner fully extended into a lay-flat position, offering complete body support.

Power Headrest Adjustment

- Use the dedicated power headrest button to adjust the angle of the headrest for optimal neck and head support.

Power Lumbar Support

- Activate the power lumbar function using its specific button to increase or decrease the lumbar support for your lower back.

Power Lift Function

- From a seated position, press and hold the "Lift" button. The recliner will gently tilt forward and lift, assisting you in standing up.
- To return to a seated position, press and hold the "Lower" button. The recliner will slowly lower and tilt back to a standard seated position.
- **Safety Note:** Ensure the area around the recliner is clear before using the lift function. Do not attempt to stop the lift mechanism manually.



Figure 5: Side profile of the recliner in an upright position, highlighting its robust construction.



Figure 6: Side profile of the recliner in a partially reclined state, showing the mechanism for extension.

Maintenance

Proper care and maintenance will extend the life and performance of your Catnapper Warner Recliner.

Fabric Care (Thick Chenille)

- **Regular Cleaning:** Vacuum the fabric regularly using a soft brush attachment to remove dust and loose debris.
- **Spot Cleaning:** For spills, blot immediately with a clean, dry cloth. Do not rub. For stubborn stains, use a mild, water-free solvent or dry-cleaning product. Always test on an inconspicuous area first.
- **Avoid Harsh Chemicals:** Do not use bleach, abrasive cleaners, or harsh detergents, as these can damage the fabric.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight to prevent fading.

Mechanism and Electrical Components

- **Power Cord:** Periodically inspect the power cord for any damage. If damaged, discontinue use and contact a qualified technician.
- **Moving Parts:** The reclining mechanism is designed for long-term use and typically does not require lubrication. Keep the area around the moving parts clear of obstructions.
- **Cleaning:** Keep the control buttons and remote clean and free of dust. Use a dry cloth for cleaning.

Troubleshooting

If you encounter issues with your recliner, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Recliner does not operate (no power).	Power cord unplugged or loose. Outlet not functioning. Circuit breaker tripped.	Ensure power cord is securely plugged into both the recliner and a working wall outlet. Test the outlet with another device. Check your home's circuit breaker panel.
Motor makes noise but recliner does not move.	Obstruction in mechanism. Mechanism jammed.	Inspect under and around the recliner for any objects obstructing the mechanism. Do not force movement. Contact customer support if obstruction is not visible or easily removed.
Recliner moves slowly or intermittently.	Low power supply. Loose connection.	Ensure the recliner is plugged directly into a wall outlet, not a power strip or extension cord. Check all power connections for tightness.
Power Headrest/Lumbar not adjusting.	Specific motor issue. Control button malfunction.	Verify main power is on. If other functions work, this may indicate a specific motor or control issue. Contact customer support.

If the problem persists after attempting these solutions, please contact customer support.

Specifications

Brand	Catnapper
Model Name	Warner
Model Number	764862172416
UPC	720368871998
Color	Putty
Material	Textile (Thick Chenille Fabric), Memory Foam (Seat/Fill)
Frame Material	Metal
Product Dimensions (D x W x H)	41"D x 38"W x 43"H
Item Weight	151 Pounds
Seat Height	21 Inches

Seat Depth	22 Inches
Seat Length	26.5 Inches
Arm Height	26 Inches
Features	Dual Motor, Power Headrest, Power Lumbar, Power Lift, Lay Flat Recline, Comfort Coil Seating, Comfor-Gel
Assembly Required	Yes (minimal)
Indoor/Outdoor Usage	Indoor

Warranty Information

Specific warranty details for the Catnapper Warner Recliner are typically provided at the point of purchase or included with the product documentation. Please refer to your purchase receipt or contact the retailer from whom you purchased the recliner for comprehensive warranty terms and conditions. Warranty coverage usually includes manufacturing defects and may vary by component.

Customer Support

For technical assistance, parts replacement, or further inquiries regarding your Catnapper Warner Recliner, please contact the retailer where you made your purchase. They can provide specific support tailored to your product and region. You may also visit the official Catnapper website for general product information and potential support contacts.

© 2023 Catnapper. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BSNTXTZ4

More documents and user manuals: **https://manuals.plus/**