

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Casio](#) /

› [Casio Edifice EFV-610D-5CV Chronograph Watch Instruction Manual](#)

Casio EFV-610D-5CV

Casio Edifice EFV-610D-5CV Chronograph Watch

INSTRUCTION MANUAL

Product Overview

This manual provides essential information for the proper use and maintenance of your Casio Edifice EFV-610D-5CV chronograph watch. This timepiece features a 1/10-second stopwatch, date display, and 100-meter water resistance, all encased in durable stainless steel.



Image: Casio Edifice EFV-610D-5CV watch, showcasing its brown dial, three sub-dials, and stainless steel bracelet.

Setup and Initial Settings

Before using your watch, perform the following initial setup steps to ensure accurate timekeeping and functionality.

1. Time Adjustment:

- Pull the crown out to the second click position. The small second hand will stop.
- Rotate the crown to set the hour and minute hands. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator.

- Push the crown back in to the normal position.

2. Date Adjustment:

- Pull the crown out to the first click position.
- Rotate the crown to set the date. Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.
- Push the crown back in to the normal position.

3. Chronograph Hand Zero Position Correction:

If the chronograph hands do not return to the 12 o'clock (zero) position when reset, follow these steps:

- Pull the crown out to the second click position.
- Press button A (top right) to adjust the 1/10-second chronograph hand.
- Press button B (bottom right) to adjust the chronograph minute and second hands.
- Once all chronograph hands are aligned to the 12 o'clock position, push the crown back in to the normal position.

Operating the Chronograph (Stopwatch)

The EFV-610D-5CV features a 1/10-second stopwatch with a measuring capacity of 59 minutes, 59.9 seconds.

1. Measuring Elapsed Time:

- Press button A to start the stopwatch.
- Press button A again to stop the stopwatch.
- Read the elapsed time from the chronograph hands.
- Press button B to reset the chronograph hands to the zero position.

2. Split Time Measurement:

- Press button A to start the stopwatch.
- Press button B to measure a split time. The chronograph hands will stop to indicate the split time.
- Press button B again to release the split time and resume elapsed time measurement.
- Press button A to stop the stopwatch.
- Press button B to reset the chronograph hands to the zero position.

Water Resistance Guidelines

Your Casio Edifice EFV-610D-5CV watch is rated for 100M (10 ATM) water resistance. This means it is suitable for everyday use, showering, swimming, and snorkeling. However, please observe the following precautions:

- Do not operate the crown or buttons while the watch is wet or submerged in water.
- Avoid exposing the watch to hot water, such as in hot showers, saunas, or hot tubs, as this can compromise the water seals.
- After exposure to saltwater, rinse the watch thoroughly with fresh water and wipe it dry.
- Water resistance is not a permanent condition and may be affected by wear and tear or accidental impact. Have your watch inspected periodically by an authorized service center.

Battery Information

The Casio Edifice EFV-610D-5CV uses an SR920SW style battery, which provides an approximate battery life of 2 years under normal usage conditions. When the battery runs low, the watch may exhibit irregular movement or stop entirely. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and functionality.

Maintenance and Care

Proper care will help maintain the appearance and longevity of your watch.

- **Cleaning:** Wipe the watch case and band with a soft, dry cloth to remove dirt and moisture. For stainless steel bands, a soft brush with mild soapy water can be used, followed by thorough rinsing and drying.
- **Temperature:** Avoid exposing the watch to extreme temperatures (below 14°F / -10°C or above 140°F / 60°C) or sudden temperature changes.
- **Magnetic Fields:** Keep the watch away from strong magnetic fields, as they can affect timekeeping accuracy.
- **Shocks:** While durable, avoid strong impacts or dropping the watch.
- **Chemicals:** Avoid contact with gasoline, cleaning solvents, aerosol sprays, adhesives, paints, etc., as they can damage the watch's seals, case, and band.

Troubleshooting

If you encounter issues with your watch, refer to the following common problems and solutions:

- **Watch Not Running:**
 - Check if the crown is pushed in completely.
 - The battery may be depleted. Refer to the 'Battery Information' section.
- **Incorrect Time/Date:**
 - Adjust the time and date as described in the 'Setup and Initial Settings' section.
 - Ensure the crown is fully pushed in after adjustment.
- **Chronograph Hands Not Resetting to Zero:**
 - Perform the 'Chronograph Hand Zero Position Correction' procedure detailed in the 'Setup and Initial Settings' section.
- **Water Inside Watch:**
 - If moisture or condensation appears inside the watch, stop using it immediately and have it inspected by an authorized service center.

Specifications

Model Number	EFV-610D-5CV
Case/Bezel Material	Stainless Steel
Band Material	Stainless Steel
Water Resistance	100 meters (10 ATM)
Chronograph	1/10-second stopwatch, measuring capacity: 59'59.9"

Date Display	Yes
Battery Type	SR920SW
Battery Life	Approx. 2 years

Warranty and Support

Your Casio Edifice EFV-610D-5CV watch is covered by a manufacturer's warranty. Please refer to the warranty card included with your purchase for specific terms and conditions, including warranty period and coverage details.

For technical support, service, or warranty claims, please contact Casio customer service or visit their official website for a list of authorized service centers. Always ensure that any repairs or battery replacements are performed by authorized personnel to maintain the watch's integrity and water resistance.