

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Casio](#) /

› [Casio Edifice EFR-526D-5CV Chronograph Watch User Manual](#)

Casio EFR-526D-5CV

Casio Edifice EFR-526D-5CV Chronograph Watch User Manual

Model: EFR-526D-5CV

PRODUCT OVERVIEW

This manual provides detailed instructions for the Casio Edifice EFR-526D-5CV chronograph watch. Please read this manual carefully to ensure proper use and maintenance of your timepiece.



Image: Casio Edifice EFR-526D-5CV watch, showcasing its silver-tone stainless steel case and band, and the distinctive red-brown chronograph dial with date display.

SETUP

1. Setting the Time

1. Pull the crown out to the **second click position**.
2. Rotate the crown to set the hour and minute hands to the correct time.
3. Push the crown back in to the normal position to start the watch.

2. Setting the Date

1. Pull the crown out to the **first click position**.
2. Rotate the crown to set the date. Avoid setting the date between 9:00 PM and 1:00 AM, as this may interfere with the automatic date change mechanism.
3. Push the crown back in to the normal position.

3. Adjusting the Metal Band

The stainless steel band features a one-touch 3-fold clasp. For initial fitting, the band may need to be adjusted by adding or removing links. This procedure typically requires specialized tools and is best performed by a qualified jeweler or watch technician to prevent damage to the band or clasp.

OPERATING THE CHRONOGRAPH

The Casio Edifice EFR-526D-5CV features a 1/10-second stopwatch function with a measuring capacity of 59 minutes, 59.9 seconds.

Using the Stopwatch:

1. Press button **A** (top right) to start the stopwatch. The 1/10-second hand, second hand, and minute hand will begin to move.
2. Press button **A** again to stop the stopwatch.
3. Press button **B** (bottom right) to reset the stopwatch to zero.

Note: The stopwatch can measure elapsed time, split times, and two finishes. Refer to the full Casio module manual for advanced chronograph operations.

MAINTENANCE

Battery Replacement

This watch uses an SR920SW style battery, providing approximately 2 years of life. When the watch stops or the hands move erratically, it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure proper sealing and water resistance.

Cleaning and Care

- Wipe the watch regularly with a soft, dry cloth to remove dirt and moisture.
- For the stainless steel band, use a soft brush and mild soapy water to clean, then rinse thoroughly with fresh water and dry completely.
- Avoid exposing the watch to extreme temperatures, direct sunlight for prolonged periods, or strong magnetic

fields.

Water Resistance (100M / 10 ATM)

The watch is water resistant to 100 meters (10 ATM), suitable for everyday use, swimming, and snorkeling. It is not suitable for diving. Ensure the crown is pushed in completely before any contact with water. Do not operate buttons or the crown while the watch is wet or submerged.

TROUBLESHOOTING

Problem	Solution
Watch hands do not move.	Check if the crown is pushed in completely. If it is, the battery may need replacement.
Time is incorrect.	Adjust the time as described in the "Setting the Time" section. Ensure the crown is fully pushed in after adjustment.
Chronograph hands do not reset to zero.	Perform a chronograph hand position adjustment. Refer to the full Casio module manual for specific steps, as this often involves pulling the crown and using the buttons to align the hands.

SPECIFICATIONS

- Model Number:** EFR-526D-5CV
- Brand:** Casio Edifice
- Case Material:** Stainless Steel
- Band Material:** Stainless Steel
- Water Resistance:** 100 meters (10 ATM)
- Battery Type:** SR920SW
- Battery Life:** Approximately 2 years
- Chronograph:** 1/10-second stopwatch, measuring capacity 59'59.9"
- Date Display:** Yes
- Approximate Dimensions:** 44mm case diameter
- Approximate Weight:** 8.99 ounces

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Casio website or contact your authorized

Casio dealer. Keep your purchase receipt as proof of purchase for warranty claims.

Official Casio Website: www.casio.com

© 2024 Casio. All rights reserved.