

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

> [Whirlpool](#) /

> [Whirlpool 184 L 3 Star Direct-Cool Single Door Refrigerator User Manual](#)

## Whirlpool 205 WDE PRM 3S

# Whirlpool 184 L 3 Star Direct-Cool Single Door Refrigerator User Manual

Model: 205 WDE PRM 3S

## 1. INTRODUCTION

---

Thank you for choosing the Whirlpool 184 L 3 Star Direct-Cool Single Door Refrigerator, Model 205 WDE PRM 3S. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.

## 2. SAFETY INFORMATION

---

- Ensure the refrigerator is placed on a stable, level surface away from direct sunlight and heat sources.
- Allow adequate ventilation around the appliance. Maintain a minimum clearance of 10 cm from walls.
- Do not store explosive substances or flammable materials inside the refrigerator.
- Keep children away from the appliance and ensure they do not play with it.
- Unplug the refrigerator before cleaning or performing any maintenance.
- Do not damage the refrigerant circuit. If damaged, avoid open flames and ventilate the room.

## 3. SETUP & INSTALLATION

---

### 3.1 Unpacking

Carefully remove all packaging materials, including tape and protective films. Inspect the refrigerator for any damage incurred during transit. Keep packaging materials away from children.

### 3.2 Placement

Place the refrigerator in a dry, well-ventilated area. Ensure there is sufficient space for the door to open fully. The appliance should be leveled using the adjustable feet to ensure proper operation and stability.



Figure 1: Refrigerator dimensions for proper placement.

### 3.3 Electrical Connection

Connect the refrigerator to a dedicated power outlet. This model features **Stabilizer Free Operations**, allowing it to function reliably even with voltage fluctuations between 95V and 300V, eliminating the need for an external stabilizer.

### 3.4 Initial Cleaning

Before first use, clean the interior and exterior of the refrigerator with a soft cloth and mild detergent. Wipe dry thoroughly.

## 4. FEATURES OVERVIEW

Your Whirlpool refrigerator is equipped with several features designed for convenience and efficiency:

- **184 Liters Capacity:** Suitable for families with 2-3 members.
- **3 Star Energy Rating:** High energy efficiency for reduced power consumption.
- **Insulated Capillary Technology:** Ensures up to 9 hours of cooling retention during power cuts.

- **Intellisense Inverter Technology:** Operates efficiently with a low starting voltage of 95V and offers 25 years of compressor reliability (VDE Germany certified).
- **Honeycomb Moisture Lock Crisper Cover:** Maintains optimal moisture levels for fruits and vegetables, keeping them fresh longer.
- **Jumbo Storage:** Dedicated door racks can store up to three 2L bottles and five 1L bottles with ease.
- **Removable Anti-Bacterial Gasket:** Easy to clean, preventing the build-up of fungi and bacteria, ensuring hygiene.
- **Toughened Glass Shelves:** Designed to bear heavy loads, providing durable storage.
- **Auto Connect to Home Inverter:** Automatically switches to home inverter power during outages to maintain freshness.
- **Large Vegetable Crisper:** Provides ample space for storing a variety of vegetables.
- **Large Freezer Capacity:** Offers generous space for frozen items.
- **Base Stand:** An optional feature for convenient storage of items like onions and potatoes outside the main compartment.



Figure 2: Interior features including anti-bacterial gasket, toughened glass shelves, and ample bottle storage.



Figure 3: Key features: Intellisense Inverter, 3 Star Energy Rating, and Fast Ice Making.

## 5. OPERATING INSTRUCTIONS

### 5.1 Temperature Control

The refrigerator's temperature is controlled by a dial located inside the fresh food compartment. Adjust the dial to your desired cooling level. Higher numbers typically indicate colder settings.



Figure 4: Cooling control dial for temperature adjustment.

### 5.2 Manual Defrosting

As a Direct-Cool refrigerator, manual defrosting is required. When frost builds up to about 5mm thickness in the freezer compartment, turn off the refrigerator, remove all food items, and allow the frost to melt naturally. Use a soft cloth to wipe away melted water. Do not use sharp objects to remove ice.

### 5.3 Moisture Control for Crisper

The vegetable crisper features a Honeycomb Moisture Lock cover with an adjustable moisture control knob. Adjust this knob to regulate humidity levels, keeping your fruits and vegetables fresh for longer periods.



Figure 5: Honeycomb Moisture Lock In Technology for optimal freshness.

## 5.4 Using Shelves and Door Racks

Arrange food items on the toughened glass shelves and in the dedicated door racks. The jumbo door storage is designed to accommodate large bottles, such as 2-liter and 1-liter containers.



Figure 6: Jumbo storage for large bottles.

Your browser does not support the video tag.

Video 1: An overview of the Whirlpool WDE Single Door Refrigerator features, including insulated capillary technology, honeycomb moisture lock crisper, jumbo storage, stabilizer-free operation, and auto-connect to home inverter. This video highlights the convenience and efficiency of the appliance.

## 6. MAINTENANCE & CARE

### 6.1 Cleaning

- **Interior:** Clean the interior regularly with a solution of mild soap and warm water. Rinse with clean water and dry thoroughly.
- **Exterior:** Wipe the exterior surfaces with a soft, damp cloth. Avoid abrasive cleaners or solvents.
- **Removable Anti-Bacterial Gasket:** The door gasket can be easily removed for cleaning. Wash it with warm soapy water, rinse, dry, and re-install. This prevents mold and bacterial growth.



Figure 7: Removable anti-bacterial gasket for easy cleaning.

## 6.2 Defrosting Procedure

When frost accumulates to approximately 5mm, initiate manual defrosting. Unplug the refrigerator, remove all contents, and leave the door open. Place towels at the bottom to absorb melted water. Once defrosted, clean and dry the interior before plugging it back in and returning food items.

## 6.3 Power Saving Tips

- Avoid opening the door frequently or for extended periods.
- Ensure the door gasket is clean and seals properly.
- Do not place hot food directly into the refrigerator; allow it to cool first.
- Keep the condenser coils at the back clean and free of dust.

## 7. TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Refrigerator not cooling	Power supply issue, temperature control set too high, door not closed properly.	Check power connection, adjust temperature control, ensure door is sealed.
Excessive frost build-up	Door left open too long, faulty door gasket, high humidity.	Ensure door is closed tightly, clean/replace gasket, perform manual defrost.
Unusual noises	Appliance not level, items vibrating inside, normal compressor operation.	Level the refrigerator, rearrange items, some noises are normal.
Water leakage	Clogged drain tube, improper defrosting.	Clear drain tube, ensure proper manual defrosting.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Whirlpool
Model	205 WDE PRM 3S

Feature	Detail
Capacity	184 litres
Annual Energy Consumption	170 Kilowatt Hours Per Year
Refrigerator Fresh Food Capacity	169.2 litres
Freezer Capacity	14.3 Litres
Bottle Count	4 (implied from feature bullets, can store up to 3x 2L and 5x 1L)
Installation Type	Freestanding
Form Factor	Stand Alone
Special Features	Automatic Defrost (Note: Product description states 'Single door refrigerator with Auto defrost technology' but also 'Easy Manual Defrosting'. For Direct-Cool, manual defrost is typical. The 'Automatic Defrost' in specs might refer to a general feature category, not full frost-free operation.)
Colour	Sapphire Radiance-Z
Voltage	220V (Stabilizer free operation 95V-300V)
Number of Drawers	4 (This likely refers to crisper and other small compartments)
Defrost System	Automatic (As per specs, but manual defrost is required for Direct-Cool)
Door Orientation	Left
Door Material	Stainless Steel
Shelf Type	Toughened Glass
Number of Shelves	2
Material	Stainless Steel
Included Components	1 Refrigerator, 1 Egg Tray, 1 Ice Tray, 1 Instruction Manual, 1 Key
Item Weight	33 kg 400 g
Item Dimensions (LxWxH)	65.1 x 53.5 x 118.8 Centimeters

## 9. WARRANTY & SUPPORT

---

Your Whirlpool refrigerator comes with comprehensive warranty coverage:

- **Product Warranty:** 1 year on the entire product.
- **Compressor Warranty:** 10 years on the compressor, with 25 years reliability certified by VDE Germany.

For any service requests, technical assistance, or warranty claims, please contact Whirlpool customer support. Refer to the contact information provided in your purchase documentation or visit the official Whirlpool website.