

[Manuals.plus](#) /

> [WINIA](#) /

> Winia KOS-1N5HSS Microwave Oven User Manual

WINIA KOS-1N5HSS

Winia KOS-1N5HSS Microwave Oven User Manual

Model: KOS-1N5HSS | Brand: WINIA

INTRODUCTION

This manual provides essential instructions for the safe and efficient operation of your new Winia KOS-1N5HSS Microwave Oven. Please read it thoroughly before using the appliance and retain it for future reference.

IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, injury to persons, or exposure to excessive microwave energy when using your appliance, follow basic precautions, including the following:

- Read all instructions before using the appliance.
- Do not attempt to operate this oven with the door open as this can result in harmful exposure to microwave energy.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Do not use corrosive chemicals or vapors in this appliance.
- Only allow children to use the oven without supervision when adequate instructions have been given.
- Always use microwave-safe cookware.
- Never operate the oven empty.

SETUP AND INSTALLATION

Unpacking

Carefully remove the microwave oven from its packaging. Remove all packing materials, including any protective film or tape from the oven surfaces and accessories. Inspect the oven for any damage, such as a misaligned door, dents, or a broken door latch. Do not operate the oven if it is damaged.

Placement

Place the microwave oven on a flat, stable surface that can support its weight. Ensure there is adequate ventilation around the oven. Maintain a minimum clearance of 10 cm (4 inches) from the rear and sides, and 30 cm (12 inches) from the top

to allow for proper airflow.




Figure 1: Microwave dimensions and recommended clearances for proper ventilation. The unit measures approximately 54 cm wide, 41.3 cm high, and 31.3 cm deep.

Power Connection

Plug the power cord into a grounded electrical outlet. Ensure the voltage matches the requirements specified on the appliance label.

OPERATING INSTRUCTIONS

Your Winia KOS-1N5HSS microwave oven features a digital LED display and a user-friendly control panel.

Control Panel Overview




Figure 2: Detailed view of the digital control panel, showing buttons for automatic menus, power levels, and time settings.

Basic Microwave Cooking

1. Place food in a microwave-safe container on the turntable.
2. Close the oven door securely.
3. Press the "Micro." button to select microwave cooking.
4. Use the number pad to enter the desired cooking time.
5. Press "Inicio (+30seg.)" to start cooking.

Power Levels

The oven offers 5 power levels for various cooking needs. After setting the cooking time, you can adjust the power level by pressing the "Micro." button repeatedly or using a dedicated power level button if available (refer to Figure 2 for specific button layout).



Figure 3: Visual representation of adjustable power levels, indicating the microwave's capability to vary heating intensity.

Automatic Menus

The microwave includes 8 automatic menus for common food items. Simply select the desired menu and the oven will automatically set the appropriate cooking time and power level.

- Baked Potatoes
- Pasta
- Pizza
- Popcorn
- Vegetables
- Beverages
- Meat
- Reheat
- Fish



Figure 4: Examples of automatic menu functions: preparing popcorn and reheating food.

Defrosting

To defrost food, press the "Descong." button and enter the weight of the food or the desired defrosting time. The oven will automatically calculate the appropriate defrosting settings.



Figure 5: Icon representing the defrosting function, designed to thaw frozen items efficiently.

Express Function (+30 sec)

Press the "Inicio (+30seg.)" button to start cooking immediately for 30 seconds at full power. Each subsequent press adds 30 seconds to the cooking time.

Child Lock

To activate the child lock, press and hold the "Parar/Borrar" button for 3 seconds. The display will show a lock indicator. To deactivate, repeat the process.

CARE AND MAINTENANCE

Cleaning the Oven Interior

The oven cavity is designed for easy cleaning. After each use, wipe the interior with a damp cloth to remove food splatters. For stubborn stains, use a mild detergent and water, then wipe clean with a damp cloth. Do not use abrasive cleaners or scouring pads.

Cleaning the Exterior

Wipe the exterior surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials that could damage the silver mirror finish.

Cleaning the Turntable

The glass turntable and roller ring can be removed for cleaning. Wash them in warm, soapy water or in the dishwasher. Ensure they are completely dry before placing them back in the oven.

TROUBLESHOOTING GUIDE

Problem	Possible Cause	Solution
Oven does not start	Power cord not securely plugged in. Door not closed properly.	Check power connection. Ensure door is firmly closed.
Food not heating	Incorrect cooking time or power level. Microwave-safe cookware not used.	Adjust cooking time/power. Use appropriate cookware.
Sparkling inside oven	Metal objects or foil inside. Damaged oven interior.	Remove all metal. Contact service if interior is damaged.
Display shows "LOCK"	Child lock is activated.	Press and hold "Parar/Borrar" for 3 seconds to deactivate.

PRODUCT SPECIFICATIONS

- Brand:** WINIA
- Model Number:** KOS-1N5HSS
- Color:** Silver Mirror
- Capacity:** 1.5 cubic feet
- Power Output:** 1000 Watts
- Material:** Stainless Steel
- Product Dimensions (W x D x H):** 54 cm x 31.3 cm x 41.3 cm (approximately 21.26 x 12.32 x 16.26 inches)
- Product Weight:** 14 kg (approximately 30.86 lbs)
- Special Features:** Control panel lock, LED display, Digital panel, Easy-to-clean cavity, 5 Power levels, 8 Automatic menus, Express function, Clock function.
- Components Included:** Turntable ring

WARRANTY AND SUPPORT

This Winia KOS-1N5HSS Microwave Oven comes with a **3-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.

For technical support, service, or warranty inquiries, please refer to the contact information provided with your product packaging or visit the official WINIA website.

