

[manuals.plus](#) /

› [Nautica](#) /

› **Nautica Men's NAPNOS302 Nautica One Black Silicone Strap Watch User Manual**

Nautica NAPNOS302

Nautica Men's NAPNOS302 Nautica One Black Silicone Strap Watch User Manual

Model: NAPNOS302

INTRODUCTION

This manual provides comprehensive instructions for the Nautica Men's NAPNOS302 Nautica One Black Silicone Strap Watch. Please read this manual carefully to ensure proper use and maintenance of your timepiece. This watch features a bold 48mm recycled stainless-steel case, chronograph movement, and a date window, complemented by a black silicone strap.



Image 1: Front view of the Nautica NAPNOS302 watch, showcasing the black dial, chronograph sub-dials, and yellow accents.

WATCH COMPONENTS

Familiarize yourself with the main components of your Nautica NAPNOS302 watch:

- **Crown:** Used for setting time and date.
- **Pushers (A & B):** Operate the chronograph functions.
- **Bezel:** Rotatable ring with markings, often used for timing.
- **Dial:** Displays time, date, and chronograph sub-dials.
- **Hands:** Hour, minute, second, and chronograph hands with luminous infill.
- **Date Window:** Displays the current date.
- **Silicone Strap:** Adjustable strap for comfortable wear.
- **Case Back:** Screw-down design for water resistance.



Image 2: Side view of the Nautica NAPNOS302 watch, highlighting the crown and pushers.

INITIAL SETUP

Setting the Time

1. Unscrew the crown by turning it counter-clockwise until it springs out to position 1.
2. Pull the crown out to position 2 (the outermost position).
3. Turn the crown clockwise or counter-clockwise to set the hour and minute hands. Ensure the AM/PM is correctly set if your watch has a 24-hour indicator.
4. Once the time is set, push the crown back to position 1 and screw it clockwise until it is securely tightened against the case to maintain water resistance.

Setting the Date

1. Unscrew the crown by turning it counter-clockwise until it springs out to position 1.
2. Pull the crown out to position 1 (the first click).
3. Turn the crown counter-clockwise to set the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
4. Once the date is set, push the crown back to position 1 and screw it clockwise until it is securely tightened against the case.

OPERATING INSTRUCTIONS

Using the Chronograph

The chronograph function allows you to measure elapsed time.

1. **Start/Stop:** Press pusher A (top pusher) to start the chronograph. Press it again to stop.
2. **Reset:** While the chronograph is stopped, press pusher B (bottom pusher) to reset all chronograph hands to their zero positions.

Water Resistance

Your Nautica NAPNOS302 watch is water-resistant to 100 meters (330 feet). This means it is suitable for swimming and snorkeling, but not for scuba diving. Ensure the crown is always securely screwed down to maintain water resistance. Do not operate the crown or pushers while the watch is wet or submerged.

CARE AND MAINTENANCE

- **Cleaning:** Wipe the watch case and strap with a soft, damp cloth. For silicone straps, mild soap and water can be used, then rinse thoroughly and dry.
- **Avoid Chemicals:** Do not expose your watch to harsh chemicals, solvents, or detergents, as these can damage the case, strap, or seals.
- **Temperature Extremes:** Avoid exposing the watch to extreme temperatures (hot or cold) or sudden temperature changes, which can affect its accuracy and water resistance.
- **Impact:** Protect your watch from strong impacts or shocks.
- **Battery Replacement:** When the battery needs replacement, it is recommended to have it done by an authorized service center to ensure proper sealing and water resistance.



Image 3: Back view of the Nautica NAPNOS302 watch, showing the screw-down case back and strap attachment.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Watch stops or runs inaccurately.	Low battery.	Replace battery at an authorized service center.
Water inside the watch.	Crown not securely screwed down, or seals compromised.	Immediately take to an authorized service center. Ensure crown is always tightened.
Chronograph hands do not reset to zero.	Requires calibration.	Consult the full movement manual or an authorized service center for calibration instructions.

SPECIFICATIONS

Model Number: NAPNOS302

Case Material: IP Black 48mm recycled (85%) stainless steel

Crystal: Mineral Glass

Movement: Chronograph with date function

Dial: Black with luminous hands

Strap Material: Black Silicone (22x22mm)

Water Resistance: 100 meters (330 feet)

Case Back: Screw-down

Crown: Screw-down

Manufacturer: Timex (as per product data)

Product Dimensions: 4.72 x 4.72 x 4.72 inches; 9.52 ounces

WARRANTY INFORMATION

Nautica watches typically come with a limited warranty covering manufacturing defects. Please refer to the warranty card included with your purchase for specific terms, conditions, and duration. Keep your proof of purchase for warranty claims.


CUSTOMER SUPPORT


For further assistance, service, or warranty inquiries, please contact Nautica customer support or visit the official Nautica website. Contact information can usually be found on the warranty card or the brand's official online presence.

You can visit the [Nautica Store on Amazon](#) for more product information.

© 2025 Nautica. All rights reserved.


Related Documents - NAPNOS302

	<p>Nautica T300 True Wireless Stereo Earbuds User Guide Features, Specs, and Support</p> <p>Comprehensive user guide for the Nautica T300 True Wireless Stereo Earbuds with Charging Case. Learn about features, setup, safety, warranty, and technical specifications.</p>
	<p>Nautica T220 True Wireless Stereo Earbuds with Charging Case - User Manual</p> <p>Get detailed instructions for your Nautica T220 True Wireless Stereo Earbuds. This guide covers setup, pairing, charging, technical specs, safety, and warranty. Visit technofashion.com for support.</p>
	<p>Nautica T120 True Wireless Stereo Earbuds User Manual & Specifications</p> <p>Comprehensive user guide and technical specifications for Nautica T120 True Wireless Stereo Earbuds with Charging Case. Learn how to use, pair, charge, and maintain your earbuds. Includes safety information and warranty details.</p>
	<p>Инструкция по эксплуатации часов Nautica: Полное руководство пользователя</p> <p>Подробное руководство пользователя для часов Nautica. Узнайте о функциях, настройке и уходе за вашими часами Nautica, включая водостойкость, подсветку INDIGLO и различные модели.</p>



[Nautica H110 Bluetooth Stereo Sport Earphones User Manual and Specifications](#)

Official user manual and technical specifications for the Nautica H110 Bluetooth Stereo Sport Earphones, covering setup, usage, safety, warranty, and troubleshooting.



[Nautica T200 True Wireless Stereo Earbuds with Charging Case - User Manual and Specifications](#)

Comprehensive user manual for Nautica T200 True Wireless Stereo Earbuds, covering setup, usage, safety, technical specifications, and warranty information. Learn how to pair, charge, and maintain your earbuds.