Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Logitech /
- > Logitech Pebble Keys 2 K380s Multi-Device Bluetooth Wireless Keyboard User Manual

Logitech K380s

Logitech Pebble Keys 2 K380s User Manual

Model: 920-011775

1. SETUP

1.1 Unboxing and Initial Setup

Your Logitech Pebble Keys 2 K380s keyboard comes with 2 AAA batteries included. Locate the battery compartment on the underside of the keyboard and ensure the batteries are correctly inserted. The keyboard is ready for use once powered on.

IN THE BOX







Description: An image showing the Logitech Pebble Keys 2 K380s keyboard alongside two AAA batteries, illustrating the contents typically found in the product packaging.


1.2 Powering On/Off

To power on the keyboard, locate the small switch on the left side of the keyboard and slide it to the 'On' position. A small LED indicator will light up briefly. To power off, slide the switch back to the 'Off' position to conserve battery life.

1.3 Bluetooth Pairing

The Pebble Keys 2 K380s supports multi-device connectivity, allowing you to pair with up to three different devices. Use the Easy-Switch buttons (labeled 1, 2, and 3) located at the top-left of the keyboard.

- 1. Turn on the keyboard.
- 2. Press and hold one of the Easy-Switch buttons (1, 2, or 3) for 3 seconds until the LED indicator above the button starts blinking rapidly. This indicates the keyboard is in pairing mode.
- 3. On your device (computer, tablet, or phone), open your Bluetooth settings and select 'Logitech K380s' from the list of available devices.
- 4. Follow any on-screen prompts to complete the pairing process. The LED indicator on the keyboard will turn solid for 5 seconds and then turn off, confirming successful pairing.



Description: An image illustrating the Logitech Pebble Keys 2 K380s keyboard simultaneously connected to a desktop computer and an iPad, highlighting its multi-device pairing feature.


1.4 Logi Options+ App Installation

For enhanced customization and functionality, download and install the Logi Options+ App from logi.com/optionsplus. This application allows you to personalize Fn shortcut keys and manage device connections.

2. OPERATING

2.1 Typing Experience

The Pebble Keys 2 K380s features scooped, low-profile circular keys designed for a comfortable and quiet laptoplike typing experience. The key layout is optimized for both Windows and macOS, with dual-labeled keys for seamless transition between operating systems.



Description: An image showing a user's hand positioned on the Logitech Pebble Keys 2 K380s keyboard, emphasizing the ergonomic design and the unique round keycaps for a comfortable typing experience.

2.2 Function Keys (Fn Shortcuts)

The top row of keys includes Fn shortcut keys for quick access to various functions such as screen capture, search, voice dictation, and the emoji menu. These keys can be customized using the Logi Options+ App to perform everyday actions or assign specific keyboard shortcuts.

SHORTCUTS JUST A TAP AWAY



Description: A detailed view of the Logitech Pebble Keys 2 K380s keyboard, specifically focusing on the top row of Fn keys that offer customizable shortcuts for various functions.

2.3 Multi-Device Switching

To switch between paired devices, simply press the corresponding Easy-Switch button (1, 2, or 3). The keyboard will instantly connect to the selected device.

2.4 Compatibility

The Logitech Pebble Keys 2 K380s is compatible with a wide range of operating systems, including Windows, macOS, iPadOS, iOS, ChromeOS, and Android, ensuring versatile use across different platforms.

3. MAINTENANCE

3.1 Battery Replacement

The keyboard is powered by 2 AAA batteries, offering an estimated 3-year battery life. When the battery is low, the LED indicator on the keyboard may flash red. To replace the batteries, slide open the battery compartment cover on

the underside of the keyboard, remove the old batteries, and insert new ones, ensuring correct polarity. Close the cover securely.

3.2 Cleaning

To clean your keyboard, power it off. Use a soft, lint-free cloth slightly dampened with water or a mild cleaning solution. Avoid excessive moisture. For debris between keys, use compressed air. Do not immerse the keyboard in liquid.

3.3 Storage

When not in use for extended periods, power off the keyboard to conserve battery life. Store it in a cool, dry place away from direct sunlight and extreme temperatures. Its slim and portable design makes it easy to store in a bag or drawer.

4. TROUBLESHOOTING

4.1 Connection Issues

- **Keyboard not pairing:** Ensure the keyboard is powered on and the LED is blinking rapidly. Check your device's Bluetooth settings to ensure Bluetooth is enabled and the keyboard is discoverable. Try restarting both the keyboard and your device.
- Frequent disconnections: Ensure the keyboard is within the recommended Bluetooth range (typically up to 10 meters or 33 feet). Avoid interference from other wireless devices.

4.2 Key Responsiveness

• **Keys not responding:** Check battery levels and replace if necessary. Ensure the keyboard is properly paired to your device. Clean around the affected keys to remove any debris.

4.3 Battery Life

• Short battery life: Ensure you are using quality AAA batteries. Power off the keyboard when not in use.

4.4 Software Issues (Logi Options+ App)

 App not recognizing keyboard: Ensure the keyboard is connected via Bluetooth. Try restarting the app or reinstalling it.

5. Specifications

Feature	Detail
Brand	Logitech
Model Number	920-011775
Connectivity Technology	Bluetooth Low Energy Technology
Compatible Devices	Personal Computer, Chromebook, Mac
Operating System Compatibility	Windows 10, 11 or later; macOS; iPadOS; iOS; ChromeOS; Android

Power Source	Battery Powered (2 AAA batteries included)
Estimated Battery Life	3 years
Item Weight	14.6 ounces (415g including batteries)
Product Dimensions	10.98 x 4.88 x 0.63 inches (279 x 124 x 16 mm)
Special Feature	Portable, Lightweight, Customizable Shortcuts



Description: A diagram illustrating the physical dimensions of the Logitech Pebble Keys 2 K380s keyboard, including its height, width, thickness, and total weight with batteries.

6. WARRANTY AND SUPPORT

For detailed warranty information and product support, please visit the official Logitech website or contact Logitech customer service. Keep your proof of purchase for warranty claims.

