

JBL p33

Generic JBL p33 Wireless Bluetooth Folding Headset User Manual

Model: JBL p33

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Generic JBL p33 Wireless Bluetooth Folding Headset. Please read this manual thoroughly before using the product to ensure optimal performance and to prevent damage.

2. PRODUCT OVERVIEW

The Generic JBL p33 is a versatile wireless headset designed for audio playback and communication. It features Bluetooth connectivity, a built-in microphone, support for Micro SD cards, and a foldable design for portability. The headset also incorporates sound isolation for an enhanced listening experience.



Figure 1: Front view of the Generic JBL p33 Wireless Bluetooth Folding Headset.

Package Contents:

- Generic JBL p33 Wireless Bluetooth Folding Headset
- USB Charging Cable
- 3.5mm Audio Cable

- User Manual (this document)

Key Features:

- Wireless Bluetooth Connectivity
- Integrated Microphone for Hands-Free Calls
- Micro SD Card Slot for MP3 Playback
- Foldable Design for Easy Storage and Portability
- Sound Isolation for Enhanced Audio Experience
- 3.5mm Audio Jack for Wired Connection

3. SETUP

3.1 Charging the Headset

1. Connect the small end of the USB charging cable to the charging port on the headset.
2. Connect the larger end of the USB charging cable to a USB power adapter (e.g., computer USB port, wall charger).
3. The LED indicator on the headset will illuminate (typically red) during charging.
4. Once fully charged, the LED indicator will typically change color (e.g., blue) or turn off. Disconnect the charging cable.

Note: For first-time use, ensure the headset is fully charged.

3.2 Bluetooth Pairing

1. Ensure the headset is turned off.
2. Press and hold the Power button (often a multi-function button) for approximately 3-5 seconds until the LED indicator flashes rapidly (typically blue and red alternately), indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "JBL p33" (or similar name) from the list of found devices.
5. Once paired, the LED indicator on the headset will typically flash blue slowly or remain solid blue. A voice prompt may confirm successful connection.

Note: If a password is required, enter "0000".

3.3 Micro SD Card Insertion

1. Locate the Micro SD card slot on the headset.
2. Gently insert the Micro SD card with the gold contacts facing downwards (or as indicated by a small icon next to the slot) until it clicks into place.
3. The headset will automatically switch to Micro SD card playback mode if it detects a card with playable audio files.

4. OPERATING INSTRUCTIONS

4.1 Power On/Off

- **Power On:** Press and hold the Power button for approximately 2-3 seconds until the LED indicator lights up

and a voice prompt confirms "Power On".

- **Power Off:** Press and hold the Power button for approximately 3-4 seconds until the LED indicator turns off and a voice prompt confirms "Power Off".

4.2 Volume Control

- **Volume Up:** Short press the "+" button.
- **Volume Down:** Short press the "-" button.

4.3 Music Playback Control

- **Play/Pause:** Short press the Power/Multi-function button.
- **Next Track:** Long press the "+" button.
- **Previous Track:** Long press the "-" button.

4.4 Call Handling

- **Answer Call:** Short press the Power/Multi-function button when an incoming call rings.
- **End Call:** Short press the Power/Multi-function button during a call.
- **Reject Call:** Long press the Power/Multi-function button when an incoming call rings.
- **Redial Last Number:** Double-press the Power/Multi-function button.

4.5 Mode Switching

The headset supports multiple playback modes. Press the "M" (Mode) button to cycle through available modes:

- Bluetooth Mode
- Micro SD Card Mode
- AUX Mode (Wired connection via 3.5mm audio cable)

5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the headset. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use, store the headset in a cool, dry place, away from direct sunlight and extreme temperatures. The foldable design allows for compact storage.
- **Battery Care:** To prolong battery life, charge the headset regularly, even if not used frequently. Avoid fully discharging the battery for extended periods.
- **Water Exposure:** This headset is not waterproof. Avoid exposure to water or excessive moisture.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Headset does not power on.	Low battery.	Charge the headset fully.
Cannot pair via Bluetooth.	Headset not in pairing mode; Bluetooth disabled on device; device too far.	Ensure headset is in pairing mode (flashing red/blue LED). Enable Bluetooth on your device. Move device closer to headset (within 10 meters).

Problem	Possible Cause	Solution
No sound during playback.	Volume too low; headset not connected; incorrect mode.	Increase volume on both headset and connected device. Repair Bluetooth. Ensure correct mode (Bluetooth, SD card, AUX) is selected.
Micro SD card not recognized.	Card inserted incorrectly; unsupported file format; corrupted card.	Re-insert the Micro SD card correctly. Ensure audio files are in a supported format (e.g., MP3). Try a different Micro SD card.
Microphone not working.	Headset not fully connected; microphone muted on device.	Ensure Bluetooth connection is stable. Check microphone settings on your connected device.

7. SPECIFICATIONS

Model Name	JBL p33
Brand	Generic
Connectivity Technology	Wireless (Bluetooth)
Wireless Communication Technology	Bluetooth
Headphones Jack	3.5 mm Jack
Sensitivity	92 dB
Noise Control	Sound Isolation
Included Components	Ear Cushions, Headband
Color (as per product data)	Blue (Note: Product title indicates "Black", but specifications list "blue". Please refer to your specific product color.)

8. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation provided at the time of purchase or contact your retailer. As this is a Generic brand product, specific warranty terms may vary by seller and region. Keep your proof of purchase for any warranty claims.

