

[manuals.plus](#) /

› [HMF](#) /

› [HMF Safe, Small with Key, Furniture Safe, 23 x 17 x 17 cm, Black Instruction Manual](#)

HMF 49216-02

HMF Safe Instruction Manual

Model: 49216-02

1. INTRODUCTION

This manual provides essential information for the safe and effective use of your HMF Small Furniture Safe. Please read these instructions carefully before setup and operation to ensure proper functionality and security.



Figure 1: HMF Small Furniture Safe (Model 49216-02) with the door open and key inserted.

2. SAFETY INFORMATION

Always adhere to the following safety guidelines:

- Keep keys in a secure location away from the safe. Do not store keys inside the safe.
- Ensure the safe is securely mounted to a wall or floor to prevent unauthorized removal.
- Do not attempt to force the lock or door.
- Keep the safe away from extreme temperatures and moisture.
- This safe is designed for storing valuables and documents; it is not fireproof or waterproof unless explicitly stated.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 1 x HMF Small Furniture Safe
- 2 x Double Point Keys
- 2 x Metal Dowels
- 2 x Fixing Screws



Figure 2: Included accessories: two double point keys and two metal dowels for secure mounting.

4. SPECIFICATIONS

Feature	Detail
Model Number	49216-02
Brand	HMF
External Dimensions (W x H x D)	23 x 17 x 17 cm
Internal Dimensions (W x H x D)	22.5 x 16.5 x 16.5 cm (suitable for DIN A5 documents)
Weight	2.35 kg
Material	Alloy Steel
Wall Thickness	1 mm (body), 3 mm (door)

Feature	Detail
Lock Type	Mechanical double-bit lock with three-bolt lock
Mounting	Prepared holes for wall or floor mounting



Figure 3: External dimensions of the HMF safe.

5. SETUP AND INSTALLATION

5.1 Unpacking

Carefully remove the safe and all accessories from the packaging. Inspect for any damage. Retain packaging for future transport or storage if needed.

5.2 Opening the Safe for the First Time

1. Locate one of the two double-bit keys provided.

2. Insert the key into the keyhole on the safe door.
3. Turn the key clockwise to unlock the safe.
4. Pull the door open.



Figure 4: Safe door open, revealing the three-bolt locking mechanism.

5.3 Mounting the Safe

The safe is equipped with pre-drilled holes for secure mounting to a wall or floor. This significantly enhances security.

1. Choose a suitable location for the safe, considering both accessibility and concealment.
2. Mark the drilling points on the wall or floor using the safe's pre-drilled holes as a template. The safe has two holes on the back and two on the bottom.
3. Drill holes at the marked points using an appropriate drill bit for your wall/floor material.
4. Insert the provided metal dowels into the drilled holes.

5. Align the safe with the dowels and secure it using the provided fixing screws. Ensure the safe is firmly attached and does not wobble.



Figure 5: Rear view of the safe, highlighting the pre-drilled mounting holes.

6. OPERATING THE SAFE

6.1 Locking the Safe

1. Ensure the safe door is fully closed.
2. Insert the double-bit key into the keyhole.
3. Turn the key counter-clockwise until it stops. The three bolts will extend, securing the door.
4. Remove the key and store it in a secure, separate location.



Figure 6: The safe in a closed and locked position.

6.2 Unlocking the Safe

1. Insert the double-bit key into the keyhole.
2. Turn the key clockwise until it stops. The three bolts will retract.
3. Pull the door open.
4. You can now access the contents of your safe.



Figure 7: Interior view of the safe, suitable for storing various small valuables.

7. MAINTENANCE

- **Cleaning:** Wipe the exterior of the safe with a soft, damp cloth. Avoid abrasive cleaners or solvents that could damage the finish.
- **Lock Mechanism:** The mechanical lock requires minimal maintenance. If the key turns stiffly, a small amount of graphite lubricant (not oil) can be applied to the key and inserted into the lock.
- **Inspection:** Periodically check the mounting screws to ensure they remain tight.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Key does not turn or turns stiffly.	Obstruction in keyhole, worn key, or dry lock mechanism.	Ensure no debris is in the keyhole. Try the second key. Apply a small amount of graphite lubricant to the key and insert into the lock.
Safe door does not open after unlocking.	Bolts not fully retracted, door stuck.	Ensure the key is turned fully clockwise. Gently pull the door. Do not force.
Safe feels loose after mounting.	Mounting screws are loose or not properly installed.	Tighten all mounting screws. If necessary, re-install the safe ensuring proper dowel and screw placement.

9. WARRANTY INFORMATION

HMF products are manufactured to high-quality standards. For specific warranty terms and conditions, please refer to the documentation provided at the time of purchase or visit the official HMF website. Keep your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

If you encounter any issues not covered in this manual or require further assistance, please contact HMF customer support:




Website: www.hmf.de (Please note: This is a general placeholder. Refer to your product packaging or purchase details for specific regional support contacts.)

Email: support@hmf.de



Related Documents - 49216-02

	<p>HMF Electronic Lock Safe: Instruction Manual and Operation Guide</p> <p>Detailed instructions for operating, setting up, and installing HMF electronic lock safes (models 4612112-4612812). Covers battery replacement, code management, emergency access, automatic locking, wall mounting, and troubleshooting.</p>
	<p>HMF Electronic Lock Safe: Instruction Manual and User Guide</p> <p>Comprehensive instructions for operating and installing HMF electronic lock safes (models 4612112-4612812), including setup, code management, troubleshooting, and wall mounting.</p>
	<p>HMF Furniture Safe with Electronic Lock: Instruction Manual</p> <p>Comprehensive instruction manual for the HMF Furniture Safe with Electronic Lock, covering setup, operation, code entry, emergency opening, battery replacement, anchoring, troubleshooting, safety guidelines, and disposal. Includes model numbers 46121 through 4612812.</p>

	<p>HMF 250442 Fireproof Document Safe: Instruction Manual</p> <p>Comprehensive instructions for the HMF 250442 fireproof and waterproof document safe, covering safe operation, storage, security, and warranty information.</p>
	<p>HMF Key Safe with Electronic Lock User Manual</p> <p>This manual provides instructions for operating and maintaining the HMF Key Safe with Electronic Lock, including setup, code entry, and troubleshooting.</p>
	<p>HMF Furniture Safe with Electronic Lock - Instruction Manual</p> <p>Comprehensive instruction manual for the HMF furniture safe with electronic lock (models 4612112, 4612212, 4612312, 4612412, 4612512, 4612812). Learn how to commission, set codes, operate, anchor, and troubleshoot your safe.</p>