

[Manuals.plus](#) /

› [STAPLES](#) /

› STAPLES Emerge Vortex Bonded Leather Gaming Chair, Black and Red, 2/Pack (58292-CCVS)

STAPLES 58292-CCVS

STAPLES Emerge Vortex Bonded Leather Gaming Chair User Manual

Model: 58292-CCVS

INTRODUCTION

The STAPLES Emerge Vortex Bonded Leather Gaming Chair is designed for high-performance users, offering advanced features for a comfortable and immersive seating experience. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your gaming chair.

Key features include:

- Bonded leather back and seat with color contrast stitching.
- Flip-up adjustable arms for flexible positioning.
- Padded headrest and plush cushions for enhanced comfort.
- Lumbar support, seat height adjustment, tilt tension, and tilt lock for customized support.
- Durable base supporting up to 275 lbs.
- Wear-resistant 360° casters for smooth mobility.

IMPORTANT SAFETY INFORMATION

Please read and understand all instructions before assembling and using this chair. Failure to follow these instructions may result in injury or damage to the product.

- Do not stand on the chair.
- Do not use the chair as a step stool.
- Ensure all bolts, screws, and knobs are securely tightened before use. Re-tighten periodically.
- Do not use this chair if any parts are missing, damaged, or worn. Contact customer support for replacement parts.
- Use this chair only for its intended purpose.
- Keep children away from moving parts during assembly.
- Avoid exposing the chair to direct sunlight or extreme temperatures to prevent material degradation.

COMPONENTS LIST

Before assembly, verify that all components are present and undamaged. If any parts are missing or damaged, do not

proceed with assembly. Contact customer support for assistance.

1. Backrest Assembly
2. Seat Cushion Assembly
3. Armrests (2)
4. Gas Lift Cylinder
5. Gas Lift Cover
6. Star Base
7. Casters (5)
8. Mechanism Plate
9. Hardware Pack (screws, washers, Allen wrench)

Built-in padded
headrest and
lumbar support
for comfort



Figure 1: Overview of main chair components. Ensure all parts are accounted for before beginning assembly.

ASSEMBLY INSTRUCTIONS

Follow these steps carefully for proper assembly. It is recommended to assemble the chair on a soft, clean surface to prevent scratching.

1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of the star base until they click securely into place.

Durable base holds up to 275 lbs.



Wear-resistant 360° casters

Figure 2: The durable five-star base with wear-resistant 360° casters. Ensure casters are fully inserted.

2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base. Cover the gas lift with the gas lift cover.
3. **Attach Mechanism to Seat:** Align the mechanism plate with the pre-drilled holes on the underside of the seat cushion. Ensure the front of the mechanism faces the front of the seat. Secure with screws provided in the hardware pack, tightening them firmly with the Allen wrench.
4. **Attach Armrests to Seat:** Attach the armrests to the sides of the seat cushion using the provided screws. Do not overtighten initially to allow for minor adjustments.
5. **Attach Backrest to Seat:** Align the backrest with the mounting brackets on the seat cushion. Secure with the remaining screws. Once all screws are in place, tighten all armrest and backrest screws firmly.
6. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the tapered end of the gas lift fits securely into the mechanism.

Once assembled, test all functions to ensure proper operation before regular use.

OPERATING INSTRUCTIONS

Your STAPLES Emerge Vortex Gaming Chair offers several adjustment features to customize your seating experience.

Seat Height Adjustment

To adjust the seat height:

- To raise the seat: While standing, pull the lever located on the right side of the chair upwards. The seat will rise automatically. Release the lever at the desired height.
- To lower the seat: While seated, pull the lever located on the right side of the chair upwards. The seat will lower. Release the lever at the desired height.

Sit at the perfect height



Lift lever to
adjust seat height



Flip-up
arms allow for
easier positioning
under a desk

Figure 3: Lift lever to adjust seat height. The chair allows you to sit at the perfect height for your desk.

Tilt and Tilt Lock Function

The chair features a tilt mechanism allowing you to recline and rock. The tilt tension can be adjusted to suit your preference.

- **To recline/rock:** Pull the same lever (used for height adjustment) outwards. The chair will now allow you to recline and rock.
- **To lock the tilt:** Push the lever inwards to lock the chair in an upright position.
- **Tilt Tension Adjustment:** Rotate the round knob located underneath the seat, at the front of the mechanism. Turn clockwise to increase tilt tension (making it harder to recline) or counter-clockwise to decrease tension (making it easier to recline).

90° – 120° Recline



Figure 4: The chair offers a 90° to 120° recline range and a full 360° swivel for versatile movement.

Armrest Adjustment

The armrests are designed to flip up, allowing for easier positioning under a desk or when not needed.

- To flip up the armrests: Grasp the armrest and rotate it upwards until it locks into the vertical position.
- To lower the armrests: Gently pull the armrest downwards until it returns to the horizontal position.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your gaming chair.

- **Cleaning:** For bonded leather surfaces, wipe with a soft, damp cloth. For tougher stains, use a mild soap solution and wipe dry immediately. Avoid harsh chemicals or abrasive cleaners.
- **Casters:** Periodically check casters for hair or debris buildup and clean as necessary to ensure smooth rolling.

- **Hardware:** Regularly inspect all screws and bolts to ensure they remain tight. Re-tighten as needed to maintain stability and safety.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause the bonded leather to fade or crack. Position the chair away from direct sunlight.
- **Weight Limit:** Do not exceed the maximum weight capacity of 275 lbs.



Bonded leather with
color-contrast stitching

Thick
foam
padding

Figure 5: Close-up of the bonded leather with color-contrast stitching and thick foam padding, highlighting the material quality.

TROUBLESHOOTING

If you encounter issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height.	Gas lift cylinder is faulty or lever is not engaged.	Ensure the lever is fully pulled up. If still unresponsive, the gas lift may need replacement. Contact customer support.
Chair is wobbly or unstable.	Loose screws or improper assembly.	Check and re-tighten all assembly screws, especially those connecting the backrest, armrests, and mechanism to the seat. Ensure the gas lift is fully seated in the base.
Casters do not roll smoothly.	Debris (hair, lint) caught in casters.	Turn the chair over and carefully remove any debris from the caster wheels.
Chair squeaks when moving.	Loose connections or friction between parts.	Re-tighten all screws. Apply a small amount of silicone lubricant to moving parts or joints if the squeaking persists.

PRODUCT SPECIFICATIONS

Detailed specifications for the STAPLES Emerge Vortex Bonded Leather Gaming Chair:

- Model:** 58292-CCVS
- Overall Dimensions:** 45.9 - 49.7"H x 28.4"W x 30.1"D
- Seat Dimensions:** 22"W x 18.6"D x 17.9-21.6"H (Floor to seat)
- Back Dimensions:** 29.9"H x 21.4"W
- Armrest Dimensions:** 28.3"-32.1"H x 21.7"W (Flip-up adjustable)
- Item Weight:** 43.6 pounds
- Maximum Weight Capacity:** 275 lbs.
- Material:** Bonded Leather
- Color:** Black and Red
- Recline Angle:** 90° - 120°
- Swivel:** 360°
- Certifications:** Meets or exceeds ANSI/BIFMA standards



Figure 6: Comprehensive dimensional overview of the gaming chair, including height, width, and depth measurements.

WARRANTY INFORMATION

This STAPLES Emerge Vortex Bonded Leather Gaming Chair comes with a**7-year manufacturer limited warranty**. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, please refer to the documentation included with your purchase or

contact customer support.

CUSTOMER SUPPORT

For any questions, assistance with assembly, missing parts, or warranty inquiries, please contact STAPLES customer support.

You can visit the official STAPLES store on Amazon for more information and support resources:

[Visit the STAPLES Store on Amazon](#)

© 2023 STAPLES. All rights reserved. Product specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question